

LEMEGA DR3

LEMEGA DR3P Portable Digital DAB/DAB+ and FM Radio User Manual

Model: DR3

1. INTRODUCTION

This manual provides instructions for the operation and maintenance of your LEMEGA DR3P Portable Digital Radio. Please read this manual thoroughly before using the device to ensure proper functionality and to understand all features.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x LEMEGA DR3P Portable Digital Radio
- 1 x USB-C Power Cable
- 1 x User Manual



Mains power and cable included



Owner's Manual included

Image: Package contents and product dimensions.

3. PRODUCT OVERVIEW

The LEMEGA DR3P radio features a compact design with a 2.4-inch TFT color display and intuitive controls for easy navigation between DAB/DAB+, FM, and Bluetooth modes.



**Dependable DAB/DAB+/FM
Radio, enhanced DAB+ signal
for full UK & Europe.**

Image: Front view of the LEMEGA DR3P radio.

Controls and Connections



Enjoy crystal clear sound for music and news radio, or use the convenient headphone jack for private listening.

Image: Close-up of the control panel.

- **Display:** 2.4-inch TFT color screen for station information, track details, and menu navigation.
- **Power/Volume Knob:** Press to power on/off, rotate to adjust volume.
- **Source Button:** Select between DAB, FM, and Bluetooth modes.
- **Menu/Back Button:** Access menu options or go back to the previous screen.
- **Info Button:** Display additional information about the current station or track.
- **Presets Button:** Access saved radio stations.
- **Alarm Button:** Set and manage alarms.
- **Sleep Button:** Activate the sleep timer function.
- **Navigation Buttons (◀▶):** Navigate through menus and stations.
- **Play/Pause Button (▶■■):** Control playback in Bluetooth mode.
- **Headphone Jack:** 3.5mm output for private listening.
- **USB-C Port:** For power supply.

4. SETUP

4.1 Powering the Device

The DR3P radio can be powered by mains electricity or AA batteries for portability.

- **Mains Power:** Connect the supplied USB-C cable to the radio's USB-C port and the other end to a compatible USB power adapter (not included in all packages, check contents) or a USB power source.
- **Battery Power:** For portable use, insert 4 x AA batteries (not included) into the battery compartment located on the back of the radio. The radio offers approximately 11 hours of battery life.

4.2 Initial Setup

1. **First Power On:** Press the Power/Volume knob to turn on the radio.
2. **Language Selection:** Follow the on-screen prompts to select your preferred language.
3. **Time and Date:** The radio will attempt to synchronize the time and date automatically via DAB or FM signals. If not, you can set it manually through the menu.
4. **DAB Auto-Scan:** Upon first use in DAB mode, the radio will automatically scan for available DAB/DAB+ stations. This process may take a few minutes.

5. OPERATING INSTRUCTIONS

5.1 Switching On/Off

Press the **Power/Volume** knob to turn the radio on or off.

5.2 Mode Selection

Press the **Source** button repeatedly to cycle through available modes: DAB, FM, and Bluetooth.

5.3 DAB/DAB+ Radio

1. Select DAB mode using the **Source** button.
2. The radio will display a list of available stations. Use the navigation buttons (◀▶) to browse.
3. Press the **Select** button (usually the Power/Volume knob pressed in) to choose a station.
4. To save a station as a preset, press and hold the **Presets** button. Select a preset number using the navigation buttons and press **Select** to confirm. The radio supports 40 presets.
5. To recall a preset, press the **Presets** button, then use navigation buttons to select the desired preset and press **Select**.

5.4 FM Radio

1. Select FM mode using the **Source** button.
2. To auto-scan for stations, press and hold the **Select** button. The radio will scan and stop at the next strong station.
3. To manually tune, use the navigation buttons (◀▶).
4. Saving and recalling presets works similarly to DAB mode (40 presets available).

5.5 Bluetooth Mode

The DR3P features Bluetooth 5.3 for wireless audio streaming.

1. Select Bluetooth mode using the **Source** button. The display will show "Bluetooth Pairing".
2. On your mobile device, enable Bluetooth and search for "LEMEGA DR3P".
3. Select the radio from your device's list to pair. Once connected, the radio will confirm.
4. You can now stream audio from your device to the radio. Use the radio's Play/Pause and navigation buttons to

control playback, or control directly from your paired device.



Image: Bluetooth streaming from a smartphone to the radio.

5.6 Alarm Function

The radio supports dual alarms with weekday/weekend settings.

1. Press the **Alarm** button to access alarm settings.
2. Select Alarm 1 or Alarm 2 and configure the time, source (DAB, FM, or buzzer), volume, and frequency (daily, weekdays, weekends).
3. To snooze an active alarm, press the **Snooze** button (usually the Power/Volume knob).
4. To turn off an alarm, press the **Alarm** button again.

5.7 Sleep Timer

The Sleep Timer allows the radio to turn off automatically after a set period.

1. Press the **Sleep** button.
2. Use the navigation buttons to select the desired sleep duration (e.g., 15, 30, 60, 90 minutes).

3. The radio will automatically switch off after the selected time.

5.8 Equalizer Settings

Adjust the audio output to your preference using the equalizer.

- 1. Press the **Menu/Back** button to enter the main menu.
- 2. Navigate to "Equalizer" or "EQ Settings".
- 3. Choose from preset modes (e.g., Normal, Classic, Jazz, Pop, Rock, Speech) or a custom setting.

5.9 Headphone Use

Connect 3.5mm headphones to the headphone jack for private listening. The main speaker will be muted automatically.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the radio's surface. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, remove the batteries and store the radio in a cool, dry place.
- **Antenna:** Extend the telescopic antenna fully for optimal DAB/FM reception. Handle with care to avoid damage.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Radio does not turn on	No power supply; flat batteries; power cable not connected.	Check power cable connection; replace batteries; ensure power adapter is working.
Poor DAB/FM reception	Weak signal; antenna not extended; interference.	Fully extend the antenna; reposition the radio; perform a full scan for stations.
Bluetooth device cannot pair	Radio not in pairing mode; device too far; Bluetooth off on device.	Ensure radio is in Bluetooth mode; move device closer; enable Bluetooth on your device.
No sound from speaker	Volume too low; headphones connected; mute activated.	Increase volume; disconnect headphones; check if mute is active.
Time/Date incorrect	No signal for auto-sync; manual setting required.	Ensure good DAB/FM signal; manually set time/date via menu.

8. SPECIFICATIONS

Feature	Detail
Model Number	DR3
Dimensions (L x W x H)	17.5 cm x 10.6 cm x 5.4 cm
Weight	405 g
Display	2.4-inch TFT Color Display

Feature	Detail
Radio Bands	DAB, DAB+, FM
Bluetooth Version	5.3
Connectivity	Auxiliary, Bluetooth, USB-C
Power Source	Corded Electric (USB-C) and Battery Powered (4 x AA batteries, not included)
Max Speaker Output	5 Watts
Audio Output Mode	Stereo
Material	Plastic
Manufacturer	LEMEGA
Origin	China

9. WARRANTY AND SUPPORT

The LEMEGA DR3P radio comes with a 1-year product warranty. For technical support, warranty claims, or further assistance, please refer to the contact information provided in your purchase documentation or visit the official LEMEGA website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

