Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC/DC Adapter for Bigasuo PRO302

onerbl AC/DC Adapter for Bigasuo PRO302 Projector User Manual

Model: AC/DC Adapter for Bigasuo PRO302

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/DC Adapter, designed for compatibility with the Bigasuo PRO302 Multimedia Projector. Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Guidelines

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open, modify, or repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is connected to a power outlet with the correct voltage (AC 100-240V).
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep the adapter away from children and pets.

This adapter features multiple protection mechanisms to safeguard your devices:

- **Over Voltage Protection:** Prevents damage from excessive voltage.
- **Over Heat Protection:** Shuts down if internal temperature exceeds safe limits.
- **Short-Circuit Protection:** Protects against short-circuit conditions.
- **Over-Current Protection:** Safeguards against excessive current draw.



Image: The adapter incorporates a smart chip for multiple safety protections, including short-circuit, over-voltage, and over-current protection, indicated by respective icons.

3. Product Overview

The onerbl AC/DC Adapter is designed to provide reliable power to your compatible devices, such as the Bigasuo PRO302 Multimedia Projector. It consists of the main adapter unit and a detachable power cord.



Image: Detailed dimensions of the AC/DC adapter, showing the main unit (4.2 inches long, 1.8 inches wide), the output cable (44.3 inches), and the input cable (79.3 inches), totaling a cable length of 127.8 inches.



Image: The detachable power cord, featuring a standard two-prong US plug for wall outlets and a C7 connector for the adapter unit.

4. Setup

Follow these steps to properly connect your AC/DC adapter:

1. **Connect the Power Cord:** Insert the C7 connector end of the detachable power cord firmly into the corresponding port on the AC/DC adapter unit.
2. **Connect to Device:** Plug the barrel connector from the adapter's output cable into the power input port of your Bigasuo PRO302 Multimedia Projector. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the two-prong plug of the power cord into a standard AC 100-240V wall outlet.
4. **Verify Connection:** A blue indicator light on the adapter unit will illuminate, confirming it is receiving power.




Image: The AC/DC adapter is shown correctly plugged into a wall outlet and connected to a device, illustrating a typical setup.

5. Operating Instructions

Once the adapter is properly set up and connected, you can power on your Bigasuo PRO302 Multimedia Projector as per its own operating instructions. The adapter will automatically provide the necessary power.

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Do not cover the adapter with cloths or other materials during operation.

6. Maintenance

Proper care and maintenance will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cables to prevent damage.
- **Inspection:** Periodically inspect the cables and connectors for any signs of wear, cuts, or damage. If any damage is found, discontinue use and replace the adapter.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Adapter indicator light is off.	No power from outlet; loose connection.	Check wall outlet with another device. Ensure all cable connections are secure.
Device not powering on/charging.	Adapter not receiving power; incorrect adapter; device issue.	Verify adapter indicator light is on. Confirm adapter compatibility with your device. Test device with another known working power source if available.
Adapter feels excessively hot.	Poor ventilation; overloaded.	Ensure adapter is in a well-ventilated area. Do not cover. Disconnect and allow to cool. If problem persists, discontinue use.

8. Specifications

- **Input:** AC 100-240V, 50/61Hz (Worldwide AC Input)
- **Output:** Specific output voltage and current are designed to match the Bigasuo PRO302 Multimedia Projector's requirements.
- **Connector Type:** Barrel Connector (for device connection)
- **Cable Length:** Approximately 127.8 inches (total length including adapter unit)
- **Protections:** Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection
- **Compatible Devices:** Bigasuo PRO302 Multimedia Projector

9. Warranty and Customer Support

For warranty information or customer support regarding your onerbl AC/DC Adapter, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C65CJNX9

More documents and user manuals: **https://manuals.plus/**