Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl B0C65GV594

onerbl 12V AC/DC Adapter for Fangor F-601 Projector User Manual

Model: B0C65GV594

1. Introduction

This manual provides instructions for the safe and effective use of the onerbl 12V AC/DC Adapter, designed for compatibility with the Fangor F-601 and F601 Video Projectors. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: The onerbl 12V AC/DC Adapter, showing the main adapter unit and the detachable power cord. This image illustrates the complete product package.

2. Safety Information

Observe the following safety precautions to prevent damage to the adapter or connected devices, and to ensure personal safety:

- Do not expose the adapter to water or excessive moisture.
- Do not disassemble or modify the adapter.
- Ensure the input voltage matches the specifications (AC 100-240V).
- Avoid using the adapter in extremely hot or cold environments.
- Keep out of reach of children.
- Disconnect from power outlet when not in use for extended periods.



Figure 2: This diagram illustrates the built-in safety features of the adapter, including short-circuit protection, over-voltage protection, and over-current protection, designed to safeguard your devices.

3. Specifications

Product Specifications

Feature	Detail
Model	B0C65GV594
Input Voltage	AC 100-240V, 50/60Hz (Worldwide Auto Input)
Output Voltage	12V DC
Compatibility	Fangor F-601, F601 Video Projector
Protection Features	Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection
Cable Length	Approximately 127.8 inches (324.6 cm) total




Figure 3: This image provides detailed dimensions of the adapter unit and the total cable length, including the AC input cord and the DC output cord. The total length is approximately 127.8 inches.

4. Setup Instructions

1. **Unpack the Adapter:** Carefully remove the onerbl 12V AC/DC Adapter and its power cord from the packaging.
2. **Connect the Power Cord:** Insert the AC power cord into the adapter's input port. Ensure a secure connection.
3. **Connect to Projector:** Plug the DC output connector of the adapter into the 12V DC input port of your Fangor F-601 or F601 Video Projector.
4. **Connect to Power Outlet:** Insert the AC power plug into a standard wall outlet (AC 100-240V).
5. **Verify Power:** A blue indicator light on the adapter typically illuminates when power is supplied, indicating it is ready for use.



Figure 4: This image demonstrates the adapter connected to a wall outlet and supplying power to a device, illustrating a typical setup scenario. The blue indicator light on the adapter is visible.

5. Operating the Adapter

The onerbl 12V AC/DC Adapter operates automatically once connected. It converts the AC wall power to the required 12V DC power for your compatible projector.

- Ensure all connections are firm before powering on your projector.
- The adapter is designed for continuous operation within its specified limits.
- If the adapter feels excessively hot, disconnect it immediately and check for proper ventilation or potential issues with the connected device.

6. Maintenance and Care

To ensure the longevity and optimal performance of your adapter:

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the cables excessively. Do not place heavy objects on the cables.



Figure 5: This image highlights the durable design of the adapter's cable, featuring a copper wire core and a robust PVC jacket for enhanced durability and safety.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Troubleshooting Guide

Problem	Possible Cause	Solution
No power indicator light	Loose connection, faulty outlet, adapter malfunction	Check all cable connections. Try a different wall outlet. If the issue persists, the adapter may be faulty.
Projector not powering on	Adapter not supplying power, projector issue	Ensure the adapter's indicator light is on. Verify the projector's power button and settings. Test the adapter with another compatible device if possible.
Adapter is hot to the touch	Overload, poor ventilation, internal fault	Disconnect immediately. Ensure adequate ventilation around the adapter. Verify the connected device's power requirements do not exceed the adapter's capacity.

8. Warranty Information

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact the seller directly. The warranty typically covers defects in materials and workmanship under normal use.

9. Customer Support

For technical assistance or inquiries regarding the onerbl 12V AC/DC Adapter, please contact your retailer or the manufacturer. When contacting support, please have your product model (B0C65GV594) and purchase information ready.
Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C65GV594

More documents and user manuals: **https://manuals.plus/**