

Bayer 26758AA

Bayer Pram Xeo Twin Doll Stroller Instruction Manual

Model: 26758AA

1. SAFETY INFORMATION

Attention! Not suitable for children under 3 years. Small parts. Choking hazard!

Always supervise children during play. Ensure all parts are securely assembled before use. Regularly check for any loose or damaged components.

2. PRODUCT OVERVIEW

The Bayer Pram Xeo Twin Doll Stroller is a modern and versatile accessory designed for dolls up to 18 inches (46 cm). It features a stylish green and white stars design, offering a realistic play experience for children aged 36 months to 8 years.

Key Features:

- **Twin Doll Capacity:** Designed to comfortably seat two dolls up to 18 inches (46 cm).
- **Adjustable Handle:** The handle height can be adjusted from 23-28 inches (58-71 cm) to accommodate growing children.
- **Flexible Sun Covers:** Features individual sun covers for each doll, providing protection from sun and wind.
- **Reversible Handles & Customizable Seating:** Allows for effortless maneuverability and various seating arrangements (forward-facing, parent-facing, or angled).
- **Integrated Shopping Basket:** Provides convenient storage space for doll accessories and other essentials.
- **Shoulder Bag:** Includes a practical matching shoulder bag for additional storage.
- **Compatibility:** Can be used with the EasyGo doll's car seat (sold separately) for enhanced play.

3. WHAT'S IN THE BOX

- 1 Doll Pram Frame
- 2 Doll Seats/Bassinets

- 1 Shoulder Bag

4. SETUP INSTRUCTIONS

Follow these steps to assemble your Bayer Pram Xeo Twin Doll Stroller. Refer to the video for visual guidance.

4.1 Frame Assembly

1. Unfold the main stroller frame until it locks into place.
2. Attach the handle bar by aligning the connectors and pushing until they click securely.
3. Insert the rear axle into the designated slots on the lower frame.
4. Attach the large rear wheels to the rear axle, ensuring they are firmly in place.
5. Attach the smaller front swivel wheels to the front legs of the frame, ensuring they click into position.



Image: The fully assembled Bayer Pram Xeo Twin Doll Stroller, showcasing its dual seats, adjustable handle, and storage basket.

4.2 Seat/Bassinet Attachment

1. Prepare the doll seats/bassinets by attaching the canopy frames and securing the fabric.
2. Attach the canopy to the seat/bassinet unit by snapping the fasteners.
3. Align the connectors on the bottom of the seat/bassinet unit with the attachment points on the stroller frame.
4. Push down firmly until each seat/bassinet clicks securely into place. Ensure both units are stable.



Image: Side view of the assembled stroller, highlighting the individual seats and canopies.

4.3 Accessory Attachment

- Attach the shoulder bag to the handle bar using the provided straps.

Setup Video Guide:

Your browser does not support the video tag.

Video: A comprehensive guide demonstrating the assembly and various features of the Bayer Pram Xeo Twin Doll Stroller.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Handle Height

To adjust the handle height, locate the adjustment buttons on either side of the handle. Press these buttons and simultaneously move the handle up or down to the desired height (23-28 inches / 58-71 cm). Release the buttons to lock the handle in place.

5.2 Reversing Seats and Handle

The seats can be easily removed and re-attached to face forward, backward (parent-facing), or in angled positions. The handle is also reversible, allowing you to push the stroller from either side without re-positioning the seats.

5.3 Adjusting Sun Covers

Each seat is equipped with a flexible sun cover. Adjust the canopy by pulling it forward or pushing it back to provide the desired amount of shade or protection for your dolls.

5.4 Using the Shopping Basket

The integrated shopping basket located beneath the seats provides ample space for carrying doll accessories, small toys, or other items during playtime adventures.

6. MAINTENANCE

- **Cleaning:** Wipe down the frame with a damp cloth and mild soap. Fabric parts can be spot cleaned or removed for gentle hand washing if necessary. Allow all parts to air dry completely.
- **Storage:** When not in use, store the stroller in a clean, dry place away from direct sunlight to prevent fading and material degradation.
- **Inspection:** Periodically check all screws, bolts, and fasteners to ensure they are tight and secure. Inspect wheels for any debris or damage that might affect smooth operation.

7. TROUBLESHOOTING

- **Wheels not rolling smoothly:** Check for hair, string, or other debris caught in the wheel axles. Clean as needed. Ensure wheels are properly attached.
- **Frame feels wobbly:** Verify that all frame connections are securely locked into place. Re-check assembly steps if necessary.
- **Seats not attaching securely:** Ensure the seat connectors are correctly aligned with the frame attachment points and pushed down until a click is heard.

8. SPECIFICATIONS

Product Dimensions	14.37 x 5.51 x 19.09 inches
Item Weight	6.71 pounds
Item Model Number	26758AA
Manufacturer Recommended Age	36 months - 8 years
Handle Height	23-28 inches (58-71 cm)
Manufacturer	Bayer Design

9. WARRANTY & SUPPORT

For warranty information or product support, please contact Bayer Design customer service directly. Keep your purchase receipt as proof of purchase.

Visit the official [Bayer Design Store](#) for more products and information.