

Lamshaw Lamshaw Smart Watch Band for Mindrose H80 / Wontrum Y70

Lamshaw 18mm Soft Silicone Magnetic Smart Watch Band
Instruction Manual

For Mindrose H80 1.47 inch Watch and Wontrum Y70 Smart Watch

1. PRODUCT OVERVIEW

The Lamshaw 18mm Soft Silicone Magnetic Smart Watch Band is a replacement strap designed for comfort and durability. It features a magnetic buckle for easy adjustment and a seamless connector interface for secure attachment to your compatible smart watch.

Material and Design

- **Material:** Soft, flexible, and eco-friendly silicone.
- **Resistance:** Sweat and water resistant, suitable for active lifestyles.
- **Closure:** Magnetic folding buckle for secure and adjustable fit.
- **Interface:** Seamless connector for a stable connection to the watch face.

Compatibility

This 18mm band is compatible with smart watches featuring a 1.47-inch watch face, specifically the **Mindrose H80 1.47 inch Watch** and the **Wontrum Y70 Smart Watch**.

Compatible with Model



Wontrum Y70 Watch



Mindrose H80 Watch

Image: The band is compatible with both Wontrum Y70 and Mindrose H80 smart watches.

2. INSTALLATION AND ADJUSTMENT

Attaching the Band

The band features a one-button removal system for quick and easy attachment and detachment. Align the connectors on the band with the slots on your smart watch and slide them into place until you hear a click, indicating a secure connection.



Image: The band features a seamless connector interface for easy attachment to your smart watch.

Adjusting the Magnetic Buckle

The magnetic folding buckle allows for precise and comfortable adjustment to fit your wrist. There are no traditional holes or clasps to deal with, simply slide the magnetic buckle along the strap to achieve your desired fit.

Magnetic Folding Buckle



New Upgrade Magnetic Folding Buckle Design

Pretty, convenient and stable

No need to deal with holes and clasp, adjust the length as you wish

Image: The magnetic folding buckle design allows for convenient and stable adjustment without traditional clasps.



【How to adjust】

Open the button on the back of the strap, adjust it to suit your wrist circumference, press the button, and the adjustment is complete

Image: To adjust, open the button on the back of the strap, adjust it to suit your wrist circumference, press the button, and the adjustment is complete.

Wrist Size Compatibility

The band is designed to fit a wide range of wrist sizes. The minimum wrist circumference is 5.7 inches (145mm), and the maximum wrist circumference is 8.25 inches (210mm).



Image: The band accommodates wrist sizes from 5.7 inches (145mm) to 8.25 inches (210mm).

Video Guide: Installation and Adjustment

Video: This video demonstrates the installation process of the silicone magnetic buckle sport replacement strap and how to adjust it for a comfortable fit.

3. CARE AND MAINTENANCE

To ensure the longevity and appearance of your Lamshaw smart watch band, follow these care instructions:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth to remove dirt and sweat. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the

silicone material.

- **Storage:** Store the band in a cool, dry place away from direct sunlight when not in use to prevent discoloration or degradation of the material.
- **Magnetic Buckle:** Keep the magnetic buckle free from metallic debris that could interfere with its function.

4. SPECIFICATIONS

Feature	Detail
Brand	Lamshaw
Band Width	18mm
Material	Soft Silicone
Clasp Type	Magnetic Buckle
Compatibility	Mindrose H80 1.47 inch Watch, Wontrum Y70 Smart Watch
Water Resistance	Sweat and Water Resistant
Minimum Wrist Size	5.7 inches (145mm)
Maximum Wrist Size	8.25 inches (210mm)
Item Weight	1.6 ounces (0.1 Pounds)
Product Dimensions	0.5 x 0.5 x 0.5 inches

5. SAFETY INFORMATION

Please observe the following safety guidelines:

- Ensure the band is securely attached to your smart watch before wearing to prevent accidental detachment and potential damage to the device.
- Avoid exposing the band to extreme temperatures or direct contact with sharp objects to prevent damage.
- If you experience any skin irritation, discontinue use and consult a healthcare professional.
- Keep the band out of reach of small children to prevent choking hazards from small parts.

6. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the product's original purchase platform or contact Lamshaw customer service directly. Details are typically available on the product listing page or within your order history.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C662M6JM>

More documents and user manuals: <https://manuals.plus/>