

[Manuals.plus](#) /

> [Skullcandy](#) /

> Skullcandy Kilo Wireless Bluetooth Speaker User Manual

Skullcandy 2SKSK1845B0L2

Skullcandy Kilo Wireless Bluetooth Speaker User Manual

Model: 2SKSK1845B0L2

INTRODUCTION

Thank you for choosing the Skullcandy Kilo Wireless Bluetooth Speaker. This compact and durable speaker is designed for portability and high-quality audio, featuring IPX7 waterproofing, a 24-hour battery life, and True Wireless Stereo pairing. This manual provides essential information for setting up, operating, and maintaining your speaker.





Image: The Skullcandy Kilo Wireless Bluetooth Speaker in black, showcasing its compact design.

Your browser does not support the video tag.

Video: An overview of the Skullcandy Kilo speaker, highlighting its features and portability.

WHAT'S IN THE BOX

- SKDY Kilo™ Wireless Speaker
- 1 x 3FT C-to-A Charging Cable
- 1 x User Manual

PRODUCT OVERVIEW

The Skullcandy Kilo speaker is designed for ease of use and durability. It features intuitive controls and a robust build suitable

for various environments.



Image: Key features of the Skullcandy Kilo speaker, including IPX7 waterproofing, 24-hour battery, and Bluetooth 5.3 connectivity.

Controls

- **Power Button (Center 'O')**: Press and hold to power on/off.
- **Volume Down ('-')**: Press to decrease volume.
- **Volume Up ('+')**: Press to increase volume.

Your browser does not support the video tag.

Video: Demonstrates the compact size and sound capabilities of the Skullcandy Kilo speaker.

SETUP

Charging Your Speaker

Before first use, fully charge your Skullcandy Kilo speaker. Use the provided USB-C to USB-A charging cable.

1. Connect the USB-C end of the cable to the charging port on the speaker.
2. Connect the USB-A end to a compatible USB power adapter (not included).
3. The LED indicator lights on the speaker will illuminate to show charging status.



Image: A close-up view of the USB-C charging port and battery indicator lights located on the side of the speaker.

Bluetooth Pairing

To connect your Skullcandy Kilo speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered off.
2. Press and hold the Power button (center 'O') until the speaker powers on and enters pairing mode (indicated by a flashing LED).
3. On your device, enable Bluetooth and search for 'SKDY Kilo' in the list of available devices.
4. Select 'SKDY Kilo' to connect. The LED will turn solid when connected.

True Wireless Stereo Pairing

For an immersive stereo experience, you can pair two Skullcandy Kilo speakers together:

1. Ensure both Kilo speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be your primary speaker), press the Power button twice quickly. It will enter TWS pairing mode.
3. The primary speaker will search for the secondary speaker. Once connected, both speakers will play audio in stereo.



Image: Two Skullcandy Kilo speakers shown side-by-side, illustrating the True Wireless Stereo pairing feature.

OPERATING YOUR SPEAKER

Portability and Attachment

The Skullcandy Kilo is designed for on-the-go use. It features an integrated aluminum anodized carabiner for easy attachment.

- Attach the speaker to your backpack, belt loop, bike, or any suitable hook.
- Its lightweight design makes it ideal for outdoor activities like hiking, camping, or simply hanging out at the park.



Image: The Skullcandy Kilo speaker clipped to a person's outdoor climbing gear, demonstrating its integrated carabiner and portability.

Your browser does not support the video tag.

Video: A comparison video highlighting the portability and attachment options of the Skullcandy Kilo speaker against another model.

Waterproof Features (IPX7)

The Kilo speaker boasts an IPX7 waterproof rating, meaning it can be submerged in up to 1 meter of water for up to 30 minutes without damage. This makes it perfect for use near pools, at the beach, or in rainy conditions.



Image: The Skullcandy Kilo speaker partially submerged in water, demonstrating its IPX7 waterproof capability.

MAINTENANCE

Cleaning

- To clean the speaker, use a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the speaker's finish or waterproof seals.
- Ensure the charging port is dry before charging after exposure to water.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to about 50% to prolong its lifespan.

TROUBLESHOOTING

Speaker Not Charging

- Ensure the charging cable is securely connected to both the speaker and the power adapter.
- Verify that the power adapter is functioning correctly and plugged into a live outlet.
- Check the USB-C port on the speaker for any debris or damage.
- Try using a different USB-C cable or power adapter.

Your browser does not support the video tag.

Video: A user demonstrating an issue where the speaker is not charging, which can be helpful for troubleshooting.

Bluetooth Pairing Issues

- Make sure the speaker is in pairing mode (flashing LED).
- Ensure your device's Bluetooth is enabled and within range (up to 10 meters).
- Forget 'SKDY Kilo' from your device's Bluetooth settings and attempt to pair again.
- If pairing two speakers for TWS, ensure both are disconnected from other devices before initiating TWS pairing.

Sound Quality Issues

- Check the volume levels on both the speaker and your connected device.
- Ensure there are no obstructions between the speaker and your device that could interfere with the Bluetooth signal.
- Move closer to your device to rule out range issues.
- If using TWS, ensure both speakers are placed optimally for stereo sound.

SPECIFICATIONS






Image: Visual representation of the Skullcandy Kilo speaker's dimensions: 4.7 inches (height), 3.25 inches (width), and 2 inches (depth).

Feature	Detail
Brand	Skullcandy
Model Number	2SKSK1845B0L2
Connectivity Technology	Bluetooth, USB, Wireless
Bluetooth Range	10 Meters
Waterproof Rating	IPX7
Battery Life	Up to 24 Hours
Speaker Maximum Output Power	10 Watts
Audio Output Mode	Stereo
Item Dimensions (D x W x H)	2"D x 3.25"W x 4.7"H

Enclosure Material	Aluminum
Control Method	Voice

WARRANTY AND SUPPORT

The Skullcandy Kilo Wireless Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, product support, or to register your product, please visit the official Skullcandy website or contact their customer service.

Official Skullcandy Website: www.skullcandy.com