

Hoffen HBG-900-2

Hoffen HBG-900-2 Cordless Showerproof Body Shaver User Manual

Model: HBG-900-2

INTRODUCTION

Thank you for choosing the Hoffen HBG-900-2 Cordless Showerproof Body Shaver. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.

The Hoffen HBG-900-2 is designed for body grooming, offering a comfortable and efficient shaving experience. Its waterproof design allows for use in the shower, and the skin protection system helps prevent nicks and irritation.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Hoffen HBG-900-2 Body Shaver:

- **Trimming Head:** The main shaving component with blades and skin protection.
- **Power On/Off Button:** Activates and deactivates the device.
- **Battery Cover:** Located at the bottom, provides access to the battery compartment.
- **Silicone Hanging Loop:** For convenient storage.
- **3mm Trimmer Comb:** Attachable comb for trimming hair to a 3mm length.
- **0.5mm Skin Protector:** Attachable guard for sensitive areas, providing a 0.5mm trim.
- **Cleaning Brush:** For removing hair residue from the trimming head.



Image 1: Hoffen HBG-900-2 Body Shaver with its main components, including the 0.5mm skin protector and 3mm trimmer comb attachments.



Image 2: Disassembled view of the Hoffen HBG-900-2, illustrating the main unit, detachable trimming head, 3mm trimmer comb, and 0.5mm skin protector.



Image 3: The Hoffen HBG-900-2 Body Shaver shown with its accessories: a cleaning brush, the 3mm trimmer comb, and the silicone hanging strap.

SETUP

1. Battery Installation

1. Locate the battery cover at the bottom of the shaver.
2. Twist or slide the battery cover to open it.
3. Insert one 1.5-volt AA alkaline battery (not included), ensuring correct polarity (+/-).
4. Close the battery cover securely to maintain the device's waterproof seal.

2. Attaching Combs/Protectors

- To attach the 3mm Trimmer Comb or 0.5mm Skin Protector, align the attachment with the trimming head and press firmly until it clicks into place.
- To remove, gently pull the attachment away from the trimming head.

OPERATING INSTRUCTIONS

General Use

1. Ensure the battery is correctly installed and the battery cover is sealed.
2. Press the Power On/Off button to start the shaver.
3. For sensitive areas, it is recommended to use the 0.5mm Skin Protector or the 3mm Trimmer Comb. Do not remove the comb when shaving sensitive areas.
4. Move the shaver gently against the direction of hair growth for optimal results. The bidirectional trimmer is designed to cut hair growing in any direction.
5. The shaver is 100% waterproof and can be used in the shower.
6. After use, press the Power On/Off button to turn off the device.

Tips for Best Results

- For longer hair, trim it shorter with the 3mm comb before attempting a closer shave with the 0.5mm protector or directly with the trimming head.
- Stretch the skin taut with your free hand to ensure a smooth surface for shaving.
- Clean the trimming head regularly to maintain performance.

MAINTENANCE

Cleaning the Shaver

1. Turn off the shaver before cleaning.
2. Remove any attached comb or skin protector.
3. Rinse the trimming head under running water. The shaver is waterproof, so you can rinse the entire head.
4. Use the provided cleaning brush to remove any trapped hairs from the blades and inside the trimming head.
5. Allow the trimming head and shaver body to air dry completely before reattaching components or storing.

Battery Replacement

When the shaver's performance decreases, it's time to replace the AA battery. Follow the battery installation steps in the "Setup" section.

Important: Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is dead or incorrectly installed.	Replace the AA battery or check its polarity. Ensure the battery cover is securely closed.
Poor shaving performance / pulling hair.	Trimming head is clogged with hair or battery is low.	Clean the trimming head thoroughly. Replace the battery.

Problem	Possible Cause	Solution
Shaver makes unusual noise.	Hair trapped in the mechanism or component not properly seated.	Clean the trimming head. Ensure the trimming head is securely attached to the main unit.

SPECIFICATIONS

Model: HBG-900-2

Brand: Hoffen

Power Source: 1 x 1.5V AA Battery (not included)

Special Feature: Cordless, 100% Waterproof

Blade Material: Titanium

Head Type: Foil

Dimensions (Package): 20 x 8 x 4 cm

Weight (Product): 250 Grams

Color: Black

Manufacturer: Ace Incorporation

WARRANTY AND SUPPORT

This Hoffen HBG-900-2 Body Shaver comes with a **1-year replacement warranty** against any manufacturing defects from the date of purchase.

For warranty claims or technical support, please contact your retailer or the manufacturer directly. Keep your proof of purchase for warranty validation.