

[Manuals.plus](#) /

> [COSTWAY](#) /

> COSTWAY 4-Piece Patio Rattan Furniture Set Instruction Manual (Model 67841+-CYWH)

COSTWAY 67841+-CYWH

COSTWAY 4-Piece Patio Rattan Furniture Set Instruction Manual

Model: 67841+-CYWH

1. PRODUCT OVERVIEW

This manual provides instructions for the assembly, use, and maintenance of your COSTWAY 4-Piece Patio Rattan Furniture Set. This set includes one loveseat, two single chairs, and one coffee table, designed for outdoor use in various settings such as yards, balconies, backyards, and poolside areas.

Product Dimension

Loveseat X 1
Armchair X 2
Coffee Table X 1



Image: The complete 4-piece patio rattan furniture set, featuring a loveseat, two single chairs, and a coffee table, arranged in an outdoor setting.

2. SAFETY INFORMATION

Please read and understand all safety information before assembling and using this product. Failure to follow these instructions may result in injury or damage.

- Assemble the furniture strictly according to the instructions provided.
- Do not exceed the weight capacity of each furniture piece.
- Ensure the furniture is stable and does not tip over, especially when used by children.
- Keep small parts and sharp edges away from children during assembly and use.
- Inspect the furniture regularly for any signs of wear, damage, or loose connections. Tighten fasteners as needed.
- Avoid prolonged exposure to rain to extend the service life of the furniture.

3. INCLUDED COMPONENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- 1 x Coffee Table
- 1 x Instruction Manual
- 1 x Loveseat
- 2 x Armchairs
- 4 x Seat Cushions
- 4 x Back Cushions

All installing accessories for the entire set are typically found in Box 1.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches.

4.1 Assembly Video Guide

For a visual guide, please watch the official assembly video:

Your browser does not support the video tag.

Video: Official assembly guide for the COSTWAY 4-Piece Patio Rattan Furniture Set. This video demonstrates the step-by-step process of putting together each component of the set.

4.2 Step-by-Step Assembly

Please do not tighten screws completely until all screw holes are lined up and all components are loosely assembled. Then, tighten all screws securely.

4.2.1 Single Chair Assembly

1. Connect the backrest (A) with the seat base (B) using bolts and washers.
2. Attach the side panels (C) to the assembled backrest and seat base using bolts and washers.
3. Ensure all connections are secure before proceeding.

4.2.2 Loveseat Assembly

1. Connect the loveseat backrest (D) with the loveseat seat base (E) using bolts and washers.
2. Attach the side panels (F, G) to the assembled loveseat backrest and seat base using bolts and washers.
3. Ensure all connections are secure before proceeding.


4.2.3 Coffee Table Assembly

1. Assemble the coffee table frame (I, K, L) using the provided bolts and washers.
2. Place the tempered glass tabletop (O) onto the assembled coffee table frame. Suction cups on the frame will help secure the glass.



Image: Product dimension diagram for the loveseat, armchair, and coffee table, indicating length, width, and height measurements.

Practical Coffee Table



**Premium
Tempered Glass**




**Lower Shelf
for Extra Storage**




**Securely Fixed
by 5 Suckers**

Image: Detailed view of the coffee table, highlighting its premium tempered glass top, lower shelf for additional storage, and secure fixation by suction cups.



Breathable &
Wear-resistant Rattan




Thick & Resilient
Sponge Cushion



Zippered Cover for
Easy Cleaning

Image: Detailed view of the cushion and rattan material, emphasizing the breathable and wear-resistant rattan, thick and resilient sponge cushion, and zippered cover for easy cleaning.

Product Details



Sturdy Cross-shaped Structure



Comfortable & Wide Armrest



Anti-slip Foot Pads

Image: Key product details, including the sturdy cross-shaped structure for stability, comfortable and wide armrests, and anti-slip foot pads to protect surfaces.

5. CARE AND MAINTENANCE

Proper care will extend the life and appearance of your patio furniture set.

- **Cleaning:** Wipe the rattan and metal frames with a dry cloth. For tougher dirt, use a damp cloth with mild soap and water, then wipe dry.
- **Cushion Care:** The cushion covers feature smooth zippers for easy removal. Machine wash covers on a gentle cycle with cold water and air dry. Do not bleach.
- **Glass Tabletop:** The tempered glass tabletop is anti-scratch and easy to clean. Use a glass cleaner and a soft cloth.
- **Weather Protection:** While the set is designed for all-weather use, prolonged exposure to harsh weather conditions (heavy rain, strong sun, snow) can reduce its lifespan. Consider using a furniture cover or storing cushions indoors during extreme weather.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Tighten as necessary.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------------------------|--|
| Color | Grey |
| Material Type | Rattan, Steel, Sponge, Polyester Cloth |
| Loveseat Dimensions (L x W x H) | 48.5" x 26.5" x 30" |
| Armchair Dimensions (L x W x H) | 28.5" x 26.5" x 30" |
| Coffee Table Dimensions (L x W x H) | 34" x 19.5" x 14" |
| Item Weight | 89 Pounds |
| Loveseat Weight Capacity | 800 lbs |
| Armchair Weight Capacity | 400 lbs (each) |
| Required Assembly | Yes |

7. TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following common solutions:

- **Missing Parts:** Double-check all packaging materials. If parts are genuinely missing, contact COSTWAY customer support with your model number and a description of the missing parts.
- **Difficulty Aligning Holes:** Ensure all bolts are only finger-tightened initially. This allows for slight adjustments to align all holes before fully tightening. If a hole is still misaligned, slightly loosen adjacent bolts.
- **Unstable Furniture:** After assembly, ensure all bolts are fully tightened. Check that the furniture is on a level surface. If an individual leg is uneven, anti-slip foot pads can sometimes be adjusted or shims can be used.
- **Damaged Components:** Do not attempt to use damaged components. Contact customer support for replacement parts.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact COSTWAY customer service directly. Keep your purchase receipt and model number (67841+-CYWH) handy for faster service. You can typically find contact information on the product packaging or the official COSTWAY website.