

Yaheetech B0C694M75B

Yaheetech Mid-Century Accent Chairs Instruction Manual

Model: B0C694M75B

Brand: Yaheetech

1. PRODUCT OVERVIEW

The Yaheetech Mid-Century Accent Chairs are designed to provide comfortable seating with a modern aesthetic. These upholstered chairs feature a button-tufted back, wide track arms, and solid wood legs, making them suitable for various indoor settings such as living rooms, bedrooms, or offices.

Key features include:

- **Comfortable and Supportive:** Cushioned seat with sinuous springs and a gently slanted backrest for optimal support.
- **Elegant Tufted Design:** A stylish button-tufted backrest enhances the chair's visual appeal.
- **Sturdy Construction:** Crafted with durable rubberwood legs and plastic foot pads to protect floors. Maximum loading capacity is 136 kg (300 lb).
- **Compact Design:** Ideally proportioned for small spaces, including apartments, guest rooms, or reading nooks.
- **Versatile Aesthetic:** Contemporary design with mid-century inspiration, complementing various decor styles.



Image 1.1: Two Yaheetech Mid-Century Accent Chairs in Retro Brown faux leather, showcasing their design and color.



Blind Biscuit Tufting



Water-resistant Upholstery



Solid Wood Legs



Wide Track Arms



Soft Seat Cushion

Image 1.2: Detailed view of the chair's features: blind biscuit tufting on the back, water-resistant upholstery, solid wood legs, wide track arms, and a soft seat cushion.

Your browser does not support the video tag.

Video 1.1: An official Yaheetech video showcasing the upholstered living room chair.

2. PACKAGE CONTENTS

Upon opening the package, ensure all components are present and undamaged. The package typically includes:

- Chair body (seat and arms)
- Backrest
- 4 x Solid Wood Legs
- Assembly Hardware (screws, washers, Allen wrench)
- User Manual (this document)

If any parts are missing or damaged, please contact customer support.

3. SETUP AND ASSEMBLY

Assembly is required and can be completed with basic tools provided. Follow these steps for proper setup:

1. **Attach the Legs:**

Carefully turn the main chair body upside down on a soft, clean surface to prevent scratching. Locate the pre-drilled holes and corresponding labels (e.g., C for front legs, arrows for alignment) on the underside of the chair and on the leg plates.

Attach each leg using the provided screws and washers. Hand-tighten the screws initially to allow for minor adjustments. Once all screws are in place, use the Allen wrench to fully tighten them, ensuring the legs are secure and stable.



Maximum Weight capacity: 300 lb

Image 3.1: Chair dimensions for reference during assembly.

Your browser does not support the video tag.

Video 3.1: Official Yaheetech installation guide demonstrating how to attach the chair legs and backrest.

2. Attach the Backrest:

Once the legs are securely attached, turn the chair upright. Locate the metal brackets on the sides of the chair body and on the backrest. Align the backrest brackets with the chair body brackets and slide the backrest down until it clicks securely into place.

Ensure both sides of the backrest are properly engaged with the brackets for a stable fit.

Your Yaheetech Mid-Century Accent Chair is now assembled and ready for use.

4. OPERATING INSTRUCTIONS

The Yaheetech Mid-Century Accent Chair is designed for comfortable seating in various indoor environments. Simply sit and enjoy its supportive cushioning and ergonomic design.



Image 4.1: The accent chair positioned in a living room, demonstrating its suitability for various home settings.



Image 4.2: The chair's versatility is highlighted by its placement in different environments: living room, bedroom, study, and restaurant.

5. MAINTENANCE

To ensure the longevity and appearance of your Yaheetech Mid-Century Accent Chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For spills, spot clean immediately. Avoid harsh chemicals or abrasive cleaners.
- **General Care:** Regularly check and tighten all screws to maintain stability. Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 136 kg (300 lb).



Image 5.1: The water-resistant faux leather upholstery is easy to clean, as shown by water droplets beading on the surface.

6. TROUBLESHOOTING

If you encounter any issues with your chair, consider the following common solutions:

- **Wobbling:** Ensure all leg screws are securely tightened. Check that the chair is placed on a flat, even surface.
- **Loose Backrest:** Verify that the backrest brackets are fully engaged and clicked into the chair body.
- **Stains/Marks:** Refer to the cleaning instructions in the Maintenance section. For persistent stains, consult a professional upholstery cleaner.

For further assistance, please contact Yaheetech customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	B0C694M75B
Color	Retro Brown
Product Dimensions	29"D x 28.5"W x 33"H
Quantity	Set of 2
Back Style	Solid Back
Special Feature	Arm Rest
Product Care Instructions	Wipe Clean
Recommended Uses	Bedroom, Living Room, Office
Maximum Weight Recommendation	136 kg (300 Pounds)
Material	Faux Leather (Upholstery Fabric Type: suede), Foam (Fill Material)
Leg Style	Tapered Leg
Item Weight	17.37 kg (38.3 pounds) per chair



Image 7.1: The accent chairs integrated into a commercial setting, highlighting their robust design.

8. IMPORTANT SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- Assembly required. Some basic tools may be needed.
- Do not exceed the maximum weight capacity of 136 kg (300 pounds).
- This chair is intended for indoor use only.
- Keep away from open flames and excessive heat.
- Ensure all parts are correctly assembled and tightened before use.






9. WARRANTY AND SUPPORT

For warranty information, product support, or to report any issues, please visit the official Yaheetech website or contact their customer service department. Please have your model number (B0C694M75B) and purchase details ready when contacting support.

You can find more information and contact details on the [Yaheetech Brand Store](#).

© 2023 Yaheetech. All rights reserved.

Related Documents - B0C694M75B

	<p>Yaheetech 592438 Accent Chair Assembly Instructions</p> <p>Comprehensive assembly guide for the Yaheetech 592438 accent chair. This manual provides step-by-step instructions, a parts list, and maintenance tips for easy setup and care of your new furniture.</p>
	<p>Yaheetech 615118 Armchair Assembly Instructions and Care Guide</p> <p>Comprehensive assembly instructions, care guide, and safety information for the Yaheetech 615118 armchair. Includes parts list, step-by-step assembly, and maintenance tips.</p>
	<p>Yaheetech 611622 Armchair Assembly Instructions and Care Guide</p> <p>Comprehensive assembly instructions, safety warnings, parts list, and care guide for the Yaheetech 611622 armchair. Includes troubleshooting and contact information.</p>
	<p>Yaheetech 593172 Patio Dining Chairs Assembly Instructions</p> <p>This document provides assembly instructions for the Yaheetech 593172 patio dining chairs. It includes safety warnings, assembly steps with diagrams, and product care instructions in multiple languages.</p>
	<p>Yaheetech Dining Chair Assembly Instructions (Model 611269)</p> <p>Step-by-step assembly guide for the Yaheetech Dining Chair, Model 611269. Includes safety precautions, parts identification, and detailed instructions for building your chair.</p>



1. Please read this instruction manual carefully before attempting to assemble.
2. The chair is designed for indoor use only. It is not suitable for outdoor use.
3. The chair is not intended for use by children under the age of 16.
4. The chair is not intended for use by people with back problems or other medical conditions.
5. The chair is not intended for use by pregnant women.
6. The chair is not intended for use by people who are unable to sit for long periods of time.
7. The chair is not intended for use by people who are unable to stand for long periods of time.
8. The chair is not intended for use by people who are unable to walk for long periods of time.
9. The chair is not intended for use by people who are unable to climb stairs for long periods of time.
10. The chair is not intended for use by people who are unable to get in and out of the chair for long periods of time.
11. The chair is not intended for use by people who are unable to sit on the chair for long periods of time.
12. The chair is not intended for use by people who are unable to stand on the chair for long periods of time.
13. The chair is not intended for use by people who are unable to walk on the chair for long periods of time.
14. The chair is not intended for use by people who are unable to climb on the chair for long periods of time.
15. The chair is not intended for use by people who are unable to get in and out of the chair for long periods of time.
16. The chair is not intended for use by people who are unable to sit on the chair for long periods of time.
17. The chair is not intended for use by people who are unable to stand on the chair for long periods of time.
18. The chair is not intended for use by people who are unable to walk on the chair for long periods of time.
19. The chair is not intended for use by people who are unable to climb on the chair for long periods of time.
20. The chair is not intended for use by people who are unable to get in and out of the chair for long periods of time.



[Yaheetech 612415 Rocking Chair Assembly and Care Instructions](#)

Comprehensive assembly guide and maintenance tips for the Yaheetech 612415 rocking chair. Learn how to assemble, care for, and maintain your Yaheetech glider chair for optimal use.