

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gaiatop](#) /
- › [GAIATOP Portable Handheld Fan \(Model Fan-FS08\) User Manual](#)

Gaiatop Fan-FS08

GAIATOP Portable Handheld Fan (Model Fan-FS08) User Manual

Comprehensive user manual for the GAIATOP Portable Handheld Fan (Model Fan-FS08), detailing setup, operation, maintenance, troubleshooting, and specifications.

1. INTRODUCTION

Thank you for choosing the GAIATOP Portable Handheld Fan. This versatile 3-in-1 device functions as a handheld fan, a desktop fan, and a backup power bank. Its compact, foldable design makes it ideal for various indoor and outdoor activities, providing up to 17 hours of cooling time.



Image: The GAIATOP Portable Handheld Fan showcasing its compact folded form, handheld use, and desktop setup.

2. KEY FEATURES

- **Foldable Mini Size & Powerful Airflow:** Compact (4.4"x1.4"x1.5", 4oz) with an upgraded motor for strong wind.
- **Extended Cooling Time:** Up to 17 hours on Speed 1, 10 hours on Speed 2. Rechargeable via USB.
- **Versatile 3-in-1 Functionality:** Use as a handheld fan (180° unfolded), a desktop fan (90° or 270°), or a backup power bank.
- **Safety & Easy Operation:** Features touchable, soft blades with surge and short circuit protection. Simple push-button control for power and speed.
- **Integrated Flashlight:** Provides additional utility in low-light conditions.

3. PACKAGE CONTENTS

- 1 x GAIATOP Portable Handheld Fan (Model Fan-FS08)
- 1 x Type-C Charging Cable
- 1 x User Manual

4. SETUP

4.1 Initial Charging

1. Before first use, fully charge the fan.
2. Locate the Type-C charging port on the fan.
3. Connect the provided Type-C cable to the fan and a suitable USB power source (e.g., wall adapter, computer USB port).
4. The LED indicator will show charging status. A full charge typically takes a few hours.

Foldable Design for Multiple Functions



0°
Power Bank



180°
Hand Fan



90°/270°
Desk Fan



Image: The GAIATOP Portable Handheld Fan displaying its Type-C charging port and LED indicator.

5. OPERATING INSTRUCTIONS

5.1 Unfolding the Fan

The fan features a 3-stage foldable design. To unfold:

- **Method 1:** Gently open from the small gap between the cover and the fan body at the top.
- **Method 2:** Press the base slightly where the button is, then pull off the top cover.



Image: Visual guide demonstrating two methods to unfold the GAIATOP Portable Handheld Fan.

5.2 Power On/Off and Speed Settings

1. To turn the fan on, short press the power button. It will start at Speed 1.

2. Short press again to switch to Speed 2.
3. Short press a third time to turn the fan off.
4. The digital display will show the current speed setting or battery percentage.

Soft TPE Blades Safety Ensure



Method 1: Open from the Small
Gap at Top



Method 2: Press the Switch Base
Then Pull off the Exposed Top

Image: The fan shown in handheld mode (180° unfolded) and desktop mode (90° angle).

5.3 Using as a Desktop Fan

The fan can be folded to a 90° or 270° angle to stand on a flat surface, converting it into a mini desktop fan.

5.4 Using as a Backup Power Bank

The fan can also serve as a backup power bank. Connect your device to the USB-A output port on the fan using your device's charging cable. This feature is useful for charging small electronic devices on the go.




Image: The fan connected via USB to charge a mobile phone, demonstrating its power bank functionality.

5.5 Flashlight Function

To activate the flashlight, long press the power button. Long press again to turn it off.

6. MAINTENANCE

- Keep the fan in a dry place when not in use.
- To clean, gently wipe the exterior with a soft, dry cloth. Do not use harsh chemicals or immerse in water.
- The soft TPE blades are designed to stop automatically if touched, ensuring safety. Avoid intentionally obstructing the blades during operation.

7. TROUBLESHOOTING

- **Fan not turning on:** Ensure the battery is charged. Connect to a power source using the Type-C cable.
- **Weak airflow:** Check the speed setting and ensure the fan blades are free from obstruction.
- **Charging issues:** Verify the Type-C cable is securely connected to both the fan and the power source. Try a different cable or power adapter if necessary.
- **Power bank not charging device:** Ensure the fan has sufficient charge. Use a compatible USB-A cable for your device.

8. SPECIFICATIONS

Feature	Specification
Brand	Gaiatop
Model Name	Fan-FS08
Product Dimensions	1.4"D x 1.5"W x 4.26"H
Item Weight	4.8 ounces
Power Source	Battery Powered (1 Lithium Ion battery included)
Voltage	5 Volts
Wattage	1.5 watts
Number of Power Levels	2
Control Method	Touch (Push Button)
Reusability	Rechargeable
Special Features	10-17 Hours Cooling Time, 3 in 1 Handheld & Desk Fan, Backup Power Bank, Mini Size Foldable Small Fan

9. WARRANTY & SUPPORT

For any product inquiries, technical support, or warranty claims, please contact Gaiatop customer service. Refer to the

product packaging or the official Gaiatop website for contact information.

