HOGOKIDS 301153

HOGOKIDS Flowers Music Box Building Block Kit

Model: 301153

Introduction

This instruction manual provides detailed guidance for assembling, operating, and maintaining your HOGOKIDS Flowers Music Box Building Block Kit. This creative botanical collection set allows you to construct a beautiful floral display that also functions as a music box with integrated lighting. Designed for ages 6 and up, it offers an engaging building experience resulting in a unique decorative piece.



Image: The HOGOKIDS Flowers Music Box Building Block Kit, showcasing the assembled product alongside its packaging.

What's in the Box

Upon opening the package, verify that all components are present:

- 571 Building Blocks (various shapes and colors for flowers, teacup, and base)
- Music Box Mechanism
- LED Light String and Battery Box (batteries not included)
- Illustrated Instruction Manual

Setup and Assembly

Follow the step-by-step instructions provided in the included manual for proper assembly. It is recommended to sort the building blocks by color and shape before beginning to facilitate the process.

1. **Preparation:** Unpack all components and lay them out on a clean, flat surface. Identify the main base, teacup, and various flower pieces.
2. **Base Assembly:** Begin by assembling the base structure as indicated in the manual. This will house the music box mechanism and battery compartment for the lights.
3. **Music Box and Light Installation:** Carefully install the music box mechanism and thread the LED light string according to the manual's diagrams. Ensure the light string is positioned to illuminate the floral arrangement.
4. **Floral Construction:** Proceed with building the individual flower components. The kit includes various flower types such as orchids, roses, Chinese roses, peonies, and embroidery balls.
5. **Teacup and Waterfall Assembly:** Attach the teacup to the top of the structure and arrange the assembled flowers to create the cascading 'waterfall' effect as depicted in the instructions.
6. **Final Touches:** Secure all pieces firmly. Due to the intricate design, some parts may require careful handling during assembly to ensure stability.



Image: A person engaged in the assembly of the HOGOKIDS flower music box building kit, following the instructions.



Image: A close-up showing the variety of flower building block pieces, including orchids, roses, Chinese roses, peonies, and embroidery balls.

Operating Instructions

Once assembled, your HOGOKIDS Flowers Music Box can be operated as follows:

- **Music Box Function:** To activate the music, gently rotate the base of the assembled unit clockwise. The music box will play a melodious tune.
- **Lighting Function:** Locate the light switch on the battery box, typically integrated into the base. Flip the switch to the 'ON' position to illuminate the floral display. Ensure batteries are correctly installed in the battery compartment.



Image: The assembled HOGOKIDS flower music box, highlighting the light switch module for illumination.



Image: The HOGOKIDS flower music box illuminated with soft lighting, creating a romantic ambiance.

Maintenance

To ensure the longevity and appearance of your music box:

- **Cleaning:** Gently wipe the assembled model with a dry, soft cloth to remove dust. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the product in a dry environment, away from direct sunlight or extreme temperatures, to prevent material degradation or fading.
- **Handling:** Handle the assembled music box with care, especially when rotating the base for music, to avoid dislodging any building blocks.

Troubleshooting

If you encounter any issues with your HOGOKIDS Flowers Music Box, refer to the following common solutions:

- **Blocks Not Staying Together:** Ensure each block is fully pressed into place. Verify that you are using the correct pieces as indicated in the instruction manual. If a connection feels loose, re-examine the assembly step.
- **Music Box Not Playing:** Confirm that the base is being rotated in the correct direction (clockwise) and that there are no obstructions preventing its movement.
- **Lights Not Working:** Check that batteries are installed correctly with the correct polarity. Replace old batteries with new ones if necessary. Ensure the light switch is in the 'ON' position.

Specifications

Attribute	Detail
Product Name	Flowers Music Box Building Block Kit
Model Number	301153
Number of Pieces	571
Product Dimensions (Assembled)	Approximately 10 inches (25.5 cm) high, 4.3 inches (11 cm) diameter
Item Weight	3.2 ounces
Material	ABS Plastic
Manufacturer Recommended Age	6 years and up
Manufacturer	GUANGDONG SEMBO CULTURE INDUSTRY CO., LTD



Image: Visual representation of the product dimensions.



Image: Product information as presented in the instruction manual.

Safety Information

Please observe the following safety precautions:

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.

- **Adult Supervision:** This toy must be used under direct supervision of an adult.




Image: Safety warnings from the product manual.

Support

For any inquiries or assistance, please contact HOGOKIDS customer support:

- **Email:** info@hogokidstoys.com
- **Website:** www.hogokidstoys.com

© 2025 HOGOKIDS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question