

Pzloz CLED-5501C

Pzloz LED Desk Lamp (Model CLED-5501C) Instruction Manual

Comprehensive guide for setup, operation, maintenance, and troubleshooting.

1. INTRODUCTION

Thank you for choosing the Pzloz LED Desk Lamp. This manual provides essential information for the safe and efficient use of your new desk lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.

2. PRODUCT OVERVIEW

The Pzloz LED Desk Lamp is designed to provide versatile and eye-friendly illumination for various tasks, including working, reading, and studying. It features a dual-head design, flexible adjustments, and convenient remote control.



Figure 2.1: Pzloz LED Desk Lamp (Model CLED-5501C)

3. WHAT'S IN THE BOX

Upon opening the package, ensure all components are present and undamaged:

- 1 x Pzloz LED Desk Lamp (Dual Head)
- 1 x Wireless Remote Control
- 1 x Power Adapter
- 1 x User Manual (this document)



Figure 3.1: Package Contents

4. SETUP INSTRUCTIONS

Follow these steps to set up your Pzloz LED Desk Lamp:

1. **Attach the Clamp:** Securely attach the adjustable metal clamp to the edge of your desk. The clamp is designed to fit desks up to 2 inches (5 cm) thick. Ensure it is tightened firmly to prevent wobbling.
2. **Insert the Lamp:** Insert the base of the lamp into the clamp.
3. **Connect Power:** Plug the power adapter into the lamp and then into a standard electrical outlet.
4. **Position the Lamp:** Adjust the flexible gooseneck and the 180° foldable swing arms to achieve your desired lighting angle and coverage. The light strips can also rotate 270° for precise direction.
5. **Remote Control Batteries:** Insert 2 AAA batteries (not included) into the wireless remote control.



Figure 4.1: One-step Installation



Figure 4.2: Clamp Compatibility




Figure 4.3: Light Strip Extension (180° Rotation)




Figure 4.4: Light Strip Rotation (270°)

5. OPERATING INSTRUCTIONS

Your Pzloz LED Desk Lamp is operated using the included wireless remote control. The remote offers various functions to customize your lighting experience.



Figure 5.1: Wireless Remote Control Functions

- **Power On/Off:** Press the central power button to turn the lamp on or off.
- **Brightness Adjustment:** Use the "Brightness" button to cycle through 5 dimmable brightness levels (20%-100%).
- **Color Temperature Adjustment:** Use the "Color Temperature" button to select from 5 color temperatures (3000K-5500K). This provides 25 light combinations.
- **Natural Light Mode:** Press the "Natural Light" button for a balanced, bright light setting.
- **Night Light Mode:** Press the "Night Light" button for a softer, lower intensity light suitable for nighttime use.
- **Timing Function:** Activate the timer function to automatically turn off the lamp after a set period (e.g., 60 minutes).
- **Memory Function:** The lamp retains your last brightness and color temperature settings when turned off and on again.



Figure 5.2: 25 Different Light Modes

6. KEY FEATURES

- **Versatile Lighting:** Offers 5 brightness levels and 5 color temperatures (3000K-5500K) for a total of 25 light combinations. Includes memory and timer functions.
- **Flexible Design:** Features a 360° standing and 180° foldable swing arms, allowing for optimal lighting coverage. The adjustable metal clamp secures to desks up to 2 inches thick.
- **Eye-Friendly Illumination:** Provides uniform illumination with no glare, no flicker, and no blue light hazards, reducing eye strain during prolonged use.
- **Durable and Energy-Efficient:** Constructed from high-quality aluminum alloy for good heat dissipation, ensuring a long service life and energy savings.



Figure 6.1: Eye Protection Features

7. MAINTENANCE

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place.
- **Bulb Replacement:** The LED light source is integrated and not user-replaceable.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Remote control batteries are dead or incorrectly inserted.	Check if the power adapter is securely plugged into the lamp and the outlet. Replace remote control batteries (2x AAA) and ensure correct polarity.
Remote control is unresponsive.	Remote control batteries are dead. Obstruction between remote and lamp.	Replace remote control batteries. Ensure a clear line of sight between the remote and the lamp's receiver.
Light flickers or is unstable.	Loose connection. Power supply issue.	Check all connections, including the power adapter. Try plugging into a different outlet.

If the remote control is not working, please contact customer support for a free replacement. No return is needed for remote control issues.

9. SPECIFICATIONS

Model Number	CLED-5501C
Brand	Pzloz
Power Source	Corded Electric
Wattage	24 Watts
Voltage	24 Volts (DC)
Light Source Type	LED
Number of Light Sources	2
Color Temperature	3000K-5500K (5 levels)
Brightness Levels	5 levels (20%-100%)
Control Method	Remote Control
Material	Metal (Aluminum Alloy)
Product Dimensions	31.5"D x 2.36"W x 29.59"H
Item Weight	2.89 Pounds
Mounting Type	Tabletop (Clamp)
Connectivity Technology	Bluetooth (for remote)

10. WARRANTY & SUPPORT

The Pzloz LED Desk Lamp (Model CLED-5501C) comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Pzloz customer service through the retailer where you purchased the product or visit the official Pzloz store online.

Note: If your remote control is not working, please contact customer support for a free replacement. No return of the entire product is needed for remote control issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question