

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GNMN](#) /
- › [GNMN V7 Bluetooth Headphones Wireless Earbuds User Manual](#)

GNMN V7

GNMN V7 Bluetooth Headphones Wireless Earbuds User Manual

Model: V7

1. INTRODUCTION

Thank you for choosing the GNMN V7 Bluetooth Headphones. These wireless earbuds are designed to provide a high-fidelity audio experience with comfort and durability, suitable for various activities including sports and daily use. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance.




Image 1.1: GNMN V7 Bluetooth Headphones and Charging Case.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Cable
- Eartips (S, M, L sizes)
- User Manual

3. PRODUCT OVERVIEW

3.1 Earbud Components

Each earbud features an ergonomic design with a secure earhook for stability during physical activity. The touch control area allows for easy management of music and calls.



Image 3.1: Earbud design highlighting secure earhooks and three eartip sizes (S, M, L) for a customized fit.

3.2 Charging Case

The charging case protects your earbuds and provides additional battery life. It features a digital LED display to show the remaining battery percentage of the case and the charging status of each earbud.



Image 3.2: The charging case displaying battery levels for the case and individual earbuds.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up.
2. Connect the USB-C cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The digital display on the charging case will show the battery percentage. When fully charged, the display will indicate 100%.

A single charge provides up to 8 hours of playback, and the charging case extends total playback time to approximately 48 hours.

Long Battery Life



48H 
Charging Case

USB-C
Charging

 **8H**
Single Charge

Image 4.1: Charging the GNMN V7 earbuds and case using the provided USB-C cable.

4.2 Pairing with Your Device

The earbuds feature one-step auto-pairing for convenience.

1. Ensure your device's Bluetooth is enabled.
2. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
3. On your device, search for Bluetooth devices and select "V7" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.

The earbuds will automatically reconnect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

One-step Auto Pairing

- ① Take out the headphones from charging case
- ② Search and connect "V7"



Image 4.2: Illustrates the one-step auto-pairing process with a smartphone showing "V7" in the Bluetooth device list.

4.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct eartip size and ensure a secure fit.

1. Select the eartips (S, M, L) that best fit your ear canals. A snug fit improves bass response and noise isolation.
2. Place the earbud into your ear, then gently rotate it to position the earhook over your ear for a stable and comfortable fit.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The GNMN V7 earbuds feature sensitive touch controls on each earbud. The specific functions are as follows:

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Volume Up	Press and Hold	N/A
Volume Down	N/A	Press and Hold
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold	Press and Hold
Activate Voice Assistant	Quadruple Tap	Quadruple Tap



Image 5.1: The touch-sensitive area on the earbud for controlling functions.

5.2 Sound Quality

The earbuds are equipped with 11mm speaker driver units and an in-ear structure to deliver hi-fi sound with strong bass, clear mids, and bright treble. The large chamber acoustic design helps balance air pressure for optimal audio performance.

Hi-Fi Stereo Sound

Big driver delivers stereo sound with dynamic treble and deep bass.



Image 5.2: Exploded view of the earbud's internal components, showcasing the 11mm dynamic driver and biological fiber composite diaphragm.

6. MAINTENANCE

6.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For eartips, remove them from the earbuds and clean with a mild soap solution, then rinse thoroughly and dry completely before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical sprays.

6.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

6.3 Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This protects them from sweat and rain. **Note: The charging case is not waterproof.** Avoid exposing the charging case to liquids.

7. TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget "V7" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, then open and take them out again. Ensure both are charged.
No sound	Check device volume and earbud volume. Ensure earbuds are connected to the correct device.
Charging case not charging	Ensure the USB-C cable is properly connected to both the case and the power source. Try a different cable or power adapter.
Touch controls unresponsive	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out.

8. SPECIFICATIONS

Feature	Detail
Model Name	V7
Connectivity Technology	Bluetooth
Wireless Communication Technology	True Wireless
Bluetooth Version	5.3
Audio Driver Type	Dynamic Driver (11mm)
Battery Life (Earbuds)	Up to 8 hours (single charge)
Total Playback Time (with Case)	Up to 48 hours
Charging Port	USB-C
Water Resistance Level	IPX7 (Earbuds only)
Control Type	Touch Control

Feature	Detail
Ear Placement	Over Ear (with earhooks)
Compatible Devices	Smartphones, TV, Computers, Laptops, Smart Watches
Product Dimensions	1.38 x 1.42 x 2.32 inches
Item Weight	5.1 ounces

9. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures, humidity, and corrosive materials.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Dispose of the product and batteries responsibly according to local regulations.

10. WARRANTY AND SUPPORT

GNMN products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or the official GNMN website. Please retain your proof of purchase for warranty claims.