

[Manuals.plus](#) /

› [PHILIPS](#) /

› PHILIPS TAT3508BK True Wireless Headphones User Manual

PHILIPS TAT3508BK

PHILIPS TAT3508BK True Wireless Headphones User Manual

Model: TAT3508BK

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your PHILIPS TAT3508BK True Wireless Bluetooth Noise Cancelling In-Ear Headphones. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The PHILIPS TAT3508BK True Wireless In-Ear Headphones, with one earbud removed and the charging case open, displaying the second earbud inside.

PACKAGE CONTENTS

Verify that all items are present in the package:

- PHILIPS TAT3508BK True Wireless In-Ear Headphones
- Charging Case
- USB-A to USB-C Charging Cable
- Multiple sizes of Silicone Ear-tips
- User Manual (this document)

Zawartość opakowania



Słuchawki douszne i etui do ładowania

Wkładki douszne



Przewód USB-A — USB-C



Image: Contents of the PHILIPS TAT3508BK package, showing the two earbuds, the charging case, various ear tip sizes, and the USB-A to USB-C charging cable.

SETUP

Initial Charge

Before first use, fully charge the headphones and charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C end of the charging cable to the charging port on the case and the USB-A end to a power source (e.g., computer USB port, wall adapter).
3. The indicator lights on the case will show charging status. A full charge takes approximately 2 hours.

Pairing with a Bluetooth Device

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet), enable Bluetooth and search for new devices.
3. Select "PHILIPS TAT3508BK" from the list of available devices.
4. Once connected, a confirmation sound will play.



Bluetooth nowej generacji

Image: PHILIPS TAT3508BK earbuds in their open charging case, with a smartphone displaying a Bluetooth connection icon, illustrating the pairing process.

Fitting the Earbuds

Select the ear-tip size that provides a comfortable and secure fit for optimal sound quality and noise cancellation.

- Gently insert the earbud into your ear canal.
- Twist slightly to ensure a snug and stable fit.



Image: A person wearing the PHILIPS TAT3508BK earbuds, demonstrating a comfortable and secure fit for extended use.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or remove the earbuds from the case. They will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Touch Controls

The earbuds feature touch-sensitive controls on their stalks.

Action	Left Earbud	Right Earbud
Play/Pause	Single tap	Single tap
Next Track	Double tap	Double tap

Action	Left Earbud	Right Earbud
Previous Track	Triple tap	Triple tap
Answer/End Call	Single tap	Single tap
Reject Call	Press and hold (2s)	Press and hold (2s)
Activate Voice Assistant	Press and hold (2s)	Press and hold (2s)
ANC/Awareness Mode Toggle	Press and hold (2s)	Press and hold (2s)



Image: PHILIPS TAT3508BK earbuds shown in use with a smartphone displaying an active call screen, highlighting their functionality for clear conversations.

Active Noise Cancellation (ANC) and Awareness Mode

Your headphones feature Active Noise Cancellation to reduce ambient noise and Awareness Mode to allow you to hear your surroundings.

- Toggle between ANC On, Awareness Mode, and ANC Off by pressing and holding the touch control on either earbud for 2 seconds.

- The Philips Headphones App allows for customization of these modes.



Image: A PHILIPS TAT3508BK earbud illustrating Active Noise Cancellation, with sound waves being blocked and reduced to enhance listening experience.

Mono Mode

You can use either earbud independently while the other is in the charging case.

Multipoint Connectivity

The headphones can connect to two Bluetooth devices simultaneously, allowing seamless switching between them.

Philips Headphones App

Download the Philips Headphones App for additional features, including:

- Customizing Noise Cancelling levels.
- Adjusting Awareness Mode transparency.
- Fine-tuning sound with an equalizer.

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners or solvents.
- Regularly clean the ear-tips and charging contacts to ensure proper function.

Storage

Store the headphones in their charging case when not in use to protect them and keep them charged.



Image: The PHILIPS TAT3508BK earbuds and charging case placed outdoors, demonstrating their portability and the convenience of the pocket-sized charging case.

Water Resistance

The headphones are IPX4 water resistant, meaning they are protected against splashing water from any direction. They are not designed for submersion.

TROUBLESHOOTING

Problem	Solution
Earbuds do not power on.	Ensure earbuds are charged. Place them in the charging case and charge the case.
Cannot pair with device.	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on your device. • Make sure the earbuds are in pairing mode (open case lid). • Forget the device from your phone's Bluetooth list and try pairing again. • Move closer to the device.
No sound or poor sound quality.	<ul style="list-style-type: none"> • Check volume levels on both earbuds and connected device. • Ensure earbuds are properly seated in your ears. • Try different ear-tip sizes. • Clean earbud grilles and charging contacts. • Reconnect the earbuds to your device.
Active Noise Cancellation not effective.	<ul style="list-style-type: none"> • Ensure earbuds are properly sealed in your ear canals. • Check ANC settings in the Philips Headphones App. • Ensure ANC is enabled via touch controls.
Earbuds not charging in case.	<ul style="list-style-type: none"> • Ensure earbuds are correctly placed in the case. • Clean the charging contacts on both earbuds and case. • Check if the charging case itself has power.

SPECIFICATIONS

- **Model:** TAT3508BK
- **Connectivity:** Bluetooth Wireless
- **Drivers:** 10mm
- **Frequency Response:** 20Hz - 20,000Hz
- **Impedance:** 32 Ohm
- **Sensitivity:** 95 dB
- **Noise Control:** Active Noise Cancellation (ANC), Awareness Mode
- **Battery Life (Earbuds):** Up to 7 hours (ANC off)
- **Battery Life (with Charging Case):** Up to 21 hours total
- **Charging Time:** Approximately 2 hours (full charge)
- **Quick Charge:** 15 minutes charge for 1 hour play time
- **Water Resistance:** IPX4
- **Control Type:** Touch Control
- **Weight:** 66 g (total, including case)

- **Dimensions (Case):** 2.81 x 6.28 x 3.54 cm

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included in your product packaging or visit the official Philips support website.

[Philips Support Website](#)