



[Manuals.plus](#) /

> [COSTWAY](#) /

> COSTWAY 4-in-1 Children's Climbing Set User Manual

COSTWAY TS10071NAIT

COSTWAY 4-in-1 Children's Climbing Set User Manual

Model: TS10071NAIT

INTRODUCTION

Thank you for choosing the COSTWAY 4-in-1 Children's Climbing Set. This versatile play structure is designed to provide a safe and engaging environment for children aged 1 year and above, promoting balance, coordination, and physical development. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience.

SAFETY INFORMATION

- Always supervise children during play.
- Ensure all components are securely assembled before use. Regularly check for loose screws or parts.
- Place the climbing set on a flat, stable, and soft surface (e.g., carpet, play mat) to minimize injury risk from falls.
- Do not exceed the maximum weight capacity of 50 kg (110 lbs) per component.
- Keep small parts away from young children during assembly to prevent choking hazards.
- This product is for indoor use only.
- Do not modify the product in any way. Use only original replacement parts if needed.

PARTS LIST

Before assembly, please verify that all parts listed below are present and undamaged.

Part	Description	Quantity
------	-------------	----------

Part	Description	Quantity
Climbing Triangle	Foldable A-frame structure with rungs.	1
Climbing Arch	Curved structure with rungs, can be used as a rocker.	1
Ramp/Slide	Double-sided board with climbing holds on one side and a smooth slide on the other.	1
Connectors	Hardware for connecting the ramp to the triangle or arch.	Set
Assembly Hardware	Screws, nuts, and Allen key.	Set

SETUP AND ASSEMBLY

Assembly requires adult supervision. Please follow these steps carefully.

Step 1: Assemble the Climbing Triangle

1. Unfold the two ladder sections of the climbing triangle.
2. Align the top hinges and secure them with the provided hardware.
3. Ensure the triangle is stable and stands firmly on its base.

Step 2: Assemble the Climbing Arch

1. Connect the two curved side panels using the rungs and secure with screws.
2. Verify that the arch is sturdy and balanced.

Step 3: Attach the Ramp/Slide

1. The ramp can be attached to either the climbing triangle or the climbing arch.
2. Align the hooks on the ramp with the rungs of the triangle or arch at the desired height.
3. Secure the ramp using the provided connectors to prevent accidental detachment.
4. To adjust the height, simply re-position the ramp to a different rung.

Combinazioni Libere per un Maggiore Divertimento



Image: Different Combination Modes. This image illustrates how the climbing triangle, arch, and ramp can be combined in various ways to create different play structures.

Altezza regolabile



Image: Adjustable Height. This image demonstrates how the ramp can be attached at different heights on the climbing triangle to vary the challenge for children.

OPERATING INSTRUCTIONS

The COSTWAY 4-in-1 Climbing Set offers multiple play configurations to stimulate children's physical and cognitive development.

Climbing Triangle with Ramp:

Attach the ramp to the climbing triangle. Children can climb up the rungs or the climbing holds on the ramp, and slide down the smooth side. Adjust the ramp's height to suit the child's age and skill level.

Climbing Arch with Ramp:

Connect the ramp to the climbing arch. This configuration allows for crawling through the arch and climbing/sliding on the ramp.

Rocking Arch:

The climbing arch can be used independently as a rocking structure. Place it on a flat surface and ensure children are seated securely while rocking.

Crawling Tunnel:

The climbing arch can also be used as a crawling tunnel when placed on its side, encouraging motor skills and imaginative play.



Image: Children engaging with the climbing set. This image shows children actively using the climbing triangle, arch, and ramp in a combined setup, demonstrating various play possibilities.

Divertimento Senza Fine con Modi Diversi

Dondolo ad Arco Multifunzionale



Cavallo a Dondolo



Arco di Arrampicata



Tunnel Strisciante

Image: Endless Fun with Different Modes. This image illustrates the versatility of the climbing arch, showing its use as a rocking horse, a climbing arch, and a crawling tunnel.

MAINTENANCE

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals. Dry immediately after cleaning.
- **Inspection:** Regularly inspect all screws, bolts, and connections to ensure they are tight. Tighten any loose hardware to maintain stability and safety.
- **Storage:** When not in use, especially for extended periods, store the climbing set in a dry, cool place away from direct sunlight and extreme temperature changes to prevent wood warping or damage. The climbing triangle is foldable for convenient storage.
- **Wood Care:** As the product is made of natural beech wood, minor variations in grain and color are normal. Avoid prolonged exposure to moisture.



Image: Foldable Design and Easy Storage. This image shows the climbing triangle folded and stored upright, demonstrating its space-saving design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Set feels wobbly after assembly.	Loose screws or improper alignment.	Check all connections and tighten screws using the provided Allen key. Ensure parts are aligned correctly according to the assembly instructions.
Ramp detaches easily.	Ramp not securely hooked or connectors not properly fastened.	Ensure the ramp's hooks are fully engaged with the rungs and the connectors are tightly secured.
Squeaking noises during use.	Friction between wooden parts or loose joints.	Tighten all screws. If squeaking persists, a small amount of wood-safe lubricant can be applied to contact points, but ensure it is non-toxic and safe for children.

SPECIFICATIONS

- **Brand:** COSTWAY
- **Model:** TS10071NAIT
- **Color:** Natural
- **Material:** Natural Beech Wood, Plywood
- **Climbing Triangle Dimensions:** 75 x 55 x 64 cm (L x W x H)
- **Climbing Arch Dimensions:** 89 x 52 x 44 cm (L x W x H)
- **Ramp Dimensions:** 98 x 40 cm (L x W)
- **Weight Capacity (per part):** 50 kg (110 lbs)
- **Net Weight:** Approximately 12 kg (26.5 lbs)
- **Assembly Required:** Yes
- **Recommended Age:** 1 year +

3 in 1 Set di Arrampicata



Triangolo da Arrampicata
Piegevole



Arco di Arrampicata



Rampa per Arrampicata
su Roccia




Image: Product Dimensions. This image provides detailed measurements for the climbing triangle, arch, and ramp components.

WARRANTY AND SUPPORT

COSTWAY is committed to providing high-quality products. For any questions, concerns, or assistance with your product, please contact COSTWAY customer support. Please refer to your purchase documentation for specific warranty details and contact information.

You can also visit the official COSTWAY store for more information and support: [COSTWAY Store on Amazon](#)

© 2025 COSTWAY. All rights reserved.