

Yaheetech MM-001231071

Yaheetech Armless Mid-Back Office Chair - User Manual

Model: MM-001231071 | Brand: Yaheetech

1. INTRODUCTION

Thank you for choosing the Yaheetech Armless Mid-Back Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before assembly and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Follow assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- Do not stand on the chair.
- Do not exceed the maximum weight capacity of 136 kg (300 lbs).
- Keep children away from the chair during assembly. Small parts may pose a choking hazard.
- Use the chair on a level surface to prevent tipping.
- Regularly check all bolts and screws to ensure they are tight. Retighten as necessary.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- 1 x Office Chair (unassembled)
- 1 x Instruction Manual
- 1 x Accessory Kit (containing all necessary screws, bolts, and tools)

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 15-30 minutes with two people. Follow these steps carefully:

1. **Prepare the Base:** Unpack all components. Place the five-star base on a flat, stable surface. Insert the five casters into the holes at the end of each leg of the base until they click into place.
2. **Install the Gas Lift:** Insert the gas lift cylinder into the center hole of the five-star base.
3. **Remove Protective Cap: IMPORTANT:** Before attaching the seat, remove the black plastic protective cap from the top of the gas lift cylinder. Failure to do so will prevent height adjustment.



Figure 4.1: Removing the black plastic cap from the gas lift.

4. **Attach the Mechanism Plate:** Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the lever is on the right side when facing the front of the seat. Secure with the provided screws and tighten using the Allen key.
5. **Connect Seat to Base:** Carefully place the assembled seat onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.

5. OPERATING INSTRUCTIONS

Your Yaheetech office chair offers several adjustable features for personalized comfort:

5.1. Seat Height Adjustment

To adjust the seat height, lift the lever located on the right side of the seat. While seated, lift the lever to lower the seat. To raise the seat, lift the lever while standing or with minimal weight on the seat. Release the lever to lock the height in place. The seat height can be adjusted from approximately 47.5 cm to 57.5 cm.

Multi-functional Office Desk Chair



Rocking Function



Smooth 360° Mobility

Figure 5.1: Adjustable seat height and rocking function.

5.2. Tilt Function and Tension

The chair features a rocking function for relaxation. To activate the rocking motion, pull out the lever on the right side of the seat. Push the lever in to lock the chair in an upright position.

The tilt tension can be adjusted by turning the round knob located underneath the seat. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

Center-Tilt Tension

The rocking feature adds more fun to traditional office chair and take your sitting experience to the next level.



Adjust the tilt tension by turning the controlling knob beneath the seat.



Pull out the lever to activate the rocking motion and push to lock.

Figure 5.2: Adjusting tilt tension and activating rocking motion.

5.3. Swivel and Mobility

The chair is designed with a 360° swivel function and smooth-rolling casters, allowing for easy movement and access to your workspace without strain.



Figure 5.3: Armless design for space-saving and easy mobility.

6. MAINTENANCE

Proper care will extend the life and appearance of your chair:

- **Cleaning:** The faux leather surface is water-resistant and easy to clean. Wipe spills immediately with a damp cloth. For general cleaning, use a soft, damp cloth with mild soap and water. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts for tightness. Retighten as needed to maintain stability and safety.
- **Casters:** Keep casters free of hair and debris to ensure smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack.

7. TROUBLESHOOTING

- **Chair not adjusting height:** Ensure the black plastic protective cap has been removed from the gas lift

cylinder. Check if the height adjustment lever is fully engaged.

- **Chair feels wobbly:** Check all assembly screws and bolts. Tighten any loose connections. Ensure the chair is on a flat, even surface.
- **Casters not rolling smoothly:** Inspect casters for trapped debris (hair, lint, etc.) and clean them.
- **Chair squeaks:** Apply a small amount of silicone lubricant to moving parts or connections if persistent squeaking occurs.

8. SPECIFICATIONS

Feature	Detail
Model Number	MM-001231071
Color	White
Main Material	Faux Leather, Iron, Foam, Plywood, Polypropylene Plastic
Overall Dimensions (W x D x H)	55 cm x 57.5 cm x (83-93) cm
Seat Dimensions (W x D)	47.5 cm x 44.5 cm
Adjustable Seat Height Range	47.5 cm - 57.5 cm
Maximum Weight Capacity	136 kg (300 lbs)
Product Weight	7.5 kg
Assembly Required	Yes
Special Features	Adjustable Height, Upholstered, Swivel, Armless Design, Tilt Function
Care Instructions	Wipe clean with a damp cloth

Note: Dimensions may vary slightly (up to 1.5 cm) due to manufacturing tolerances.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Yaheetech customer service directly. Keep your purchase receipt as proof of purchase.