

Dyson Airstrait™ Straightener User Manual

Model: 2683332

[Introduction](#) [Safety](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION TO YOUR DYSON AIRSTRAIT™ STRAIGHTENER

The Dyson Airstrait™ straightener is engineered to dry and straighten hair simultaneously from wet to dry, creating a natural straight finish for multiple hair types. It utilizes precise airflow for styling, eliminating the need for hot plates and preventing heat damage.

This innovative device simplifies your routine by allowing you to achieve a finished look from wet hair with a single machine. Its precise airflow and temperature control help maintain hair strength and protect shine, promoting less breakage and preserving natural hair health.



This image displays the Dyson Airstrait™ straightener from two angles: an open view showing the styling arms and digital display, and a closed side view highlighting its compact form.

Key Benefits

- **No Heat Damage:** Preserves hair strength, promotes less breakage, and protects natural shine to leave hair feeling healthy.
- **Easy Natural Styling:** Creates a naturally straight style with reduced frizz and flyaways, for a smooth and shiny finish, leaving hair feeling softer while keeping natural volume.
- **Convenience Without Compromise:** Combines two steps in one – drying and styling – saving you time without compromising your style or hair health.



No heat damage

Preserves hair strength, promotes less breakage, and protects natural shine to leave hair feeling healthy.



Easy natural styling

Creates a naturally straight style with reduced frizz and flyways, for a smooth and shiny finish, to leave hair feeling softer while keeping natural volume.



Convenience without compromise

Combines two steps in one - drying and styling - saving you time without compromising your style or hair health

An infographic outlining the primary advantages of the Dyson Airstrait™: preserving hair strength and shine by avoiding heat damage, enabling easy natural styling for a smooth finish, and offering convenience by combining drying and styling.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Dyson Airstrait™ straightener. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Water and Moisture:** Do not use this appliance near bathtubs, showers, basins, or other vessels containing water. Always ensure your hands are dry before plugging in or unplugging the appliance.
- **Power Supply:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Always unplug the appliance immediately after use and before cleaning.
- **Children and Supervision:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Heat:** The appliance may become hot during use. Use caution when handling. Do not place the appliance on heat-sensitive surfaces.

- **Damage:** Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner. Contact Dyson customer support for examination and repair.
- **Modifications:** Do not attempt to repair or disassemble the appliance yourself. Unauthorized repairs may void the warranty and pose safety risks.

3. GETTING STARTED: SETUP

Unboxing and Components

Carefully remove all components from the packaging. Ensure all parts are present before beginning use.

In the box



Dyson Airstrait™ straightener



Non-slip heat mat

This image shows the items included in the Dyson Airstrait™ packaging: the Airstrait™ straightener itself and a dark grey non-slip heat mat for safe placement during and after use.

Initial Setup

1. **Place on Heat Mat:** Always place the Dyson Airstrait™ on the provided non-slip heat mat or a heat-resistant surface during and after use.
2. **Plug In:** Insert the power plug into a suitable electrical outlet. The appliance will enter standby mode.
3. **Unlock Arms:** If the arms are locked, slide the lock button to release them.

4. OPERATING YOUR DYSON AIRSTRAIT™

Modes and Settings

The Dyson Airstrait™ features different modes and settings to optimize your styling experience:

- **Wet Mode:** Designed for straightening hair from damp to dry. Offers specific temperature settings for wet styling.
- **Dry Mode:** Ideal for touching up or refreshing your style on dry hair. Offers different temperature settings.
- **Airflow Settings:** Adjust the fan speed for desired airflow intensity.
- **Temperature Settings:** Select the appropriate temperature for your hair type and desired style.
- **Boost Mode:** Available in Dry mode for an extra burst of heat if required for stubborn sections.

Straightening from Wet Hair

Follow these steps for best results when straightening from wet hair:


1. **Towel Dry Hair:** Start with clean, towel-dried hair. Remove excess water until hair is damp, not dripping wet.
2. **Pre-dry Roots (Optional):** Select Wet mode, maximum airflow, and high temperature. Lock the arms and rough dry your roots until they are mostly dry.
3. **Section and Style:** Unlock the arms. Select your desired airflow and temperature for wet styling. Take small sections of damp hair and pass the straightener through them slowly and evenly from roots to ends.
4. **Cold Shot to Finish:** Once your hair is dry and straight, use the cold shot function to set your style and add shine.




1. Towel dry hair



2. Pre-dry roots



3. Section and style



4. Cold shot to finish

A visual guide illustrating the four main steps for using the Dyson Airstrait™: towel drying hair, pre-drying roots, sectioning and styling damp hair, and finishing with a cold shot for setting the style.

Straightening from Dry Hair (Touch-up)

To refresh or touch up your style on dry hair:

- 1. Select Dry Mode:** Turn on the appliance and select Dry mode.
- 2. Adjust Settings:** Choose your desired airflow and temperature. Use Boost mode if extra heat is needed for specific sections.
- 3. Style Sections:** Take small, dry sections of hair and pass the straightener through them to smooth or refine your style.

Styling Examples



Naturally straight blow out

A polished, everyday look, straightened from wet

A side-by-side comparison of a woman with wet hair on the left and the same woman with a polished, naturally straight blow out on the right, demonstrating the results achievable from wet hair.



'90s straight blow out

Pin and roll for a lift and volume with a
'90s-inspired look

A side-by-side comparison of a woman with curly hair on the left and the same woman with a voluminous, '90s-inspired straight blow out on the right, styled with the Dyson Airstrait™.



Textured blow out

Smooth and stretch hair to create a naturally straight blow out

A side-by-side comparison of a woman with textured hair on the left and the same woman with a smooth, naturally straight textured blow out on the right, created using the Dyson Airstrait™.

5. CARE AND MAINTENANCE

Regular cleaning and proper care will ensure the longevity and optimal performance of your Dyson Airstrait™ straightener.

Cleaning the Filter

The filter at the base of the handle should be cleaned regularly to prevent blockages and maintain airflow efficiency.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Remove Filter Cage:** Gently twist and pull down the filter cage located at the bottom of the handle.
3. **Clean Filter:** Use a soft, dry cloth or a small brush to remove any dust, lint, or hair from the filter mesh. Do not use water.
4. **Reattach Filter Cage:** Align the filter cage and twist it back into place until it clicks securely.

Cleaning the Styling Arms

The styling arms can accumulate product residue over time.

- **Ensure Cool:** Make sure the appliance is unplugged and completely cool before cleaning the arms.
- **Wipe Clean:** Use a soft, damp cloth to gently wipe down the surfaces of the styling arms. Do not use abrasive cleaners or harsh chemicals.

Storage

Store your Dyson Airstrait™ in a safe, dry place, away from direct sunlight and moisture. Use the provided heat mat for temporary storage during and after use.

6. TROUBLESHOOTING COMMON ISSUES

If you encounter any issues with your Dyson Airstrait™ straightener, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply.	Check if the power cord is securely plugged into a working electrical outlet. Test the outlet with another device.
No airflow or weak airflow.	Blocked air inlet filter.	Unplug the appliance and clean the filter as described in the 'Care and Maintenance' section.
Hair is not straightening effectively.	Hair too wet, sections too large, or incorrect settings.	Ensure hair is towel-dried (damp, not dripping). Take smaller sections. Adjust temperature and airflow settings according to your hair type and desired style. Pass the straightener through hair more slowly.
Appliance is making unusual noises.	Internal obstruction or malfunction.	Unplug the appliance immediately. Do not attempt to use it. Contact Dyson customer support for assistance.


If the problem persists after attempting these solutions, please contact Dyson customer support for further assistance.

7. TECHNICAL SPECIFICATIONS

Detailed specifications for the Dyson Airstrait™ Straightener:

Feature	Specification
Product Dimensions	13 x 1.6 x 2.4 inches
Item Model Number	2683332
Weight	2.2 Pounds
Department	Unisex, All Ages
Batteries Required	1 Nonstandard Battery (included)
UPC	885609027234


Feature	Specification
Manufacturer	Dyson
ASIN	B0C6BJ95SC
GTIN	885609027234



An illustration showing the internal motor of the Dyson Airstrait™, depicting how it generates and propels a strong, controlled stream of air for efficient drying and straightening.



A cutaway view of the Dyson Airstrait™ styling arms, illustrating the internal channels that precisely direct airflow onto the hair for even and effective styling.



A detailed view of hair passing through the Dyson Airstrait™ arms, with visible airflow straightening the strands. This image emphasizes the air-centric styling method, free from direct contact with hot plates.

8. WARRANTY AND CUSTOMER SUPPORT

Your Dyson Airstrait™ Straightener comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

Contacting Dyson Support

For technical assistance, troubleshooting beyond this manual, warranty claims, or to purchase genuine Dyson accessories, please contact Dyson customer support:

- **Website:** Visit the official Dyson website for support resources, FAQs, and contact information.
- **Phone:** Refer to your product documentation for the customer service phone number in your region.
- **Online Chat:** Many regions offer online chat support through the Dyson website.

Please have your product model number (2683332) and serial number ready when contacting support.