

[manuals.plus](#) /› [Gyration](#) /› [Gyration Cyberview 3000 3MP Wi-Fi Network Camera User Manual](#)

Gyration Cyberview 3000

Gyration Cyberview 3000 3MP Wi-Fi Network Camera User Manual

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Gyration Cyberview 3000 3MP Wi-Fi Network Camera. Please read this manual thoroughly before using the product to ensure proper functionality and safety. The Cyberview 3000 is designed for both indoor and outdoor surveillance, offering high-resolution video, advanced detection features, and seamless smart home integration.

2. PRODUCT OVERVIEW

2.1 Package Contents

- Gyration Cyberview 3000 3MP Smart Wi-Fi Wireless Doorbell Camera
- Wireless Chime Unit
- Mounting Hardware (screws, anchors)
- USB Charging Cable (if applicable)
- User Manual (this document)

2.2 Key Features

- High-quality 3MP image with 1/2.8" CMOS sensor (2048 x 1536@15fps; 16:9 aspect ratio)
- 3X Digital Zoom for detailed viewing
- PIR motion sensor for instant and accurate alerts
- Advanced AI detection: humanoid, vehicle, pet capture, and package detection (requires value-added services)
- Wi-Fi connectivity for easy installation
- Built-in microphone and speaker for two-way audio communication
- Multiple storage options: Cloud storage, local Micro SD card (up to 128 GB), and mobile phone memory
- IP65 weather resistance rating

- Includes a wireless chime for audible alerts
- Compatibility with Google Home & Amazon Alexa
- Remote real-time monitoring via Android/iOS mobile devices

2.3 Product Components



Figure 2.3.1: The Gyration Cyberview 3000 system, including the doorbell camera, wireless chime, and a smartphone displaying the live feed.

3M
PIXEL



3 Megapixel CMOS Sensor with Maximum resolution

Figure 2.3.2: Front view of the Cyberview 3000 camera, emphasizing its 3 Megapixel CMOS sensor for high-resolution video.



REMOTE MONITORING & NOTIFICATIONS

Figure 2.3.3: The wireless chime unit, which provides audible alerts when the doorbell is pressed or motion is detected.



Figure 2.3.4: The Cyberview 3000 doorbell camera mounted on a wall, showcasing its compact design and 3MP high-resolution capability.

3. SETUP

3.1 Charging the Device

Before initial use, ensure the doorbell camera is fully charged. Connect the camera to a 5V power source using the provided USB charging cable. The charging indicator will show the charging status.

3.2 App Installation and Account Creation

1. Download the official Gyration app from your mobile device's app store (available for Android and iOS).
2. Open the app and create a new user account. Follow the on-screen prompts to complete registration.

3.3 Device Pairing

1. Ensure your mobile device is connected to a 2.4GHz Wi-Fi network.
2. In the app, select "Add Device" or the '+' icon.
3. Follow the in-app instructions to put the camera into pairing mode (usually by pressing and holding a button on the camera).
4. Scan the QR code displayed on your phone with the camera, or follow alternative pairing methods provided by the app.
5. Once the camera is connected, follow the prompts to name your device and complete the setup.

3.4 Chime Pairing

1. Plug the wireless chime into a power outlet within range of the doorbell camera.

2. Press the SYNC button on the chime unit.
3. Press the doorbell button on the camera. The chime should ring, indicating successful pairing.
4. Adjust chime volume and melody using the buttons on the chime unit.

3.5 Physical Installation

1. Choose a suitable location for the camera, ensuring good Wi-Fi signal strength and a clear view of the area you wish to monitor.
2. Use the provided mounting hardware to securely attach the camera to a wall or doorframe.
3. Ensure the camera is positioned at an optimal height for detection and clear viewing.

4. OPERATING INSTRUCTIONS

4.1 Live View and Remote Monitoring

Open the Gyration app on your smartphone to access the live video feed from your Cyberview 3000 camera. You can monitor your property in real-time from anywhere with an internet connection.




Figure 4.1.1: Remote monitoring and notifications allow users to receive alerts and view events on their mobile device.

4.2 Two-Way Audio

While in live view, tap the microphone icon in the app to speak through the camera's speaker. Tap the speaker icon to listen to audio from the camera's microphone. This enables communication with visitors or deterrence of unwanted activity.

4.3 Motion and Activity Detection

The Cyberview 3000 utilizes a PIR motion sensor and advanced AI for detection. When motion, a person, vehicle, pet, or package is detected, you will receive an instant alert on your mobile device. You can customize detection zones and sensitivity settings within the app.



Figure 4.3.1: The camera's ability to detect people and packages, indicated by red detection lines, triggering alerts.

4.4 Night Vision

The camera features full-color infrared night vision, providing clear video footage even in low-light or no-light conditions.



Figure 4.4.1: A visual comparison demonstrating the effectiveness of the camera's full-color infrared night vision.

4.5 Video Storage

Recorded video footage can be stored in several ways:

- **Cloud Storage:** Subscribe to cloud services through the app for secure, remote storage of your recordings.
- **Micro SD Card:** Insert a Micro SD card (up to 128 GB, not included) into the camera's designated slot for local storage.
- **Mobile Phone Memory:** Manually record or download clips directly to your smartphone.

4.6 Smart Home Integration

The Cyberview 3000 is compatible with Google Home and Amazon Alexa. Follow the instructions in your smart home app to link your Gyration account and enable voice control or integrate with other smart devices.

5. MAINTENANCE

5.1 Cleaning

To maintain optimal performance, periodically clean the camera lens and housing with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

5.2 Firmware Updates

Ensure your camera's firmware is always up to date. The app will typically notify you of available updates. Follow the in-app instructions to perform firmware upgrades, which can improve performance and add new features.

5.3 Battery Management

The camera is battery-powered. Monitor the battery level through the app and recharge the device as needed to ensure continuous operation.

6. TROUBLESHOOTING

- **Camera Not Connecting to Wi-Fi:**

- Ensure your Wi-Fi network is 2.4GHz.
- Check Wi-Fi signal strength at the camera's location.
- Restart your router and the camera.
- Verify correct Wi-Fi password entry in the app.

- **No Motion Detection Alerts:**

- Check app notification settings and ensure they are enabled.
- Adjust motion detection sensitivity in the app.
- Ensure the camera's view is not obstructed.

- **Two-Way Audio Not Working:**

- Check microphone and speaker permissions for the app on your phone.
- Ensure volume levels are adjusted correctly in the app and on your phone.

- **Chime Not Ringing:**

- Ensure the chime is plugged in and powered on.
- Re-pair the chime with the doorbell camera as per Section 3.4.
- Check if the chime is within effective range of the doorbell camera.

- **Poor Video Quality:**

- Check your Wi-Fi connection speed.
- Clean the camera lens.
- Ensure adequate lighting for optimal image quality.

7. SPECIFICATIONS

Feature	Specification
Model Name	Cyberview 3000

Image Sensor	3MP, 1/2.8" CMOS
Video Resolution	2048 x 1536 @ 15fps
Digital Zoom	3X
Connectivity	Wi-Fi (2.4GHz)
Audio	Two-Way Audio (Built-in Mic & Speaker)
Storage Options	Cloud Storage, Micro SD Card (up to 128 GB), Mobile Phone Memory
Detection	PIR Motion Sensor, Humanoid, Vehicle, Pet, Package Detection
Night Vision	Full Color Infrared Night Vision
Weather Resistance	IP65 Rating
Power Source	Battery Powered (5V)
Compatible Devices	Smartphone (Android/iOS), Google Home, Amazon Alexa
Dimensions (L x W x H)	6.4 x 3.8 x 2.7 inches
Item Weight	16 ounces (1 pound)
Included Components	3MP Smart WiFi Wireless Doorbell Camera, Wireless Chime

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Gyration website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.




Manufacturer: Gyration

Part Number: CYBERVIEW 3000

UPC: 744390953484

Related Documents - Cyberview 3000

 <p>Gyration Cyberview3020 Smart PTZ Battery Camera Solar Recharging Kit User Manual</p> <p>User manual for the Gyration Cyberview3020 Smart PTZ Battery Camera with Solar Recharging Kit. Learn about setup, installation, features, and troubleshooting for this wireless security camera.</p>	
--	--

 <p>Cyberview3000 Smart Video Doorbell kit User manual</p>	<p>Gyration Cyberview3000 Smart Video Doorbell User Manual</p> <p>Comprehensive user manual for the Gyration Cyberview3000 Smart Video Doorbell kit, detailing installation, setup, features, and troubleshooting.</p>
 <p>Cyberview2000 Smart PTZ Camera User manual</p>	<p>Gyration Cyberview2000 Smart PTZ Camera User Manual - Setup, Installation, Specifications</p> <p>Comprehensive user manual for the Gyration Cyberview2000 Smart PTZ Camera. Covers setup, Wi-Fi binding, installation, sharing features, product specifications, and regulatory compliance. Includes app download information.</p>
 <p>AIR MOUSE VOICE Quick Start Guide Gyration</p>	<p>Gyration Air Mouse Voice Quick Start Guide</p> <p>A comprehensive quick start guide for the Gyration Air Mouse Voice, detailing setup, features like In-Air and Voice modes, MotionTools software customization, and warranty information.</p>
 <p>Cyberview3020 Smart PTZ Battery Camera Solar Recharging Kit User manual</p>	<p>Gyration Cyberview3020 Smart PTZ Battery Camera Solar Recharging Kit User Manual</p> <p>User manual for the Gyration Cyberview3020 Smart PTZ Battery Camera with Solar Recharging Kit. Learn about setup, installation, features, and troubleshooting for this wireless security camera.</p>
 <p>Cyberview3000 Smart Video Doorbell kit User manual</p>	<p>Gyration Cyberview3000 Smart Video Doorbell User Manual</p> <p>Comprehensive user manual for the Gyration Cyberview3000 Smart Video Doorbell kit, detailing installation, setup, features, and troubleshooting.</p>



[pdf] Datasheet

Datasheet GY CyberView 3000 11 17 22 gyration datasheets |||

CYBERVIEW 3000 3 MP Smart Wi Wireless Doorbell DATASHEET Resolution

Perimeter Detection VCA Edge Storage IP65 Waterproof Supports Wi- Cloud Solution

KEY FEATURES The Gyration **Cyberview 3000** is a 3 mp Smart AI Wi-Fi battery doorbell camera, suitable for outdoor use. Support 24 hrs. motion detection. Support PIR motion sensor. Instant & accurate alerts. 2.4GHz WiFi connection, support Micro SD card storage. Support Android/iOS system mobile devices, remote monitoring. The Cyberview 3000 initiates a video call via the CyberView Plus app when someone rings your doorbell, so you'll never miss a visitor. See and talk to your visitors from your smartphone anywhere, any time. The built-in microphone and speaker make it easy for you to hear what's happening outside the door. With CyberView Plus app, you can protect, capture, save and share what's valuable to you.

lang:en score:39 filesize: 2.39 M page_count: 5 document date: 2023-02-27



[pdf] Datasheet Borchure

Datasheet GY CyberView 3000 11 17 22 CYBERVIEW Adesso Gyration Cyberview 3 Megapixel Indoor Network Camera Color H 264 265 2048 X 1536 2 80 Mm Fixed Lens Cmos Bracket Mount Alexa Google Home Supported Ip65 Dust Proof Water DirectDial Canada 1076447246 content etilize Manufacturer Brochure |||

CYBERVIEW 3000 3 MP Smart Wi Wireless Doorbell DATASHEET Resolution

Perimeter Detection VCA Edge Storage IP65 Waterproof Supports Wi- Cloud Solution

KEY FEATURES The Gyration **Cyberview 3000** is a 3 mp Smart AI Wi-Fi battery doorbell camera, suitable for outdoor use. Support 24 hrs. motion detection. Support PIR motion sensor. Instant & accurate alerts. 2.4GHz WiFi connection, support Micro SD card storage. Support Android/iOS system mobile devices, remote monitoring. The Cyberview 3000 initiates a video call via the CyberView Plus app when someone rings your doorbell, so you'll never miss a visitor. See and talk to your visitors from your smartphone anywhere, any time. The built-in microphone and speaker make it easy for you to hear what's happening outside the door. With CyberView Plus app, you can protect, capture, save and share what's valuable to you.

lang:en score:31 filesize: 2.39 M page_count: 5 document date: 2023-01-03



[pdf]

PowerPoint user Gyration Company Profile 2023 gyration UploadFiles |||


About Us Since 1994 Global Logistic Support Center 2019 1994 2020 2008 2018 1994 2019 2020 ... SD AI Motion Detection Built-In Mic/ Speaker Edge Storage Waterpro of Cloud Stream Storage **Cyberview 3000** 3MP Smart WiFi Wireless Doorbell Doorbell Package Activity Detection PerPseoondP...
lang:en score:26 filesize: 4.53 M page_count: 28 document date: 2023-01-18



[pdf]

PowerPoint user ADESSO Keyboards Mice Webcams Headsets Speakers Document Scanners More Adesso Inc Your Input Device Specialist Gyration Company PPT 2023 us adesso assets fp |||

Retail Industry Solution Restaurants Lodge Government Hospital Critical Infrastructure Smart ... ker Edge Storage Waterpro of Cloud Stream Storage WiFi AI Doorbell Security Camera with Chime **Cyberview 3000** 3MP Smart WiFi Wireless Doorbell Package Activity Detection PerPseoondDleeDteectt...
lang:en score:22 filesize: 3.84 M page_count: 24 document date: 2022-12-31



[Gyration Cyberview3000 Smart Video Doorbell User Manual](#)

Comprehensive user manual for the Gyration Cyberview3000 Smart Video Doorbell kit, detailing installation, setup, features, and troubleshooting.

lang:en score:17 filesize: 2.98 M page_count: 44 document date: 2023-01-01