

[manuals.plus](#) /› [Kawai](#) /› [Kawai CA501 Digital Piano User Manual](#)**Kawai CA501**

Kawai CA501 Digital Piano User Manual

Model: CA501

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Kawai CA501 Digital Piano. Please read these instructions thoroughly before operating the instrument and retain them for future reference. The Kawai CA501 is a digital piano designed to offer a high-quality playing experience. It features an 88-key keyboard with grade-weighted hammer-action wooden keys, stereo-sampled concert grand piano sounds, and integrated speakers. The instrument also includes Bluetooth connectivity and various sound effects.

2. PRODUCT OVERVIEW



Figure 2.1: Front view of the Kawai CA501 Digital Piano in Satin White. The image displays the full 88-key keyboard, the music rest, and the three foot pedals at the base.

Key Features:

- 88-key Digital Piano with Grade-weighted Hammer-action Wooden Keys
- Built-in Speakers for rich sound reproduction
- Bluetooth Compatibility for wireless connectivity
- Stereo Sampled Sounds for authentic acoustic piano experience
- 24 Additional Effects to enhance sound customization
- Furniture-grade upright cabinet design
- Ivory Touch surface on keys for enhanced tactile feel

3. SETUP INSTRUCTIONS

Careful assembly and placement are crucial for optimal performance and longevity of your digital piano.

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Verify that all parts listed in the packing list are present.
3. Retain packaging materials for potential future transport or service.

3.2 Assembly (General Guidance)

While specific assembly steps are detailed in a separate assembly guide (not included in this manual), general steps typically involve:

- Attaching the side panels to the base unit.
- Securing the pedal board to the base.
- Placing the main keyboard unit onto the assembled stand.
- Connecting internal cables (e.g., pedal unit to keyboard).
- Attaching the music rest.

Caution: Always lift the piano with at least two people to prevent injury or damage.

3.3 Power Connection

1. Ensure the piano's power switch is in the OFF position.
2. Connect the provided AC adapter to the DC IN jack on the piano.
3. Plug the AC adapter into a suitable wall outlet.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To power on: Press the POWER button.
- To power off: Press and hold the POWER button until the display turns off.

4.2 Basic Playback

- Adjust the volume using the VOLUME slider/knob.
- Select desired instrument sounds using the dedicated buttons or menu system.
- Utilize the three pedals (Sustain, Sostenuto, Soft) as you would on an acoustic piano.

4.3 Bluetooth Connectivity

The Kawai CA501 supports Bluetooth for audio streaming and MIDI communication.

1. Activate Bluetooth on your external device (smartphone, tablet, computer).
2. On the piano, navigate to the Bluetooth settings menu.
3. Select your device from the list to pair.
4. Once paired, you can stream audio to the piano's speakers or use it as a MIDI controller.

5. MAINTENANCE

Proper care ensures the longevity and optimal performance of your Kawai CA501 Digital Piano.

5.1 Cleaning

- **Cabinet:** Wipe with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Keys:** Wipe with a soft, slightly damp cloth. Do not use chemical cleaners, as they may damage the key

surface.

5.2 Storage and Environment

- Avoid direct sunlight, extreme temperatures, and high humidity.
- Keep the instrument away from heat sources and air conditioning vents.
- Ensure adequate ventilation around the piano.

6. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
No sound	Volume too low; headphones connected; power issue.	Increase volume; disconnect headphones; check power connection.
Keys not responding	Instrument mode incorrect; internal error.	Check selected instrument voice; power cycle the piano.
Bluetooth pairing failure	Device too far; Bluetooth off on device/piano; interference.	Move device closer; ensure Bluetooth is active on both; restart devices.

If the problem persists, please contact Kawai customer support.

7. SPECIFICATIONS

Model Name	CA501
Brand	Kawai
Number of Keys	88
Key Action	Grade-weighted Hammer-action Wooden Keys
Finish Type	Satin
Color	White
Connectivity Technology	Bluetooth, USB
Power Source	Corded Electric
Item Weight	109.8 pounds (approx. 49.8 kg)
Product Dimensions	61.5 x 27 x 22.75 inches (approx. 156.2 x 68.6 x 57.8 cm)
Special Feature	Portable (referring to its design for home use, not easily transportable like a stage piano)

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the





official Kawai website. Keep your proof of purchase for warranty claims.


Customer Support:

If you require technical assistance, service, or have questions regarding your Kawai CA501 Digital Piano, please contact Kawai customer support through their official channels. Contact information can typically be found on the Kawai website or in the product packaging.

Online Resources: For additional resources, FAQs, and software updates, visit the official [Kawai Global website](#).


Related Documents - CA501

 <p>KAWAI CA49 Owner's Manual</p> <ul style="list-style-type: none">Important InformationPreparationBasic OperationAdjustments & SettingsAppendix	<p>Kawai CA49 Digital Piano Owner's Manual</p> <p>Comprehensive owner's manual for the Kawai CA49 digital piano, covering setup, operation, features, safety instructions, and troubleshooting.</p>
 <p>KAWAI STAGE PIANO MP11SE Manual de Usuario</p> <ul style="list-style-type: none">IntroducciónFuncionamiento GeneralMenú EZAlmacenamiento MP3GrabaciónAlarmaMenú SYSTEMAjustes	<p>Kawai MP11SE Stage Piano: Manual de Usuario Completo</p> <p>Guía detallada del Kawai MP11SE Stage Piano. Aprenda a usar el teclado Grand Feel, las secciones de sonido PIANO, E.PIANO, SUB, el grabador, funciones USB y más. Incluye instrucciones de seguridad y configuración.</p>
 <p>KAWAI ES60 Owner's Manual Bedienungsanleitung Manuel de l'utilisateur Manual de Usuario Manual de Uso 使用说明书 取扱説明書</p> <ul style="list-style-type: none">Capítulo 1: IntroducciónCapítulo 2: Funcionamiento GeneralCapítulo 3: Menú EZCapítulo 4: Almacenamiento MP3Capítulo 5: GrabaciónCapítulo 6: AlarmaCapítulo 7: Menú SYSTEMCapítulo 8: Ajustes	<p>Kawai ES60 Digital Piano Owner's Manual: Your Comprehensive Guide</p> <p>Official owner's manual for the Kawai ES60 digital piano. Learn setup, operation, features, safety, and maintenance for optimal performance. Includes multiple languages.</p>
 <p>KAWAI NOVUS NOVUS Hybrid-Piano</p> <ul style="list-style-type: none">1. Einrichtung und Bedienung2. Wartung und Pflege3. Fehlerbehandlung4. Technische Spezifikationen	<p>Kawai NV12/NV6 Hybrid-Piano Bedienungsanleitung: Umfassender Leitfaden für Einrichtung und Bedienung</p> <p>Erhalten Sie detaillierte Anleitungen zur Einrichtung, Bedienung und Wartung Ihres Kawai NV12/NV6 Hybrid-Pianos. Dieses Handbuch deckt Sicherheitshinweise, grundlegende und erweiterte Funktionen, Fehlerbehebung sowie technische Spezifikationen ab.</p>



[Kawai CA701 Digital Piano Operation Manual: Features, Functions, and Settings](#)

Explore the Kawai CA701 digital piano with this comprehensive operation manual. Learn about its controls, playing modes (Dual, Split, Four Hands), metronome, recorder, lesson functions, sound settings, Virtual Technician, and Bluetooth connectivity for an enhanced musical experience.



[Kawai CL36 Digital Piano Owner's Manual: Features and Operation](#)

Explore the Kawai CL36 digital piano with this comprehensive owner's manual. Learn about its advanced features, lesson function, MIDI capabilities, and how to get the most out of your instrument.