



[Manuals.plus](#) /

› [Faber](#) /

› Faber FPB1800W Digital Power Blender Mixer Grinder User Manual

## Faber FPB1800W

# Faber FPB1800W Digital Power Blender Mixer Grinder User Manual

Model: FPB1800W

[Overview](#)   [Setup](#)   [Operation](#)   [Safety Instructions](#)   [Product](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Faber FPB1800W Digital Power Blender Mixer Grinder. Retain this manual for future reference.

- Always ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the jar while blending to reduce the risk of severe injury to persons or damage to the blender.
- Blades are sharp. Handle with extreme care when cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Ensure the lid is securely locked in place before operating the blender. The sensor technology prevents operation if the lid is not correctly positioned.
- Do not overfill the jars. Refer to the maximum fill lines.
- Use only attachments and accessories recommended by the manufacturer.
- Exercise caution when blending hot liquids, as steam can cause burns.
- This appliance is for household use only.

## 2. PRODUCT OVERVIEW

### 2.1 Included Components

- Main Motor Unit (Base)

- 1.2L Glass Jar with Lid and 6-Leaf Stainless Steel Blade
- 0.8L Stainless Steel Jar with Lid and Blade
- Tamper/Pusher
- Cleaning Brush
- Measuring Cup

## 2.2 Key Features

- **Powerful 1800W Motor:** Ensures efficient blending, grinding, and mixing for various ingredients.
- **Built-in 850W Heater:** Allows for hot soup making and keeping food warm directly in the blender.
- **6 Auto-Cook Menus:** Pre-programmed settings for common preparations like hot soup, nut milk, smoothies, and more.
- **Digital Display & Touch Control:** Intuitive interface for easy operation and precise control over time and speed.
- **Durable Jars:** Includes a 1.2L Boron Glass Jar and a 0.8L Stainless Steel Jar for versatile use.
- **6-Leaf Stainless Steel Serrated Blade:** Designed for optimal blending and grinding consistency.
- **3D Cyclone Flow Technology:** Ensures thorough mixing and prevents lumps.
- **Sensor Technology:** Activates the control panel only when the lid is securely locked, enhancing safety.
- **Leak-Proof Design:** Prevents accidental spills and splashes during operation.
- **Metal Coupler:** Provides enhanced durability and stability for long-lasting performance.

## 2.3 Product Visuals

# Multifunctional cooking machine



Figure 1: Faber Digital Power Blender Mixer Grinder with 1.2L glass jar and 0.8L stainless steel jar.

### Blend Juices



### Blend Milk Shake



### Blend Smoothies



### Blend Ice Cubes



Figure 2: Close-up of the digital control panel with various function buttons.



Figure 3: Icons representing the various functions and auto-cook menus available on the blender.

## 2.4 Official Product Video

Your browser does not support the video tag.

Video 1: An official product video demonstrating the Faber Digital Power Blender's features, including blending, grinding, hot soup making, and its digital controls and safety features.

## 3. SETUP GUIDE

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future shipping.
2. **Clean:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Placement:** Place the motor base on a stable, flat, and dry surface. Ensure it is away from heat sources and water.
4. **Assemble Jar:**
  - For the glass jar, ensure the blade assembly is securely attached to the bottom.
  - For the stainless steel jar, ensure the blade is correctly seated.
5. **Attach Jar to Base:** Place the desired jar onto the motor base, aligning the bottom of the jar with the coupler on the base. Twist gently until it locks into place.
6. **Secure Lid:** Add ingredients to the jar. Place the lid onto the jar and twist clockwise until it clicks securely into position. The digital control panel will illuminate, indicating it's ready for operation.
7. **Power On:** Plug the power cord into a suitable electrical outlet.

## 4. OPERATING INSTRUCTIONS

---

The Faber FPB1800W features a user-friendly digital control panel. Ensure the jar and lid are correctly assembled and locked before starting any operation.

### 4.1 General Operation

1. **Add Ingredients:** Place your desired ingredients into the chosen jar. Do not exceed the maximum fill line.
2. **Secure Lid:** Place the lid on the jar and twist clockwise until it locks. The control panel will activate.
3. **Select Function:**
  - **Manual Mode:** Use the "TIME" and "SPEED" buttons to adjust blending duration and intensity.
  - **Auto-Cook Menus:** Press the "MENU" button to cycle through the 6 pre-programmed functions (Juice/Grinding, Smoothie, Milkshake, Batter, Soup, Nut Milk). The selected program will display on the screen.
  - **Warm Function:** Press "WARM" to activate the heating element for hot soups or to keep contents warm.
  - **Washing/Pulse:** Use "WASHING/PULSE" for quick bursts of power or for cleaning.
4. **Start/Stop:** Press the "START/STOP" button to begin or end the selected operation.
5. **After Use:** Once blending is complete, press "START/STOP" to halt the operation. Unplug the appliance before removing the lid and jar.

### 4.2 Specific Functions

- **Blending Smoothies/Juices:** Use the 1.2L glass jar. Select "Smoothie" or "Juice/Grinding" from the menu. For best results, add liquids first, then soft ingredients, and finally harder items or ice.
- **Dry Grinding:** Use the 0.8L stainless steel jar for dry spices, nuts, or coffee beans. Select "Juice/Grinding" or use manual speed control.
- **Hot Soup Making:** Use the 1.2L glass jar. Add ingredients for soup (e.g., vegetables, broth). Select the "Soup" auto-cook menu. The built-in 850W heater will cook and blend the ingredients to a smooth, hot consistency.
- **Nut Milk:** Use the "Nut Milk" auto-cook menu for preparing fresh nut milks.
- **Ice Crushing:** The powerful motor and blades are suitable for crushing ice. Use the 1.2L glass jar and select an appropriate speed or pulse function.

## Versatile Machine That Caters to All Your Needs



Figure 4: The blender's versatility in preparing a range of items from soups to smoothies.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Self-Cleaning (Quick Clean):**
  - Add warm water and a drop of dish soap to the jar (do not exceed half full).
  - Secure the lid and place the jar on the motor base.
  - Press the "WASHING/PULSE" button for a few seconds, or run on low speed for 30 seconds.
  - Rinse the jar thoroughly.
3. **Deep Cleaning Jars and Lids:**
  - Disassemble the jars and blades (if removable).
  - Wash with warm, soapy water using the provided cleaning brush for hard-to-reach areas.
  - Rinse thoroughly and allow to air dry completely before reassembling or storing.
  - *Note:* The jars and lids are dishwasher safe.
4. **Cleaning the Motor Base:**

- Wipe the motor base with a soft, damp cloth.
- Do not use abrasive cleaners or scourers.
- Never immerse the motor base in water or any other liquid.

5. **Storage:** Store the blender and its accessories in a clean, dry place.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	<ul style="list-style-type: none"> <li>• Not plugged in.</li> <li>• Lid not securely locked.</li> <li>• Jar not correctly seated on base.</li> <li>• Power outage.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure the power cord is securely plugged into a working outlet.</li> <li>• Twist the lid clockwise until it clicks into place and the digital panel illuminates.</li> <li>• Ensure the jar is properly aligned and twisted onto the motor base.</li> <li>• Check your household's power supply.</li> </ul>
Ingredients are not blending smoothly or are lumpy.	<ul style="list-style-type: none"> <li>• Too little liquid.</li> <li>• Overfilled jar.</li> <li>• Ingredients are too large or dense.</li> </ul>	<ul style="list-style-type: none"> <li>• Add more liquid (water, milk, juice) to facilitate blending.</li> <li>• Reduce the amount of ingredients in the jar.</li> <li>• Cut ingredients into smaller pieces. Use the tamper/pusher if necessary.</li> </ul>
Burning smell during operation.	<ul style="list-style-type: none"> <li>• Overloading the motor.</li> <li>• Prolonged continuous operation.</li> </ul>	<ul style="list-style-type: none"> <li>• Unplug immediately. Reduce ingredients or add more liquid. Allow the motor to cool down for at least 15-20 minutes before resuming.</li> <li>• Avoid running the blender for extended periods. Use pulse function for tough ingredients.</li> </ul>
Leakage from the jar.	<ul style="list-style-type: none"> <li>• Lid not properly sealed.</li> <li>• Jar overfilled.</li> <li>• Damaged gasket or blade assembly.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure the lid is twisted clockwise until it is fully secured.</li> <li>• Do not fill ingredients above the maximum fill line.</li> <li>• Inspect the gasket and blade assembly for damage. Contact customer support if damaged.</li> </ul>

## 7. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Faber

Feature	Detail
Model	FPB1800W
Color	Black
Wattage	1800 Watts (Motor), 850 Watts (Heater)
Voltage	220 Volts
Capacity	1.2 Litres (Glass Jar), 0.8 Litres (Stainless Steel Jar)
Material	Stainless Steel (Jars & Blades), Boron Glass (Main Jar)
Blade Material	Stainless Steel
Number of Speeds	8
Special Features	Leak Proof, 6 Auto Cook Menus, Hot Soup Maker, Digital Display, Touch Control
Dishwasher Safe Parts	Yes (Jars and Lids)
Item Weight	5360 Grams
Country of Origin	China

## 8. WARRANTY AND SUPPORT

The Faber FPB1800W Digital Power Blender Mixer Grinder comes with a **2-year limited warranty** from the date of purchase.

This warranty covers manufacturing defects and faulty materials under normal household use. It does not cover damage resulting from misuse, neglect, accidental damage, or unauthorized repairs.

### Customer Support:

For warranty claims, technical assistance, or spare parts, please contact Faber customer service. Refer to the contact information provided in your product packaging or visit the official Faber website.

Manufacturer: Faber, Faber