

Xgody X60

Xgody X60 4G LTE Smartphone User Manual

MODEL: X60

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your Xgody X60 4G LTE Smartphone. Please read this guide thoroughly to ensure proper usage and to maximize your device's performance.

2. What's in the Box

Upon opening your Xgody X60 package, verify that all components are present:

- Xgody X60 Cell Phone
- HD Screen Protector
- Tempered Film
- Phone Case
- USB Cable
- SIM Card Tray Pin
- User Manual
- Packing Box

The following video demonstrates the unboxing process and contents:

Your browser does not support the video tag.

Video: Unboxing the Xgody X60, showing the phone, battery, USB cable, screen protectors, phone case, and user manual.

All Day Without Charging

Everything you want to do has its
lasting-long support



Image: A flat lay of the Xgody X60 package contents, including the blue smartphone, clear phone case, USB cable, screen protectors, user manual, and battery.

3. Product Overview

The Xgody X60 is a 4G LTE unlocked smartphone designed for ease of use and essential mobile functions. Key features include:

- **Display:** 6-inch QHD Waterdrop Screen with an 18:9 aspect ratio.
- **Performance:** 2GB RAM + 16GB ROM, expandable up to 256GB with an SD card. Runs on Android 9.
- **Camera:** 5MP front camera and 5MP rear camera.
- **Battery:** 3000mAh removable battery for extended use.
- **Security:** Face Unlock feature for convenient and secure access.
- **Connectivity:** Dual SIM slots (1 Nano SIM, 1 Micro SIM) supporting 4G LTE networks (AT&T and T-Mobile compatible).

Why Choose **XGODY X60**

Many Functions In One




Image: A graphic illustrating key features of the Xgody X60, including Quad-core Processor, 2GB RAM + 16GB ROM, 3-in-1 Navigation System, 5MP+5MP Camera, Android 9, 3000mAh Battery, 6.0" QHD+ Display, 3 Card Slots, Ultra-Slim Design, and Face Unlock.

Most Comfortable Grip Size


The ergonomically designed size makes it easy to hold.



480*960
High Resolution



18:9
Aspect Ratio



6"
HQD Display

*Image: A blue Xgody X60 smartphone held in hand, highlighting its ergonomic design, 480*960 high resolution, 18:9 aspect ratio, and 6-inch HQD display.*

See The World Through HD Camera



5MP

Front camera



5MP

Rear camera



Panorama



Time lapse




Image: The Xgody X60 phone displaying a 100% battery charge, with icons indicating battery life for video playback (8 hours), music (15 hours), 4G web surfing (20 hours), and game playback (5 hours).

Installing Is Simple



Image: An illustration of the Xgody X60's camera features, including 5MP front camera, 5MP rear camera, Panorama, and Time-lapse modes, accompanied by three sample portrait photos.

4. Setup

Follow these steps to prepare your Xgody X60 for first use:

1. **Insert SIM and SD Cards:** The X60 features three independent card slots: one for a Nano SIM card, one for a Micro SIM card, and one for an SD card (up to 256GB). Use the provided SIM card tray pin to open the back cover. Carefully insert your SIM cards and SD card into their respective slots.
2. **Install Battery:** Place the 3000mAh removable battery into the battery compartment. Ensure it is correctly aligned.
3. **Close Back Cover:** Securely reattach the back cover.
4. **Power On:** Press and hold the power button located on the side of the phone until the Xgody logo appears.
5. **Initial Setup:** Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

Refer to the following video and image for visual guidance on installing the battery and SIM/SD cards:

Your browser does not support the video tag.

Video: Demonstration of how to open the back cover of the Xgody X60 mobile phone to access the battery and SIM/SD card slots.



Image: A four-panel guide showing the steps to open the phone's back cover, insert Nano and Micro SIM cards along with an SD card, place the battery, and close the back cover.

Dual SIM Dual Standby

SD Slot Support Storage Expandable Upto 256GB



Image: A visual representation of the Xgody X60's dual SIM and SD card slots, highlighting 4G network compatibility and specifying SIM types (Nano SIM 1, Micro SIM 2) and supported network bands.

5. Operating Instructions

Once your phone is set up, you can begin using its features:

- **Power On/Off:** Press and hold the power button to turn the device on or off. A short press will lock/unlock the screen.
- **Navigation:** Use the on-screen navigation buttons (Back, Home, Recent Apps) to move between applications and screens.
- **Settings:** Access device settings by swiping down from the top of the screen to open the notification panel, then tapping the gear icon, or by finding the 'Settings' app in your app drawer.
- **Face Unlock:** Configure Face Unlock in the security settings for quick and secure access to your device.
- **Applications:** Download and install applications from the Google Play Store.

The following video demonstrates the phone's interface and basic operations:

Your browser does not support the video tag.

Video: A demonstration of the Xgody X60's user interface, showing navigation through apps, settings, and basic phone functions.

6. Maintenance

To ensure the longevity and optimal performance of your Xgody X60:

- Keep the device clean and free from dust and moisture.
- Avoid exposing the phone to extreme temperatures.
- Use only approved chargers and accessories.
- Regularly clear cache and unnecessary files to maintain system speed.
- If the battery is damaged, it can be easily replaced due to its removable design.

7. Troubleshooting

If you encounter issues with your Xgody X60, consider the following common solutions:

- **Device not powering on:** Ensure the battery is correctly installed and charged. Connect the phone to a charger for at least 30 minutes before attempting to power on again.
- **Poor network signal:** Check that your SIM card is properly inserted and that you are within your carrier's coverage area. Restart the phone.
- **Applications crashing:** Clear the cache for the problematic app in Settings > Apps & notifications > [App Name] > Storage & cache. If the issue persists, try reinstalling the app.
- **Slow performance:** Close unused applications, clear storage, and restart the device.
- **Face Unlock not working:** Ensure your face is well-lit and unobstructed. Re-register your face data in the security settings if necessary.

8. Specifications

Detailed technical specifications for the Xgody X60 Smartphone:

Feature	Specification
Operating System	Android 9.0
RAM	2 GB
Memory Storage Capacity	16 GB (expandable up to 256GB via SD card)
Display Resolution	2560 x 1440 (QHD)
Wireless Communication Technologies	Cellular, Wi-Fi
Cellular Technology	4G LTE (AT&T and T-Mobile compatible)
GPS	True
Camera Features	Front, Rear (5MP + 5MP)
Battery Power Rating	3000 Milliampere Hour (mAh)

Item Weight	1.61 pounds
Package Dimensions	7.68 x 6.06 x 1.69 inches

9. Warranty and Support

Xgody is committed to customer satisfaction. Should you encounter any issues while using your Xgody X60 Smartphone, please contact our professional after-sales team. Our team will review your concerns promptly within 12 hours and provide a solution within 24 hours.