

[manuals.plus](#) /› [Dylanto](#) /› [Dylanto Instant Print Camera for Kids - User Manual](#)

Dylanto BLL2

Dylanto Instant Print Camera for Kids - User Manual

Model: BLL2

1. INTRODUCTION

This manual provides instructions for the Dylanto Instant Print Camera for Kids, Model BLL2. This camera is designed to allow children to capture photos and videos, and instantly print black and white images using thermal paper. It features a 2.4-inch screen, 1080P video recording, and various creative functions.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Dylanto Instant Print Camera (Purple)
- 3 rolls of printing paper
- 32GB memory card
- Lanyard
- USB Type-C cable
- User Manual (this document)



Image: The Dylanto Instant Print Camera in purple, shown with included accessories: three rolls of thermal paper, a 32GB memory card, a USB Type-C charging cable, and a lanyard.

3. PRODUCT FEATURES

The Dylanto Instant Print Camera offers a range of features designed for children:

- **Instant Printing:** Prints black and white photos directly from the camera using thermal paper.
- **Dual Camera:** Front and rear lenses for photos and selfies.
- **2.4-inch IPS Screen:** Clear display for viewing photos and videos.
- **1080P Video Recording:** Capture moments in high definition.
- **16x Digital Zoom:** Magnify subjects for closer shots.
- **Flash:** Built-in flash for low-light conditions.
- **Time-lapse Photography:** Set delays for photos.
- **Continuous Shooting:** Capture multiple photos in quick succession.
- **Filter Frames:** Add creative effects to photos.

- **Built-in Games:** Includes 4 puzzle games for entertainment.
- **MP3 Player:** Supports music playback.
- **32GB Memory Card:** Ample storage for photos and videos.
- **2000mAh Battery:** Provides 3-4 hours of continuous use.
- **Type-C Charging:** Fast and convenient charging.



Image: An illustration highlighting the camera's features, including print photo, 1080P video, MP3 player, game player, photograph, 2000mAh battery, playback, and filter effects.

4. SETUP

4.1 Charging the Camera

Before first use, fully charge the camera. Connect the included USB Type-C cable to the camera's charging port and a compatible USB power adapter (not included). The charging indicator will show the charging status. A full charge typically takes 2.5 hours and provides 3-4 hours of continuous use.



Image: A close-up of the camera's Type-C charging port, indicating its location for charging.

4.2 Installing the Memory Card

Locate the memory card slot on the side of the camera. Insert the provided 32GB memory card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.

4.3 Installing Thermal Printing Paper

Follow these steps to correctly install the thermal printing paper:

1. Push up the part with the lens to open the paper slot.
2. Insert a roll of thermal printing paper into the slot. Ensure the paper roll is inserted in the correct direction to avoid blank prints. The printable side should face the lens.
3. Close the two parts of the camera securely.
4. To prevent blank prints, pull out approximately 1 inch of paper before the first print.




Image: A visual guide demonstrating how to open the camera, insert the thermal paper roll in the correct direction, and close the camera. It also shows pulling out paper before printing and troubleshooting for blank prints.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press and hold the power button (usually located on the top or side) to turn the camera on or off.

5.2 Navigating the Menu

Use the directional buttons (up, down, left, right) to navigate through the camera's menu options on the 2.4-inch IPS screen. The 'OK' button confirms selections.

5.3 Taking Photos

1. Select the photo mode from the main menu.
2. Frame your shot using the screen.
3. Press the shutter button to capture the photo.
4. To print the photo, ensure the camera is in 'Print Mode' (if applicable, check camera settings) and press the print key.

Cute Frame Stickers&Graffiti

Draw unique postcard




Image: A child happily using the purple Dylanto Instant Print Camera to take a picture, demonstrating its ease of use for young users.

5.4 Recording Videos

1. Select the video mode from the main menu.
2. Press the shutter button to start recording.
3. Press the shutter button again to stop recording.
4. Videos are saved to the 32GB memory card.

Your browser does not support the video tag.

Video: A demonstration of the camera's video recording capability, showing a child celebrating. This video illustrates the camera's ability to capture moving images.

5.5 Using Creative Features

- **Filter Frames:** Access the filter menu to apply various frames and effects to your photos before or after taking them.
- **Time-Lapse:** Set a delay (e.g., 2s, 5s, 10s) before a photo is taken, allowing time to pose.
- **Games:** Navigate to the 'Games' section to play the 4 pre-installed puzzle games.
- **MP3 Player:** Load MP3 files onto the memory card and access the MP3 player function to listen to music.



Image: An illustration showcasing various cute frame stickers and graffiti options available for photos, demonstrating how users can draw unique postcards and customize their images.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body and screen. Do not use liquid cleaners.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Fully charge the camera after each use to prolong battery life. If storing for an extended period, charge it periodically.
- **Thermal Paper:** Store thermal paper in a cool, dark place to prevent fading.
- **Drop Protection:** The camera features a shockproof shell, but avoid excessive drops to prevent damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not turn on.	Low battery.	Charge the camera fully using the USB Type-C cable.

Problem	Possible Cause	Solution
Prints are blank.	Thermal paper installed incorrectly.	Ensure the thermal paper roll is inserted with the printable side facing the lens. Rotate the paper roll 180 degrees and re-install if necessary. Pull out 1 inch of paper before printing.
Poor print quality.	Low battery; dirty print head; old thermal paper.	Charge the camera. Gently clean the print head with a soft, dry cloth. Use fresh thermal paper.
Cannot save photos/videos.	Memory card full or not inserted correctly.	Check if the 32GB memory card is inserted correctly. Delete unnecessary files or replace the card if full.
Camera freezes or malfunctions.	Software issue; temporary glitch.	Press and hold the power button to force a restart. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Dylanto
Model Name	BLL2
Screen Size	2.4 Inches IPS Display
Video Resolution	1080p
Effective Still Resolution	1 MP
Digital Zoom	16x
Memory Storage Capacity	32 GB (Micro SD card included)
Battery Capacity	2000 mAh Lithium Ion
Battery Average Life	3-4 Hours (continuous use)
Charging Port	USB Type-C
Image Stabilization	Digital
Supported File Format	JPEG (photos), AVI (videos)
Item Weight	15.5 Ounces
Dimensions (approx.)	3.9 inches (width) x 3.1 inches (height)

9. WARRANTY AND SUPPORT

The Dylanto Instant Print Camera comes with a **6-month warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact Dylanto customer service

through the retailer where the product was purchased or visit the official Dylanto store page:

[Visit the Dylanto Store](#)

Additional protection plans may be available for purchase separately:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan)

These plans offer extended coverage beyond the standard manufacturer's warranty.

© 2025 Dylanto. All rights reserved.

[gen_bottom_of_page]

Related Documents - BLL2

 SANUS BLL2-B1 FIXED-POSITION PREMIUM TV WALL MOUNT INSTRUCTION MANUAL 	<p>SANUS BLL2-B1 Fixed-Position Premium TV Wall Mount Instruction Manual</p> <p>Detailed instruction manual for the SANUS BLL2-B1 fixed-position premium TV wall mount. Includes safety information, tools required, parts list, installation steps for various wall types (wood stud, concrete, steel stud), and cable management.</p>
 SANUS  BLL2 INSTRUCTION MANUAL  GET IT RIGHT THE FIRST TIME <small>Follow this step-by-step instruction manual to speed up your installation.</small>  <small>What to watch a video that shows how to install your wall mount? Click here to watch a video.</small> <small>What to read a step-by-step instruction manual that shows how to install your wall mount? Click here to read a manual.</small> <small>Call an expert. Call us at 1-800-334-0000.</small> <small>Or click here to call.</small>	<p>SANUS Elite BLL2 TV Wall Mount Instruction Manual</p> <p>Step-by-step instructions for installing the SANUS Elite BLL2 TV Wall Mount. Includes safety information, tool requirements, and installation guides for wood studs, concrete, and steel studs.</p>
 ACCESSORIES & SOFTWARE <small>Enhance Your Love of Sewing</small>	<p>Baby Lock Accessories & Software: Enhance Your Love of Sewing</p> <p>Explore the extensive range of Baby Lock sewing machine accessories, feet, software, and longarm quilting tools designed to enhance your sewing experience. Find compatible parts for your specific Baby Lock model to unlock new creative possibilities.</p>

