

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Titan](#) /
- › [Titan Classic Quartz Chronograph Watch Model WTT90169NL01 User Manual](#)

Titan WTT90169NL01

Titan Classic Quartz Chronograph Watch User Manual

Model: WTT90169NL01

1. INTRODUCTION

Thank you for choosing the Titan Classic Quartz Chronograph Watch, Model WTT90169NL01. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

This watch features a precise quartz movement, a chronograph function for measuring elapsed time, and is designed with a dark teal green dial and a dark brown leather strap. It is water-resistant up to 50 meters.

2. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Titan Classic Chronograph Watch.



Figure 2.1: Front view of the Titan Classic Quartz Chronograph Watch.



Figure 2.2: Side view illustrating the crown and chronograph pushers.

Watch Components:

- **Crown:** Used for setting the time.
- **Pushers (A & B):** Used to operate the chronograph function.
- **Hour Hand:** Indicates the hour.
- **Minute Hand:** Indicates the minute.
- **Small Second Hand:** Continuous running second hand for timekeeping (located on a sub-dial).
- **Chronograph Second Hand:** Large central second hand used for chronograph timing.
- **Chronograph Minute Sub-dial:** Measures elapsed minutes during chronograph operation.
- **24-Hour Sub-dial:** Indicates time in a 24-hour format, synchronized with the main time.

3. SETUP

3.1 Setting the Time

1. Pull the crown out to position 2 (the outermost position). The small second hand will stop.
2. Rotate the crown to set the hour and minute hands to the desired time. Ensure the 24-hour sub-dial also reflects the correct AM/PM period.

3. Push the crown back into position 0 (normal position) to start the watch.

3.2 Adjusting the Leather Strap

The dark brown leather strap is designed for comfort and adjustability. To adjust, simply insert the buckle pin into the desired hole on the strap to achieve a snug yet comfortable fit on your wrist.

4. OPERATING THE CHRONOGRAPH

Your watch is equipped with a chronograph function to measure elapsed time.



Figure 4.1: Dial layout with chronograph sub-dials.

Chronograph Functions:

- **Pusher A (Top):** Starts and stops the chronograph.
- **Pusher B (Bottom):** Resets the chronograph to zero.

How to Use:

1. **Start:** Press Pusher A to start the chronograph. The large central second hand and the chronograph minute sub-dial will begin to move.
2. **Stop:** Press Pusher A again to stop the chronograph. The elapsed time will be indicated by the

chronograph second hand and the chronograph minute sub-dial.

3. **Reset:** After stopping, press Pusher B to reset all chronograph hands to their zero positions.
4. **Intermediate Time (Split Time):** This model does not feature a split-time function.

5. MAINTENANCE

Proper care will help preserve the appearance and function of your watch.

5.1 Cleaning

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid excessive moisture. If it gets wet, dry it gently with a soft cloth and allow it to air dry completely away from direct heat.
- Do not use chemical cleaners or abrasive materials, as these can damage the watch's finish.

5.2 Water Resistance



Figure 5.1: Case back indicating 50M Water Resistance.

- Your watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands.

- **Important:** Do not operate the crown or pushers while the watch is wet or submerged in water. This can compromise the water resistance.
- Avoid exposing the watch to hot water, steam, or sudden temperature changes, as this can damage the seals.

5.3 Battery Replacement

The watch is powered by a quartz battery. When the battery runs low, the watch may stop or the second hand may skip. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

5.4 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields.

6. TROUBLESHOOTING

If you encounter any issues with your watch, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--|---|---|
| Watch has stopped or runs intermittently. | Low battery. | Replace the battery by a professional watch technician. |
| Time is incorrect. | Time not set correctly or crown is not pushed in. | Refer to Section 3.1 to reset the time. Ensure the crown is fully pushed into position 0. |
| Chronograph hands do not reset to zero. | Requires calibration. | This usually indicates a need for professional service. Contact Titan customer support. |
| Moisture or condensation inside the crystal. | Compromised water resistance due to impact, aging seals, or operating crown/pushers underwater. | Seek immediate professional service to prevent further damage to the movement. |

For issues not listed here or if the suggested solutions do not resolve the problem, please contact Titan customer support or an authorized service center.

7. SPECIFICATIONS

Key technical details for your Titan Classic Quartz Chronograph Watch.

| Feature | Detail |
|---------------|--------------|
| Brand | Titan |
| Model Number | WTT90169NL01 |
| Movement Type | Quartz |
| Display Type | Analog |

| Feature | Detail |
|------------------|--|
| Case Diameter | 42 mm |
| Strap Material | Leather |
| Water Resistance | 50 Meters (5 ATM) |
| Special Features | Chronograph, 24-Hour Sub-dial, Arabic Numerals |
| Item Weight | 200 g |
| Batteries | Included and Required (Standard Watch Battery) |

8. WARRANTY INFORMATION

Your Titan Classic Quartz Chronograph Watch is covered by a manufacturer's warranty. The specific terms and duration of the warranty are provided with your purchase documentation. Please retain your proof of purchase for warranty claims.

For detailed warranty information, including coverage and exclusions, please refer to the warranty card included in your watch packaging or visit the official Titan website.

9. SUPPORT

Should you require assistance, service, or have any questions regarding your Titan watch, please contact Titan customer support.

- **Official Website:** www.titan.co.in
- **Customer Service:** Refer to the contact information provided in your watch packaging or on the official website for phone numbers and email support.
- **Authorized Service Centers:** A list of authorized service centers can be found on the Titan website.