

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [DNEI](#) /

› DNEI Digital Watch WR50M Waterproof Multifunctional Electronic Watch User Manual

DNEI Soraz9cs03evkop-12

DNEI Digital Watch User Manual

Model: Soraz9cs03evkop-12

INTRODUCTION

This manual provides detailed instructions for the DNEI Digital Watch, Model Soraz9cs03evkop-12. This electronic watch is designed for various activities, featuring WR50M water resistance, a clear display, and multiple functions. Please read this manual thoroughly to understand the watch's operation and maintenance.



Image: Front view of the DNEI Digital Watch, showcasing its digital display and button layout.



Image: The DNEI Digital Watch worn on a wrist, showing its size and fit.

PRODUCT FEATURES

- **Multifunction Display:** Includes luminous light, alarm, whole hour chime, running seconds, day and date display, and 12/24 hour system.
- **WR50M Water Resistance:** Suitable for swimming, showering, and exposure to rain.
- **Durable Construction:** Features an ABS plastic case, PU plastic strap, stainless steel back cover and buckle, and an acrylic resin mirror face.
- **Clear Large Screen:** Designed for easy readability.

WATCH COMPONENTS

Familiarize yourself with the watch's buttons and their primary functions:



Image: Close-up of the watch face showing the "LIGHT", "MODE", "START", and "RESET" buttons.

- **LIGHT Button:** Activates the luminous backlight.
- **MODE Button:** Cycles through different display modes (Time, Alarm, Stopwatch, etc.).
- **START Button:** Used to start/stop functions like the stopwatch, or to adjust settings.
- **RESET Button:** Used to reset functions or confirm settings.

SETUP AND BASIC OPERATION

1. Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the time setting mode is displayed (usually indicated by flashing digits).
2. Press the **RESET** button to select the digit you wish to adjust (e.g., seconds, hours, minutes, month, date, day). The selected digit will flash.
3. Use the **START** button to increase the value of the flashing digit. Hold the button to rapidly advance the numbers.

4. Continue pressing **RESET** to move to the next setting and **START** to adjust.
5. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.



Image: Close-up of the DNEI Digital Watch display on a wrist, showing the time and date clearly.

2. 12/24 Hour System Selection

While in the time setting mode (flashing hours), press the **START** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

3. Using the Luminous Light

Press the **LIGHT** button to illuminate the display for a few seconds, improving visibility in low-light conditions.

OPERATING ADVANCED FUNCTIONS

1. Alarm Setting

1. From the normal time display, press the **MODE** button until the alarm mode is displayed (often indicated by "AL" or a bell

icon).

2. Press the **RESET** button to select the hour digits. Use the **START** button to adjust the hour.
3. Press **RESET** again to select the minute digits. Use the **START** button to adjust the minutes.
4. To activate/deactivate the alarm, press the **START** button while in alarm mode (not setting time). An alarm icon will appear/disappear.
5. Press **MODE** to exit.

2. Whole Hour Chime (Hourly Chime)

While in the alarm mode, press the **RESET** button to toggle the hourly chime on or off. A chime icon or "SIG" indicator will show when it's active.

3. Stopwatch Function (Running Seconds)

1. Press the **MODE** button until the stopwatch mode is displayed (usually "ST" or "STOP").
2. Press the **START** button to begin timing.
3. Press **START** again to pause the timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press **MODE** to exit.



Image: The DNEI Digital Watch shown with a blurred background of a person running, illustrating its use for sports.

MAINTENANCE AND CARE

Water Resistance (WR50M)

The DNEI Digital Watch is rated WR50M, meaning it is suitable for swimming, showering, and general water exposure. However, it is important to observe the following:

- Do not operate buttons while the watch is submerged in water.
- Avoid exposing the watch to hot water or steam (e.g., hot showers, saunas), as this can compromise the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Cleaning

Wipe the watch case and strap with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid harsh chemicals or abrasive cleaners.



Image: Close-up view of the PU plastic strap, highlighting its texture and design.



Image: Close-up view of the stainless steel buckle on the watch strap.

Battery Information

The watch uses one LR1130 1.5V 66mAh battery, which is built-in. Battery replacement should ideally be performed by a qualified technician to ensure water resistance is maintained.

TROUBLESHOOTING

If you encounter issues with your DNEI Digital Watch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Display is blank or dim.	Low or depleted battery.	The built-in battery may need replacement. Contact a service center.
Time is incorrect.	Time was not set correctly or reset accidentally.	Refer to the "Setting Time and Date" section to re-adjust the time.

Problem	Possible Cause	Solution
Buttons are unresponsive.	Temporary software glitch or water ingress.	Try pressing all buttons firmly. If submerged, ensure watch is dry. If problem persists, contact support.
Water inside the display.	Compromised water resistance due to impact, age, or improper button use underwater.	Stop using the watch immediately. Seek professional repair to prevent further damage.

SPECIFICATIONS

Model Number	Soraz9cs03evkop-12
Brand	DNEI
Water Resistance	WR50M (5 ATM)
Strap Material	PU Plastic
Case Material	ABS Plastic
Back Cover Material	Stainless Steel
Mirror Face Material	Acrylic Resin
Watch Length	Approx. 24.5 cm / 9.6 in
Battery Type	1 x LR1130 1.5V 66mAh (Built-in)
Functions	Luminous, Alarm, Whole Hour Chime, Running Seconds, Day and Date Display, 12/24 Hour System
Country of Origin	China



24.5cm / 9.6in

Image: The DNEI Digital Watch displayed with its overall length measurement of 24.5 cm (9.6 inches).

IMPORTANT NOTES

- Manual measurements may have a slight error of 0.04-0.12 inches.
- Actual product color may vary slightly due to differences in shooting lights and monitor displays.