Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR tc70

VEVOR Mobile TV Cart Instruction Manual

Model: tc70

1. Product Overview

The VEVOR Mobile TV Cart is a versatile and robust solution designed to accommodate televisions ranging from 32 to 70 inches. It features a height-adjustable design, smooth-rolling wheels for portability, and double-tiered trays for organizing audio-visual devices and accessories. Its double-pole support structure ensures enhanced safety and stability.





Figure 1: Fully assembled VEVOR Mobile TV Cart, showcasing its design with a television mounted and media devices placed on the two integrated trays.

2. Setup and Assembly

The VEVOR Mobile TV Cart is designed for quick and easy assembly, typically taking around 10 minutes without the need for wall drilling. Follow the instructions provided in the packaging for detailed assembly steps.

2.1. Stability and Support

The TV cart features a double-pole support design, providing superior load-bearing capacity and stability for your television and devices.



Figure 2: Illustration highlighting the robust double-pole support structure, ensuring enhanced mobile stability and a maximum screen size of 70 inches with a 132 lbs weight capacity.

2.2. Height Adjustment

The rolling TV stand offers three levels of height adjustment, allowing you to customize the viewing experience for various seating arrangements or standing preferences.



Figure 3: Visual representation of the TV cart's adjustable height feature, demonstrating its adaptability for different environments such as living rooms, bedrooms, courtyards, and meeting rooms.

2.3. Double-Tiered Trays

The adjustable-height swivel mobile TV stand includes dual trays, capable of supporting up to 30 pounds. These trays are ideal for accommodating laptops, gaming systems, speakers, or other audio-visual devices.



Figure 4: Close-up view of the double trays, illustrating their utility for placing various devices. The image also highlights the integrated back cord management system for a tidy setup.

2.4. Cable Management

The integrated wire management design helps keep cables neat, tidy, and safe, preventing clutter and potential hazards.

3. Operating Instructions

3.1. Mobility

Thanks to its floor-standing design and universal rotating wheels, the TV cart can be effortlessly moved to any room. The wheels are lockable for quick stops and secure positioning.



Figure 5: Detailed view of the 360-degree universal rotating wheels, emphasizing their lockable feature for stability when the cart is in a desired position.

3.2. Swivel Functionality

The TV mount allows for swivel movement, providing optimal viewing angles from various positions in the room.

4. Maintenance

To maintain the TV cart, regularly wipe down surfaces with a soft, damp cloth. The design allows for easy access to clean the back of the TV without needing to remove it from the stand.

5. Troubleshooting

No specific troubleshooting steps are provided in this manual. For any issues, please refer to the VEVOR support channels.

6. Specifications

Feature	Detail
Product Dimensions	27 x 23 x 67 inches
Item Weight	29.9 pounds
Item Model Number	tc70
Mounting Type	Floor Mount
Movement Type	Swivel
Brand	VEVOR
Material	Metal
Maximum Compatible Size	70 Inches
Color	Black
Minimum Compatible Size	32 Inches
Compatible Devices	Television
Maximum Tilt Angle	15 Degrees
UPC	840349912608
Weight Capacity	Up to 132 lbs (60 kg)
Tray Capacity	Up to 30 lbs (13.6 kg)
VESA Compatibility	100mm x 100mm to 600mm x 400mm



Figure 6: Detailed specifications including product size (27x23x67 inches), weight capacity (132 lbs), fit screen size (32-70 inches), and VESA hole distance ranges.

7. Warranty and Support

For warranty information or further support, please visit the official VEVOR store or contact their customer service directly. Specific warranty details are not provided in this manual.

Visit the VEVOR Store for Support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6K3FLL8

More documents and user manuals: **https://manuals.plus/**