VEVOR Swivel Tall TV Stand 85 inch

VEVOR TV Stand Mount User Manual

Model: Swivel Tall TV Stand 85 inch

Product Overview

The VEVOR TV Stand Mount is a versatile and stable solution for displaying your television. Designed for TVs ranging from 32 to 85 inches and supporting up to 99 lbs, it offers universal compatibility with VESA patterns from 100x100 mm to 600x800 mm.

Its robust construction includes a 0.5-inch thick tempered glass base, ensuring enhanced safety and stability. The stand features six levels of height adjustment, allowing you to customize the viewing experience for various seating arrangements. A ±35° swivel function provides flexible viewing angles, making it ideal for multi-area spaces. Additionally, integrated cable management keeps your setup neat and tidy. The design prioritizes quick and easy assembly, requiring no drilling into walls.

Setup and Assembly

This TV stand is designed for straightforward assembly, typically completed within 10 minutes without the need for wall drilling. Follow the included instructions carefully.

Key Assembly Features:


- **No Drilling Required:** The floor-standing design eliminates the need to drill holes in your walls, protecting surfaces and allowing for easy repositioning.
- **Height Adjustment:** The stand offers six levels of height adjustment to accommodate different viewing preferences and room layouts.
- **Cable Management:** Utilize the integrated cable management system to route and conceal cables, ensuring a clean and organized appearance.
- **Removable Tray:** A convenient removable tray is included for placing media devices such as laptops or DVD players.



The stand does not require drilling into walls for installation, preserving your wall surfaces.



Adjust the TV height to one of six levels for optimal viewing comfort.



Product Size: 33x16x55in/841x397x1400 mm

Suitable For TV Hole Distance:

Min: 4"x4" /100x100 mm

Max: 24"x31"/600x800 mm

Weight Capacity: 110lbs/49.8 kg

Fit Screen Size: 32"-85"

Net Weight: 37.6 lbs/17.05 kg

Utilize the built-in cable management feature to keep wires organized and out of sight.



The stand includes a removable tray for media devices and allows for easy swiveling.

Operating Instructions

Adjusting Viewing Angle:

The TV stand features a ±35° swivel capability. Gently rotate the television screen to the left or right to achieve your desired viewing angle. This is particularly useful in rooms with multiple seating areas or to reduce glare.

Adjusting Height:

The stand allows for six levels of height adjustment. Refer to the assembly instructions for specific steps on how to safely adjust the height of the TV mounting brackets on the central column. Ensure the TV is securely fastened at the chosen height.

Using the Removable Tray:

The integrated removable tray provides a convenient surface for placing small media devices such as a DVD player, streaming box, or remote controls. Ensure any devices placed on the tray do not exceed its weight capacity.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your VEVOR TV Stand Mount.

- **Cleaning:** The 0.5-inch tempered glass base is easy to clean. Use a soft, damp cloth and a mild glass cleaner for the glass surfaces. For metal parts, a dry or slightly damp cloth is sufficient. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dust Removal:** Periodically dust the stand and the back of your TV. The floor-standing design allows for effortless movement, making it easy to access and clean the area behind the television.
- **Check Connections:** Periodically check all screws and connections to ensure they remain tight and secure, especially after moving the stand or adjusting the TV's position.

Troubleshooting

If you encounter any issues during assembly or use, consider the following common points:

- **Difficulty with Assembly:** Ensure all parts are correctly identified and oriented according to the instruction diagrams. Some steps may require careful attention to detail.
- **Incorrect Screws for TV Mounting:** When attaching the TV to the mount, it is crucial to select the correct screws that fit your TV's VESA holes without forcing them. If a screw does not fit easily, do not force it, as this can damage your television. Refer to your TV's manual for appropriate screw sizes if unsure.
- **Wobbling or Instability:** Verify that the tempered glass base is placed on a flat, stable surface. Ensure all assembly screws are tightened securely. The 0.5-inch thick tempered glass base is designed for stability, so wobbling typically indicates loose connections or an uneven surface.
- **Cable Management Issues:** If cables are not neatly organized, re-route them through the designated cable management channels. Ensure no cables are pinched or under excessive tension.

If problems persist, please contact VEVOR customer support for assistance.

Specifications

Brand	VEVOR
Model Number	Swivel Tall TV Stand 85 inch
Compatible TV Sizes	32 - 85 Inches
Weight Capacity	Up to 99 lbs (45 kg)
VESA Compatibility	Min: 100x100 mm (4"x4"), Max: 600x800 mm (24"x31")
Product Dimensions (L x W x H)	33 x 16 x 55 inches (841 x 397 x 1400 mm)
Item Weight	37 pounds (17.05 kg)
Material	Tempered Glass, Metal
Color	Black
Movement Type	Swivel (±35°)
Mounting Type	Floor Mount

UPC	840349912622



Detailed product dimensions and VESA hole distance specifications.



The stand is compatible with a wide range of TV sizes, from 32 to 85 inches.

Warranty and Support

Specific warranty details for this product are not provided in this manual. For information regarding warranty coverage, claims, or technical support, please refer to the official VEVOR website or contact VEVOR customer service directly.

Please have your product model number (Swivel Tall TV Stand 85 inch) and UPC (840349912622) available when contacting support.

Product Videos

No official product videos from the seller are available for embedding in this manual.

© 2024 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question