

## LOUTOC rk-premiere

# LOUTOC Replacement Remote Control Instruction Manual

For Roku Express, Premiere, Box, and Player Models (1, 2, 3, 4)

## 1. INTRODUCTION

---

Thank you for choosing the LOUTOC Replacement Remote Control. This remote is designed to provide seamless control for compatible Roku streaming devices. It offers a straightforward, out-of-the-box experience without the need for complex programming. Please read this manual carefully to ensure proper use and to understand the full capabilities and limitations of your new remote.

## 2. COMPATIBILITY

---

This LOUTOC Replacement Remote Control is specifically designed for use with the following Roku models:

- Roku Express
- Roku Premiere
- Roku Box
- Roku Player (Models 1, 2, 3, 4)
- Roku HD, LT, XS, XD

### Important Compatibility Notes:

- This remote is **NOT** compatible with any Roku Stick or Roku TV models.
- This is an IR (Infrared) remote. It does **NOT** feature volume control, a power button, a headphone jack, a pairing button, or voice search functionality.



**Compatible with**  
Ro-ku 1 2 3 4  
Ro-ku HD LT XS XD  
Ro-ku Express  
Ro-ku Premiere



**NOT fit for any Ro-ku Stick  
or Ro-ku TV!**



Image 2.1: Visual guide to compatible Roku box models and incompatible Roku Stick/TV models.



Image 2.2: The remote does not include a power button, voice search, or RF model capabilities. It is an IR remote.

### 3. FEATURES

Your LOUTOC Replacement Remote Control offers the following features:

- **Instant Setup:** No programming required. Simply insert batteries and it's ready to use.
- **IR Technology:** Operates using infrared signals, requiring a direct line of sight to your Roku device.
- **Dedicated Shortcut Buttons:** Quick access to popular streaming channels including Netflix, Disney+, Hulu, and Sling.
- **Durable Construction:** Made from ABS material for longevity.



**NO Setup Required**



**IR Technology**



**ABS Material**

Image 3.1: Key features of the remote: No setup required, IR technology, and durable ABS material.




Image 3.2: This remote does not include volume control, a pairing button, or a headphone jack.

## 4. SETUP AND INSTALLATION

Follow these simple steps to begin using your new remote:

1. **Insert Batteries:** Open the battery compartment cover on the back of the remote. Insert two (2) AAA batteries, ensuring correct polarity (+/-). Close the cover securely.
2. **Automatic Connection:** Point the remote directly at your compatible Roku device. The remote should function immediately without any additional programming or pairing steps.



**Batteries are NOT included.  
Rotate the batteries for best usage after you put them in.**

Image 4.1: Proper insertion of two AAA batteries into the remote's battery compartment.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the ease of setup for the LOUOC Replacement Remote Control, highlighting that it works immediately after battery insertion with compatible Roku devices.

## 5. OPERATING INSTRUCTIONS

The remote features standard navigation and playback controls:

- **Directional Pad (Purple Cross):** Use the up, down, left, and right arrows to navigate menus and content.
- **OK Button:** Confirms selections.
- **Back Button (Left Arrow):** Returns to the previous screen or menu.
- **Home Button (House Icon):** Returns to the Roku home screen.
- **Playback Controls:** Play/Pause, Fast Forward, Rewind buttons for media control.
- **Instant Replay:** The curved arrow button allows for quick replay of content.
- **Shortcut Buttons:** Directly launch Netflix, Disney+, Hulu, and Sling with a single press.



Image 5.1: The remote uses infrared (IR) technology, requiring a clear line of sight to your Roku device for optimal operation.

## 6. TROUBLESHOOTING

If you encounter issues with your remote, consider the following:

- **Remote Not Responding:** Ensure fresh AAA batteries are correctly inserted.
- **No Line of Sight:** As an IR remote, ensure there are no obstructions between the remote and your Roku device.
- **Incorrect Roku Model:** Double-check that your Roku device is one of the compatible models listed in Section 2. This remote will not work with Roku Sticks or Roku TVs.

## 7. SPECIFICATIONS

<b>Product Dimensions</b>	3.93 x 1.12 x 0.59 inches
<b>Item Weight</b>	1.76 ounces
<b>Batteries Required</b>	2 AAA batteries (not included)

<b>Technology</b>	Infrared (IR)
<b>Material</b>	ABS

## 8. WARRANTY AND SUPPORT

---

Your LOUOC Replacement Remote Control comes with a 60-day replacement policy. For any questions or support needs, please refer to the LOUOC store on Amazon or contact customer service.



Image 8.1: The product is covered by a 60-day replacement policy.

Visit the [LOUOC Store](#) for more products and support.