

[Manuals.plus](#) /

› [Legami](#) /

› Legami Gel Pen with Decorative Kitty Animal User Manual

Legami CPP0002

Legami Gel Pen with Decorative Kitty Animal

Model: CPP0002 | Brand: Legami

INTRODUCTION

This manual provides essential information for the proper use and care of your Legami Gel Pen with Decorative Kitty Animal. Designed for smooth writing, this pen features a unique decorative animal that helps prevent the pen from rolling off surfaces. It uses pink ink and has a 0.5 mm tip for precise lines.



Image: The Legami Gel Pen in pink, featuring a small grey kitty figure attached near the pen's tip. The pen is designed to prevent rolling.

SETUP

The Legami Gel Pen is ready for immediate use upon unboxing.

1. **Unpacking:** Carefully remove the pen from its packaging.
2. **First Use:** The pen features a retractable mechanism. Simply click the top button to extend the pen tip for writing. No protective cap needs to be removed.

OPERATING INSTRUCTIONS

Using your Legami Gel Pen is straightforward.

- **Writing:** Press the top of the pen to extend the 0.5 mm tip. Apply light pressure to write on paper. The gel ink provides a smooth and consistent line.
- **Retracting the Tip:** To retract the pen tip and prevent accidental marks or drying, press the top button again.

- **Anti-Rolling Feature:** The decorative Kitty animal figure is designed to act as a stopper, preventing the pen from rolling off flat surfaces when placed down.
- **Recombinable Animal:** The decorative animal figure is removable and can be exchanged with animal figures from other compatible Legami Lovely Friends pens, allowing for customization.



Image: A detailed view of the pen's tip, highlighting its 0.5 mm diameter and confirming the pink ink color.



Image: A collection of Legami Gel Pens, each with a different animal decoration, illustrating how the animal figures can be interchanged between pens.

MAINTENANCE

Proper care will extend the life and performance of your gel pen.

- **Cleaning:** If the pen body becomes dirty, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Always retract the pen tip when not in use to prevent the ink from drying out. Store the pen horizontally or tip-down to ensure consistent ink flow. Avoid extreme temperatures.
- **Ink Refills:** This specific model is not designed for ink refills. Once the ink is depleted, the pen should be replaced.

TROUBLESHOOTING

If you encounter issues with your Legami Gel Pen, consider the following common solutions:

Problem	Possible Cause	Solution
Ink not flowing smoothly or skipping	Dried ink on tip, air bubble, or low ink level.	Gently scribble on a scrap piece of paper to dislodge dried ink or air bubbles. If the issue persists, the ink may be depleted.
Pen tip feels scratchy	Debris on the tip or damage to the ballpoint.	Inspect the tip for any visible debris and gently wipe it clean. If the tip appears damaged, the pen may need replacement.
Pen does not retract/extend	Mechanism jam or damage.	Ensure no foreign objects are obstructing the mechanism. Avoid forcing the mechanism. If it remains stuck, the pen may be damaged.

SPECIFICATIONS

Key technical specifications for the Legami Gel Pen:

Brand	Legami
Model Number	CPP0002
Item Weight	0.353 ounces (approx. 10 grams)
Package Dimensions	5.43 x 0.71 x 0.51 inches (approx. 13.8 x 1.8 x 1.3 cm)
Color	KITTY (Pink Ink)
Closure Type	Retractable
Material Type	Plastic
Point Type	Fine
Line Size	0.5 mm
Ink Color	Pink

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official Legami website.

[Visit Legami Official Website](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C6L2V3JY>

More documents and user manuals: **<https://manuals.plus/>**