

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WAMPAT](#) /

› [WAMPAT Oak End Table with Charging Station \(Model: Scarlett\) - Instruction Manual](#)

## WAMPAT Scarlett

# WAMPAT Oak End Table with Charging Station (Model: Scarlett) - Instruction Manual

Your guide to assembly, use, and care.

## INTRODUCTION

---

Thank you for choosing the WAMPAT Oak End Table with Charging Station. This manual provides detailed instructions for assembling, operating, and maintaining your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



*The WAMPAT Oak End Table with Charging Station, featuring a rustic oak top and white base.*

## SAFETY GUIDELINES

---

- Ensure the weight on the table does not exceed 40 pounds (18 kg) to prevent damage or instability.
- Follow all assembly instructions carefully to ensure the table is stable and secure.
- Keep small parts and packaging materials away from children during assembly to avoid choking hazards.
- Use the charging station only for indoor purposes.
- Do not attempt to open or modify the electrical components of the charging station.

## PACKAGE CONTENTS

---

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Table Panels (various sizes)
- Drawer Panels

- Cabinet Door Panel
- Gourd-shaped Legs (4 pieces)
- Drawer Slides (2 sets)
- Handles (3 pieces)
- Charging Station Unit (2 AC outlets, 2 USB ports)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

## ASSEMBLY INSTRUCTIONS

---

For a visual guide, please refer to the official assembly video below. Ensure you have a screwdriver and follow the steps carefully.

Your browser does not support the video tag.

*Official WAMPAT Side Table with Charging Station Assembly Video.*

### Step-by-Step Assembly

1. **Prepare Panels and Dowels:** Screw cam bolts (E) into panels (3, 4, 5). Insert dowels (B) into panels (3, 4) and dowels (C) into panel (6).
2. **Attach Slider Arms:** Separate the slider bracket from the slider arm as per the diagram. Attach slider arms to panels (3, 4) with screws (S) correctly.
3. **Assemble Side Panels:** Attach panels (5) to panels (3, 4). Insert and secure cam locks (D) to lock them. Attach panels (3, 4) to panels (7, 16). Insert and secure cam locks (D) to lock them.
4. **Attach Back Panel:** Attach panel (2) to panels (3, 4) with screws (M) correctly.
5. **Install Legs:** Install the legs (8) to panel (2). Stick the Footpads (J) to legs (8).
6. **Insert Shelf Panel:** Stick stickers (X) on legs (8). Slide panel (15) into the designated area correctly.
7. **Prepare Door Panel:** Attach hinge-top (W) to panel (9) with screws (S) correctly. Attach part (P) to panel (9) with screws (S) correctly. Attach handles (H) to panel (9) with bolts (I) correctly.
8. **Attach Door:** Insert door shaft support (U) into panels (2, 7). Insert Hinge-bottom (V) to panel (2). Insert panel (9) to panel (2). Attach Hinge-bottom (V) to panel (2) with screws (S).
9. **Assemble Drawer Box:** Attach panels (11, 12) to panel (13) with screws (L) correctly. Carefully slide panel (14) into place along the bottom of the assembly.
10. **Attach Drawer Front:** Screw cam bolts (G) into panel (10). Attach handle (H) to panel (10) with bolts (I) correctly.
11. **Install Drawer:** Attach panel (10) to panels (11, 12). Insert and secure cam locks (F) to panels (11, 12) to lock it. Attach slider brackets to panels (11, 12) with screws (S) correctly. Assembled the drawers as per diagram.
12. **Install Charging Station:** Attach socket (Y) to panel (1) with screws (S) correctly.


## PRODUCT FEATURES

---

- **Integrated Charging Station:** Equipped with 2 standard AC outlets and 2 USB ports for convenient

charging of electronic devices.

- **Ample Storage:** Features a smooth-gliding drawer and a spacious storage cabinet with a magnetic door buckle to keep items organized and out of sight.
- **Durable Construction:** Made from high-quality, formaldehyde-free medium density fiberboard (MDF) with a waterproof wooden grain surface. The wood is FSC certified.
- **Elegant Design:** Modern farmhouse style with an oak body, distressed surface, and unique gourd-shaped iron legs. The top plate features a curved edge for enhanced safety.



*Convenient charging station on the tabletop.*



*Detailed view of the distressed surface finish.*



*Key features: gourd legs, certified MDF, and integrated power.*

## OPERATING THE CHARGING STATION

---

The integrated charging station allows you to power and charge your electronic devices conveniently.

1. Ensure the end table is properly assembled and the power cord is securely plugged into a functional wall outlet.
2. To charge devices, simply plug your device's power adapter into one of the two AC outlets or connect your USB cable directly to one of the two USB ports.
3. The charging station is designed for standard electronic devices such as lamps, mobile phones, tablets, and audio equipment.

## CARE AND MAINTENANCE

---

- **Cleaning:** Wipe the table surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent water damage, especially on the wooden grain surface.
- **Protection:** Consider using coasters under drinks and protective pads under hot items to preserve the tabletop's appearance.
- **Stability:** Periodically check all screws and connections to ensure they remain tight and secure. Retighten if necessary.

## TROUBLESHOOTING

---

- **Drawers or Cabinet Door Not Closing Smoothly:** Check that all drawer slides and hinges are correctly aligned and securely fastened. Ensure no obstructions are preventing smooth operation.
- **Wobbly Table:** Verify that all legs are securely attached and all assembly hardware is tightened. Ensure the table is placed on a flat, even surface.
- **Charging Station Not Working:** Confirm the power cord is fully plugged into both the table's unit and the wall outlet. Test the wall outlet with another device to ensure it is functional. If issues persist, contact customer support.

## PRODUCT SPECIFICATIONS

---

<b>Brand</b>	WAMPAT
<b>Model Name</b>	Scarlett
<b>Product Dimensions (D x W x H)</b>	23.6"D x 14.9"W x 22.9"H (60cm x 38cm x 58cm)
<b>Color</b>	Oak
<b>Top Material Type</b>	Oak Wood
<b>Frame Material</b>	Iron
<b>Number of Drawers</b>	1
<b>Number of Doors</b>	1
<b>Charging Station</b>	2 AC Outlets, 2 USB Ports
<b>Max Weight Capacity</b>	40 lbs (18 kg)

## Display Personality



*Detailed dimensions of the end table.*

## WARRANTY AND SUPPORT

WAMPAT provides lifetime service for this product. If you encounter any issues or have questions regarding your end table, please contact WAMPAT customer support for assistance. Keep your purchase receipt for warranty claims.