

[Manuals.plus](#) /

› [NOTABRICK](#) /

› NOTABRICK Bluetooth Speaker User Manual

## NOTABRICK Vi

# NOTABRICK Bluetooth Speaker User Manual

Brand: NOTABRICK | Model: Vi

## 1. INTRODUCTION

Thank you for choosing the NOTABRICK Bluetooth Speaker. This portable speaker delivers 30W stereo sound with vibrant RGB lighting, IPX7 waterproofing, and extended playtime. This manual provides detailed instructions to help you set up, operate, and maintain your speaker for optimal performance.

## 2. PRODUCT OVERVIEW



The NOTABRICK Bluetooth Speaker, showcasing its sleek gray design and illuminated speaker rings.




Speaker highlighting its RGB colorful light show feature with musical notes in the background.

## 2.1 Package Contents

- NOTABRICK Bluetooth Speaker (Model Vi)
- USB-C Charging Cable
- Auxiliary Audio Cable
- Lanyard Strap

## 2.2 Speaker Controls and Ports



Top panel showing Power ON/OFF, Volume/Previous Track, Play/Pause/Answer/Reject Phone, Volume/Next Track, and Light Button.



Side view revealing the USB-C charging port and AUX input, protected by a rubber flap.

The speaker features intuitive controls on its top surface, including power, volume, track navigation, play/pause, and a dedicated light button. A rubber flap on the side protects the USB-C charging port and AUX input, ensuring IPX7 waterproof integrity when closed.

## 3. SETUP

### 3.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and plug

the other end into a compatible USB power adapter (not included). The charging indicator light will show charging status (e.g., red for charging, off or green for full charge). A full charge takes approximately 4 hours.

### 3.2 Power On/Off

- To Power On: Press and hold the Power ON/OFF button (circle icon) for 2-3 seconds.
- To Power Off: Press and hold the Power ON/OFF button for 2-3 seconds again.

### 3.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a blinking blue light).
2. On your mobile device, enable Bluetooth and search for "NOTABRICK Vibe" in the list of available devices.
3. Select "NOTABRICK Vibe" to pair. Once connected, the speaker will indicate successful pairing (e.g., a solid blue light or an audible prompt).

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Audio Playback

- Play/Pause: Press the Play/Pause button (triangle icon) once.
- Volume Up: Press the "+" button.
- Volume Down: Press the "-" button.
- Next Track: Press and hold the "+" button.
- Previous Track: Press and hold the "-" button.

### 4.2 RGB Lighting Control

The speaker features a standalone RGB lighting system with 7 light colors and 6 light modes. Press the Light Button (sun icon) to cycle through different light modes and colors. Some modes sync with the music beat. Press and hold the Light Button to turn the lights off.



Speaker displaying vibrant blue and purple light patterns, enhancing the listening experience.



Illustration showing different light modes and colors available on the speaker.

### 4.3 TWS (True Wireless Stereo) Pairing

To achieve 360° immersive surround sound, you can pair two NOTABRICK speakers together. Power on both speakers. They will automatically attempt to pair with each other. Once paired, connect your device to one of the speakers via Bluetooth. Both speakers will then play audio in stereo. This function is supported in both Bluetooth and AUX modes.

### 4.4 Call Handling

The built-in microphone allows for hands-free calls. Press the Play/Pause button to answer or reject incoming calls. The speaker also supports Siri voice assistant activation with a single key press.

### 4.5 Auxiliary Input (AUX)

Connect an external audio device (e.g., MP3 player, laptop) to the speaker using the provided 3.5mm auxiliary audio cable. The speaker will automatically switch to AUX mode. Ensure the rubber flap covering the AUX port is securely closed when not in use to maintain waterproofing.

## 5. MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Waterproofing:** The speaker is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. Ensure all port covers are securely closed before exposing the speaker to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged.
- **No Sound:** Check if the speaker is paired correctly via Bluetooth or if the AUX cable is securely connected. Adjust the volume on both the speaker and your connected device.
- **Pairing Issues:** Ensure the speaker is in pairing mode. Turn off Bluetooth on other nearby devices to avoid interference. Try unpairing and re-pairing the speaker with your device.
- **Lights Not Working:** Press the Light Button to cycle through modes or turn them on. Ensure the speaker has sufficient battery.

## 7. SPECIFICATIONS

| Feature    | Specification |
|------------|---------------|
| Brand      | NOTABRICK     |
| Model Name | Vi            |

|                              |                                         |
|------------------------------|-----------------------------------------|
| Speaker Type                 | Outdoor                                 |
| Connectivity Technology      | Bluetooth 5.0                           |
| Speaker Maximum Output Power | 30 Watts                                |
| Battery Capacity             | 3600mAh                                 |
| Playtime                     | Up to 1000 minutes (approx. 16.6 hours) |
| Water Resistance Level       | IPX7 Waterproof                         |
| Product Dimensions           | 8.3"D x 2.7"W x 2.7"H                   |
| Item Weight                  | 1.43 pounds                             |
| UPC                          | 768795371742                            |

## 8. OFFICIAL PRODUCT VIDEOS

## 9. WARRANTY AND SUPPORT

Warranty and support information for this product is not available in the provided data. Please refer to the product packaging or the manufacturer’s official website for details.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

