

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BWE](#) /

› [BWE Shower Panel System BWEP07 User Manual: Installation and Operation Guide](#)

BWE BWEP07

BWE Shower Panel System BWEP07 User Manual

Model: BWEP07-Black

Brand: BWE

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your BWE 6-in-1 Stainless Steel Shower Panel System. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.

The BWE Shower Panel System features a comprehensive design for an enhanced showering experience, including multiple water outlets and a temperature display. It is constructed from high-grade 304 stainless steel for durability.

PRODUCT FEATURES

- **6-in-1 Functionality:** Enjoy rainfall shower, waterfall shower, four adjustable body jets, four mist sprays, a 3-setting handheld shower wand, and a waterfall tub spout.
- **Durable Construction:** Made from precision high-grade 304 stainless steel with a brass mixing valve and diverter valve.
- **Temperature Display:** An integrated digital screen displays the water temperature, allowing for precise adjustment and reduced scalding risk. (Note: Requires battery, not included).
- **Adjustable Body Jets:** Four powerful, angle-adjustable brass body jets provide a hydro-massage experience for the neck and back.
- **Versatile Handheld Shower:** The 3-function handheld shower wand offers flexibility for various tasks, such as rinsing shower walls or specific body areas.
- **Waterfall Tub Spout:** Convenient for filling tubs or buckets.




Figure 1: Overview of the BWE Shower Panel System with labeled components.

SETUP AND INSTALLATION

1. Pre-Installation Checks

- Ensure all components listed in the packaging are present and undamaged. Refer to the components image below.
- Verify that your wall structure can support the weight of the shower panel and that plumbing connections are accessible.
- Confirm water pressure is within recommended limits for optimal performance.



Figure 2: Included components for the BWE Shower Panel System.

2. Mounting the Shower Panel

- Measure and mark the desired mounting height on the wall. Refer to the product dimensions for accurate placement.
- Install the mounting brackets securely to the wall using appropriate hardware for your wall type.
- Ensure the panel is level before tightening all mounting screws.






Figure 3: Product dimensions for installation planning.

3. Water Line Connections

- Connect the hot and cold water supply lines to the corresponding inlets on the back of the shower panel. Use thread sealant tape for a watertight connection.
- Carefully attach the panel to the installed mounting brackets.

4. Temperature Display Battery Installation

- Locate the battery compartment for the temperature display.
- Insert the required batteries (not included) according to the polarity markings.



Figure 4: Temperature display and battery requirement.

OPERATING INSTRUCTIONS

1. Water Flow and Temperature Control

- The main knob controls the water flow and temperature. Rotate it to adjust the desired temperature (hot/cold).
- The digital display will show the current water temperature.



Figure 5: Adjusting the control knob for water temperature and flow.

2. Function Selection

- Use the function diverter knob to switch between the six different shower modes: rainfall, waterfall, body jets, mist sprays, handheld shower, and tub spout.
- Only one function can be active at a time to ensure optimal water pressure.



Figure 6: Various shower functions in operation.

3. Handheld Shower Operation

- Select the handheld shower function using the diverter.
- The handheld wand offers three spray settings, which can be changed by rotating the shower head or pressing a button, depending on the specific model.




Figure 7: Handheld shower spray patterns.

4. Body Jet Usage

- Activate the body jet function via the diverter.
- The four body jets are adjustable; gently pivot them to direct the water flow for a targeted massage.



Figure 8: Body jets in action.

MAINTENANCE

1. Cleaning

- Regularly clean the stainless steel surface with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for stainless steel.
- Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.
- For shower nozzles (rainfall, handheld, body jets), gently rub the rubber nozzles to dislodge any mineral buildup.

2. Temperature Display Battery Replacement

- If the temperature display becomes dim or stops working, replace the batteries.
- Access the battery compartment, typically located on the side or back of the display unit.
- Ensure correct battery type and polarity during replacement.

TROUBLESHOOTING

- **No Water Flow or Low Pressure:** Check that both hot and cold water supply valves are fully open. Ensure no blockages in the water lines or shower head nozzles. Verify household water pressure is adequate.
- **Temperature Display Not Working:** Confirm batteries are installed correctly and are not depleted. Replace batteries if necessary.
- **Leaking:** Check all connections for tightness. Ensure O-rings and gaskets are properly seated. If leaks persist, professional plumbing assistance may be required.
- **Difficulty Switching Functions:** Ensure the diverter knob is fully engaged in each position. Do not force the knob if it feels stiff.


SPECIFICATIONS

Feature	Specification
Brand	BWE
Model Number	BWEP07-Black
Color	Matte Black
Material	Stainless Steel (Panel), Brass (Handle)
Finish Type	Matte
Number of Handles	1
Mounting Type	Wall Mount
Item Weight	24 pounds (10.9 Kilograms)
Product Dimensions	10.23 x 8.66 x 51.57 inches
Included Components	Shower Head, Shower Panel, Valve
Batteries Required?	Yes (for temperature display, not included)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official BWE website. Keep your proof of purchase for warranty claims.

© 2023 BWE. All rights reserved.




[BWE Shower Panel System Installation and Mounting Guide](#)

Comprehensive instructions for installing and mounting a BWE shower panel system, including component lists, step-by-step installation procedures, and essential safety warnings.




[Indesit BWE 91484 Washing Machine: User Manual and Guide](#)

Comprehensive user manual for the Indesit BWE 91484 washing machine, detailing installation, operation, maintenance, troubleshooting, and care.



[BWE 6090 Single-Handle Lavatory Faucet Specifications and Installation Guide](#)

Detailed specifications, installation instructions, and daily maintenance tips for the BWE 6090 single-handle lavatory faucet. Learn about dimensions, sink compatibility, and proper care for your bathroom fixture.




[Washing Machine Safety and Installation Guide](#)

Comprehensive guide to the safe installation, operation, and maintenance of your washing machine, covering important safety warnings, permitted use, installation steps, electrical safety, and disposal.



[Basement Watchdog Emergency Battery Backup Sump Pump System \(Model BWE\) - Instruction Manual & Safety Warnings](#)

This manual provides essential safety warnings, operating instructions, installation guides, and troubleshooting tips for the Basement Watchdog Emergency Battery Backup Sump Pump System, Model BWE. Learn how to properly install, maintain, and operate your sump pump system to protect your home from water damage.



[Indesit Washing Machine User Manual: Operation and Maintenance](#)

Comprehensive user manual for the Indesit washing machine, covering control panel functions, wash cycle details, product description, detergent dispenser usage, troubleshooting, and maintenance tips.