

ALISENED 1213

ALISENED Computer Desk Model 1213 Instruction Manual

Model: 1213 | Brand: ALISENED

1. INTRODUCTION

Thank you for choosing the ALISENED Computer Desk Model 1213. This compact and versatile desk is designed to optimize your workspace in small areas, offering integrated storage, a monitor stand, a keyboard tray, and a CPU stand. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Keep this manual for future reference.

- **Assembly:** Always assemble according to the instructions provided. Ensure all screws and fasteners are tightened securely before use.
- **Stability:** For added stability, consider anchoring the desk to the wall, especially if it will be used by children or in a high-traffic area.
- **Weight Capacity:** Do not exceed the recommended weight capacity for any part of the desk. Distribute weight evenly across surfaces.
- **Placement:** Place the desk on a flat, stable surface. Avoid placing it in direct sunlight or near heat sources to prevent material damage.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present. If any parts are missing or damaged, please contact ALISENED customer support.

- Desk panels (various sizes for desktop, shelves, and supports)
- Metal frame components
- Keyboard tray and slides
- CPU stand components

- Monitor stand components
- All necessary screws, bolts, and fasteners
- Assembly tools (e.g., Allen wrench, screwdriver)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is straightforward. We recommend having a clear, spacious area for assembly. Follow the steps carefully.

Assembly Video Guide

Video Description: This video provides a step-by-step visual guide for assembling the ALISENED Computer Desk. It demonstrates connecting frame components, attaching adjustable feet, fixing shelves, installing the power outlet, and assembling the keyboard tray and drawer. Follow along for a smooth assembly process.

Step-by-Step Assembly

1. **Prepare Components:** Unpack all parts and lay them out. Identify each piece using the labels (A, B, C, etc.) and hardware (screws 1, 2, etc.) as shown in the instructions.
2. **Assemble the Main Frame:** Connect the primary metal frame pieces (e.g., A, B, C, D) using the designated screws. Ensure all connections are firm.
3. **Attach Adjustable Feet:** Install the adjustable feet onto the bottom of the main frame legs. These help stabilize the desk on uneven surfaces.
4. **Construct Side Shelves:** Assemble the vertical and horizontal supports for the side shelves (e.g., F, G, J) using the appropriate screws.
5. **Install Mesh Panel:** Secure the mesh panel (K) between the frame sections as indicated in the manual.
6. **Attach Desk Boards:** Carefully fix the main desktop and shelf boards (R, O, Q) to the assembled frame using screws. It is often easier to place the boards on the floor and assemble the frame upside down, then flip it over.
7. **Install Power Outlet:** Fix the power outlet unit (O) onto the designated flat top section using screws.
8. **Assemble Keyboard Tray:** Attach the keyboard tray slides to the underside of the main desktop and then install the keyboard tray (P).
9. **Attach Headphone Hooks:** Fix the headphone hooks (I) to the side frame using the round-head screws.
10. **Assemble Drawer:** Construct the fabric drawer and insert it into its designated slot.

PRODUCT DIMENSIONS




Image Description: Detailed diagram showing the product dimensions of the ALISENED Computer Desk, including measurements for the desktop, monitor stand, keyboard tray, and side shelves. Dimensions are provided in both inches and centimeters.

5. OPERATING INSTRUCTIONS (USAGE)

The ALISENED Computer Desk is designed for versatile use in various settings, including home offices, bedrooms, and study areas.

- **Desktop:** Provides ample space for a laptop, monitor, and other essential work items.
- **Monitor Stand:** Elevates your monitor to an ergonomic height, reducing neck and eye strain. It can also serve as an additional storage shelf.
- **Keyboard Tray:** A pull-out tray keeps your keyboard and mouse neatly tucked away when not in use, maximizing desktop space.
- **Storage Shelves:** Multiple side shelves offer convenient storage for books, documents, office supplies, or decorative items.
- **CPU Stand:** A dedicated space for your computer tower helps keep it off the floor, protecting it from dust and improving airflow.
- **Power Outlets:** Integrated power outlets (2*AC, 1*USB-C, 1*USB) provide convenient charging for your devices directly on the desk.

- **Headphone Hooks:** Keep your headphones within easy reach and off the desk surface.

Product Features Overview

Video Description: This video highlights the main features of the ALISENED Computer Desk, including its compact design, monitor stand, keyboard tray, storage shelves, CPU stand, and integrated power outlets. It showcases how these features contribute to an organized and efficient workspace.



Image Description: The ALISENED Computer Desk is shown in a modern home office setup, featuring a monitor, laptop, keyboard, and various office accessories. The integrated shelves and monitor stand help keep the workspace organized and clutter-free.

6. MAINTENANCE

To ensure the longevity and appearance of your ALISENED Computer Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Tighten Fasteners:** Periodically check all screws and bolts and tighten them if necessary to maintain stability.

- **Avoid Overloading:** Do not place excessively heavy items on the shelves or desktop to prevent structural damage.
- **Protect Surfaces:** Use coasters for drinks and mouse pads for computer peripherals to protect the desktop from scratches and moisture.

7. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**
Solution: Ensure all screws and bolts are securely tightened. Check that the adjustable feet are properly installed and adjusted to compensate for uneven flooring.
- **Parts Don't Align During Assembly:**
Solution: Double-check the orientation of each piece against the instruction diagrams. Sometimes, a piece may appear similar but needs to be rotated or flipped. Do not force parts together; disassemble and re-align.
- **Keyboard Tray Not Sliding Smoothly:**
Solution: Ensure the slides are correctly installed and free of obstructions. Check for any misaligned screws or debris in the tracks.
- **Missing Hardware:**
Solution: Carefully re-check the packaging. If hardware is genuinely missing, contact ALISENED customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	ALISENED
Model Number	1213
Product Dimensions (D x W x H)	17.7"D x 29.5"W x 30"H (75 x 45 x 76 cm)
Color	Black
Material Type	Engineered Wood
Special Features	Keyboard Tray Included, Monitor Stand, Storage Shelves, CPU Stand
Number of Shelves	3
Required Assembly	Yes
Item Weight	20 Pounds

9. WARRANTY AND SUPPORT

The ALISENED Computer Desk Model 1213 comes with a Limited Warranty.

- **Warranty Coverage:** The limited warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.
- **Exclusions:** The warranty does not cover damage resulting from improper assembly, misuse, accidents, or unauthorized modifications.
- **Customer Support:** For any questions, missing parts, or warranty inquiries, please contact ALISENED

customer support through the retailer where the product was purchased.