

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KKT KOLBE](#) /

› [KKT KOLBE EBM8018S Built-in Microwave Oven User Manual](#)

KKT KOLBE EBM8018S

KKT KOLBE EBM8018S Built-in Microwave Oven User Manual

Model: EBM8018S | Brand: KKT KOLBE

1. INTRODUCTION

Thank you for choosing the KKT KOLBE EBM8018S Built-in Microwave Oven. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before installation and operation, and keep them for future reference.



Image: A family observing the KKT KOLBE EBM8018S built-in microwave oven.

2. SAFETY INSTRUCTIONS

Always adhere to basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, burns, or injury. This appliance is equipped with a child safety lock to prevent unintended operation by children.

- Ensure the appliance is properly grounded before use.
- Do not operate the oven if the door or door seals are damaged.
- Only qualified personnel should perform servicing or repairs.
- Keep children away from the appliance during operation and when it is cooling down.

- Use oven mitts when handling hot dishes or accessories.

3. SETUP AND INSTALLATION

3.1 Unpacking and Inspection

Carefully remove the appliance from its packaging. Inspect for any damage during transit. Report any damage to your supplier immediately.

3.2 Installation Requirements

The KKT KOLBE EBM8018S is designed for built-in installation and operates autonomously. Ensure the installation cabinet meets the required dimensions for proper ventilation and safe operation.




Image: Installation dimensions for the EBM8018S built-in microwave oven.

Refer to the diagram above for precise measurements. Minimum cabinet dimensions are crucial for proper fit and ventilation. The appliance dimensions are approximately 54.6 x 59.5 x 59.6 cm (Depth x Width x Height).

3.3 Electrical Connection

The appliance comes with a pre-assembled Schuko plug. Ensure the electrical outlet is easily accessible after installation and that the power supply matches the appliance's requirements (2.88kW, 2880 watts).

3.4 Delivery Information

Delivery is curbside by a carrier; the appliance will not be brought into your apartment. The carrier will notify you of the delivery date via email.



Image: KKT KOLBE EBM8018S installed in a kitchen.

4. OPERATING INSTRUCTIONS

4.1 Control Panel - TouchSelect

The appliance features intuitive TouchSelect sensor controls for quick and easy operation. The large and bright LCD display provides all current status information at a glance.



Image: TouchSelect sensor control panel.

4.2 Cooking Functions

The EBM8018S offers a variety of cooking modes to suit your needs:

- **Microwave:** For rapid heating and cooking.
- **Grill:** Ideal for browning and crisping dishes.
- **Convection / Hot Air:** Ensures even cooking and baking results.
- **Pizza Function:** Specifically designed for recipes with moist toppings and crispy dough, such as pizzas, quiches, and tarts.
- **Defrost Function:** Gently and quickly thaws frozen food.
- **EcoCook Grill-Roast System:** Excellent for grilling and roasting large cuts of meat at low temperatures, or for gratinating.
- **Accelerated Preheating:** Reduces warm-up time, saving energy and time.



Image: Oven interior with function icons.

4.3 Child Safety Lock

To activate or deactivate the child safety lock, refer to the specific instructions in the full manual. This feature prevents accidental operation, ensuring safety in households with children.



Image: KKT KOLBE EBM8018S in a kitchen setting.

5. MAINTENANCE AND CLEANING

5.1 Steam-Clean System

The EBM8018S features a Steam-Clean system for easy maintenance. This system softens dirt and food residues with steam, making them simple to wipe away.

Easyclean 2.0



Image: Easyclean 2.0 Steam-Clean system steps.

5.2 General Cleaning

For general cleaning, use a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could damage the appliance's surfaces. Ensure the appliance is cool before cleaning.




Image: Included accessories: baking tray, grill rack, and sponge.

6. TROUBLESHOOTING

If your appliance is not functioning correctly, please check the following common issues before contacting customer service:

- **Appliance does not turn on:** Check if the power plug is securely inserted and if there is power to the outlet.
- **Food not heating:** Ensure the door is fully closed and the correct cooking mode and time are selected.
- **Display not working:** Check power supply. If the issue persists, contact support.

For more complex issues, refer to the comprehensive troubleshooting guide in the full product manual or contact KKT KOLBE customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
---------	---------------

Brand	KKT KOLBE
Model Number	EBM8018S
Product Dimensions (D x W x H)	54.6 x 59.5 x 59.6 cm
Item Weight	45 kg
Capacity	72 Liters
Wattage	2880 Watts
Installation Type	Built-in
Fuel Type	Electric
Heating Method	Convection
Color	Black
Finish Type	Black
First Available Date	October 18, 2019

8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, service requests, or technical support, please refer to the warranty card included with your appliance or visit the official KKT KOLBE website. Keep your purchase receipt as proof of purchase.

KKT KOLBE is committed to providing top service and quality products. Should you encounter any issues, their in-house workshop can respond quickly and effectively.