

[Manuals.plus](#) /

› [Boyel Living](#) /

› Boyel Living Touchless Kitchen Faucet with Pull Down Sprayer (Model BL-APS175TL-BTG) - User Manual

Boyel Living BL-APS175TL-BTG

Boyel Living Touchless Kitchen Faucet with Pull Down Sprayer

Model: BL-APS175TL-BTG

INTRODUCTION

This manual provides instructions for the installation, operation, maintenance, and troubleshooting of your Boyel Living Touchless Kitchen Faucet with Pull Down Sprayer, Model BL-APS175TL-BTG. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.

SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use harsh chemicals or abrasive cleaners on the faucet finish.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

PACKING LIST



Image: Contents of the Boyel Living Touchless Kitchen Faucet package, including the faucet body, control box, hot and cold water supply hoses, pull-down hose, mounting hardware, and deck plate.

- Faucet Body with Pull-Down Sprayer
- Control Box (for touchless function)
- Hot and Cold Water Supply Hoses
- Pull-Down Hose with Weight
- Mounting Hardware (nuts, washers, gaskets)
- Deck Plate (for 3-hole installations)
- Instruction Manual

SPECIFICATIONS

Feature	Detail
Brand	Boyel Living
Model Name	BL-APS175TL-BTG
Mounting Type	Deck Mount
Finish Type	Brushed Gold
Material	Stainless Steel
Number of Handles	1
Hole Count	1 or 3 (with deck plate)
Special Feature	Pull Down Sprayer, Touchless Sensor
Installation Type	Widespread
Item Weight	7.33 pounds
Product Dimensions	24.8 x 12.2 x 4.13 inches
Certification	cUPC Certified



Image: Detailed dimensions of the faucet for installation planning.

SETUP AND INSTALLATION

This section provides a general overview of the installation process. For detailed, step-by-step instructions, please refer to the dedicated installation guide included with your product. Professional installation is recommended if you are unfamiliar with plumbing procedures.

Before You Begin

- Ensure you have all necessary tools (e.g., adjustable wrench, screwdriver, plumber's putty or silicone sealant).
- Turn off the water supply to the sink at the shut-off valves.
- Clear the area under the sink for easy access.

General Installation Steps

1. **Prepare the Sink Hole:** If installing on a 3-hole sink, place the deck plate over the holes. For a 1-hole sink, the deck plate is optional.
2. **Mount the Faucet:** Insert the faucet body through the sink hole(s). Secure it from underneath the sink using the provided washer and mounting nut.

3. **Connect Water Supply Lines:** Attach the hot and cold water supply hoses from the faucet to your home's water supply lines. Ensure connections are tight to prevent leaks.
4. **Install the Control Box:** Mount the control box in an accessible location under the sink. Connect the faucet's sensor cable and the water supply lines to the control box as per the detailed guide.
5. **Install the Pull-Down Hose and Weight:** Connect the pull-down sprayer hose to the control box. Attach the weight to the pull-down hose at the specified location to ensure proper retraction.
6. **Power Connection:** Connect the power supply to the control box (batteries or AC adapter, if applicable and provided).
7. **Test for Leaks:** Turn on the main water supply slowly and check all connections for leaks.

OPERATING INSTRUCTIONS

Touchless Operation



Image: Activating the touchless sensor for water flow.

- The faucet features an infrared sensor for touchless activation.
- To turn the water on, wave your hand within the sensor's detection range (typically a few inches in front

of the sensor located at the base of the faucet).

- To turn the water off, wave your hand in front of the sensor again.
- The handle controls water temperature and can be used to manually operate the faucet if desired.

3-Function Pull-Down Sprayer

3 SPRAY PATTERNS



Press the button to change modes



Image: Visual representation of the three spray modes: Sweep, Stream, and Spray.

- The pull-down sprayer offers three distinct water modes: Stream, Spray, and Sweep.
- Press the button on the sprayer head to cycle through these modes.
- The pull-down hose extends for increased reach and retracts automatically when released, thanks to the hose weight.



Image: The 59-inch pull-down hose provides extended reach for various tasks.

MAINTENANCE AND CLEANING

General Cleaning

- Clean the faucet regularly with a soft cloth and mild soap or a non-abrasive cleaner.
- Rinse thoroughly with water and dry with a soft cloth to maintain the brushed gold finish.
- Avoid using abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish and internal components.

Nozzle Cleaning

- The sprayer nozzle features soft rubber holes designed for easy cleaning.
- To remove mineral buildup, gently rub the rubber nozzles with your finger or a soft brush.

TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water flow or low pressure	Water supply turned off; clogged aerator; kinked hose; sensor malfunction.	Check water supply valves; clean aerator; straighten hose; check sensor power/function.
Faucet leaks from connections	Loose connections; damaged O-rings/gaskets.	Tighten connections; replace O-rings/gaskets if damaged.
Touchless sensor not responding	Sensor obstructed; low battery (if applicable); power issue; sensor dirty.	Clear obstructions; replace batteries; check power connection; clean sensor window.
Sprayer not retracting fully	Hose weight improperly positioned or obstructed.	Adjust hose weight position; clear any obstructions under the sink.

If the problem persists after attempting these solutions, please contact customer support.

WARRANTY AND CUSTOMER SUPPORT

Warranty Information

Boyel Living products are manufactured to high-quality standards. For specific warranty details regarding your BL-APS175TL-BTG faucet, please refer to the warranty card included in your package or visit the official Boyel Living website.

Customer Support

For assistance with defective, wrong, or damaged items, or if you receive an incomplete order or missing parts, please contact Boyel Living customer service immediately. Provide appropriate pictures to illustrate the issue. We recommend inspecting items within 48 hours of receipt and reporting any such issues as soon as possible.

For further support, please visit the [Boyel Living Store on Amazon](#).