Holy Stone HS600

Holy Stone HS600 2-Axis Gimbal Drone User Manual

Brand: **Holy Stone** | Model: **HS600**

Introduction

Welcome to the comprehensive user manual for your Holy Stone HS600 2-Axis Gimbal Drone. This guide provides essential information for setup, operation, maintenance, and troubleshooting to ensure a safe and enjoyable flying experience. The HS600 is equipped with a 4K EIS camera, integrated Remote ID for FAA compliance, and powerful features designed for both beginners and experienced pilots.



Figure 1: Holy Stone HS600 Drone and included accessories.

Setup

1. Unboxing and Initial Inspection

Carefully unpack all components and verify that all items listed in the 'What's in the Box' section are present and undamaged. The package includes the Holy Stone HS600 GPS 4K Drone, Transmitter, Drone Battery (x1), Blade set, and a Portable Bag.



Figure 2: All components included in the Holy Stone HS600 package.

2. Battery Charging

Ensure both the drone battery and the remote controller are fully charged before first use. The drone battery is a 2500mAh Lithium Polymer battery. Use the provided USB-C charging cables. A full charge is indicated by solid blue lights on the battery.



Figure 3: Charging the drone battery.

3. Drone Preparation

1. **Unfold the Drone:** Carefully unfold the drone arms and landing gear.
2. **Remove Gimbal Protector:** Before flight, remove the gimbal protector from the camera.
3. **Insert SD Card:** (Optional, but recommended for recording) Insert a micro SD card into the designated slot on the drone.
4. **Insert Battery:** Slide the fully charged battery into the drone until it clicks securely into place.
5. **Power On Drone:** Press and hold the power button on the drone battery for 3 seconds until you hear a chime and the LED lights begin flashing.

4. Controller and App Setup

1. **Power On Controller:** Double-click the power button on the remote controller to turn it on.
2. **Download HS Fly App:** Scan the QR code in the physical user manual or search for

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question