

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HURRISE](#) /

› [HURRISE Portable Coffee Machine User Manual](#)

HURRISE hu201

HURRISE Portable Coffee Machine User Manual

Model: hu201

INTRODUCTION

Welcome to the user manual for your HURRISE Portable Coffee Machine. This device is designed for convenience, allowing you to enjoy fresh coffee from K-Cup capsules or ground coffee wherever you are. Its compact and rechargeable design makes it ideal for travel, camping, hiking, and daily use at home or office.

IMPORTANT SAFETY INFORMATION

- Always use **boiling water** with this machine. The device does not heat water.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Use only the provided Type-C charging cable.
- Ensure all components are properly assembled before operation.
- Avoid touching hot surfaces immediately after brewing.

PRODUCT OVERVIEW AND COMPONENTS

Your HURRISE Portable Coffee Machine comes with the following components:

- Portable Coffee Machine Unit
- Coffee Powder Basket
- Capsule Adapter
- Type-C Charging Cable

- Coffee Scoop
- Storage Bag



Image: The portable coffee machine shown with its included accessories: a storage bag, a coffee scoop, and a Type-C charging cable.



Image: The HURRISE Portable Coffee Machine displayed alongside a pile of ground coffee, two coffee capsules, and a glass of freshly brewed espresso.

SETUP AND CHARGING

Before first use, ensure the device is fully charged.

1. Connect the provided Type-C charging cable to the charging port on the machine.
2. Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, power bank, car charger).
3. The indicator lights will show charging status. A full charge provides approximately 50 cups of coffee.

1200MAH LARGE CAPACITY BATTERY



Type-C
Charging



Connect
Power Bank



Connect
Car Charger



Image: The portable coffee machine being charged via a Type-C cable, with icons indicating compatibility with power banks and car chargers, surrounded by coffee beans.

OPERATING INSTRUCTIONS

Preparing Coffee with K-Cup Capsules

1. Separate the top section of the coffee machine from the base.
2. Insert a K-Cup capsule into the capsule adapter.
3. Place the capsule adapter with the K-Cup into the designated slot in the machine's brewing chamber.
4. Reattach the top section to the base, ensuring it is securely mounted.
5. Open the water tank lid and carefully pour **boiling water** (up to 5.75 oz / 170ml) into the water tank.
6. Press the power button once to turn on the machine (blue indicator light will show).
7. Press the power button again to start the extraction process.
8. Once brewing is complete, remove the coffee cup and enjoy.

Preparing Coffee with Ground Coffee

1. Separate the top section of the coffee machine from the base.
2. Fill the coffee powder basket with up to 10g of ground coffee.
3. Place the filled coffee powder basket into the designated slot in the machine's brewing chamber.
4. Reattach the top section to the base, ensuring it is securely mounted.
5. Open the water tank lid and carefully pour **boiling water** (up to 5.75 oz / 170ml) into the water tank.
6. Press the power button once to turn on the machine (blue indicator light will show).
7. Press the power button again to start the extraction process.
8. Once brewing is complete, remove the coffee cup and enjoy.

Note: This machine does not heat water. Always add pre-boiled water for hot coffee.



Add capsules or ground coffee



base mount



add Hot water



Extracted coffee

Image: A four-panel illustration demonstrating the coffee brewing process: 1) Adding capsules or ground coffee, 2) Mounting the base, 3) Adding hot water, and 4) Extracted coffee pouring into a cup.

Simple to Operate

Refer to our video demonstration
on how to make coffee



Image: A three-step diagram illustrating how to assemble the portable coffee machine for use with either ground coffee (left) or K-Cup capsules (middle), and how to fill the ground coffee basket (right).

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your coffee machine.

1. After each use, disassemble the brewing chamber, coffee powder basket, and capsule adapter.
2. Rinse all removable parts under running water. Use a mild detergent if necessary.
3. Wipe the main unit with a damp cloth. **Do not submerge the main unit in water.**
4. Allow all parts to air dry completely before reassembling or storing.
5. For deep cleaning, periodically run a cycle with clean water only to flush out any residue.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Battery is low or depleted.	Charge the machine using the provided Type-C cable.
Coffee is cold.	Cold water was used.	Always use pre-boiled, hot water for brewing. The machine does not heat water.
No coffee dispenses or flow is very slow.	Coffee grounds too fine or too much coffee; capsule not properly punctured; machine clogged.	Ensure coffee grounds are suitable for espresso. Check capsule placement. Clean the brewing chamber thoroughly.
Leaking during operation.	Components not assembled correctly; seals are dirty or damaged.	Ensure all parts are securely tightened. Clean or inspect seals for damage.

SPECIFICATIONS

- **Brand:** HURRISE
- **Model Name:** K Cup Capsules & Ground Coffee (hu201)
- **Color:** Black
- **Product Dimensions:** 2.95"D x 2.95"W x 9.64"H
- **Item Weight:** 1.18 pounds
- **Coffee Input Type:** K Cup capsules, ground coffee
- **Operation Mode:** Manual (with electric pump)
- **Battery Capacity:** 1200mAh (Rechargeable via Type-C)
- **Water Tank Capacity:** 5.75 oz (170ml)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact HURRISE customer service directly. Keep your purchase receipt for warranty claims.

USAGE SCENARIOS



About Life, About Coffee



Image: A collage showing the portable coffee machine being used in different environments: an office, during travel, while camping, and inside a car, highlighting its versatility.

LIGHT, PORTABLE AND IN ONE HAND

1 CHARGE
Endurance 50 cups

BUILT-IN LITHIUM BATTERY



Image: A hand holding the HURRISE Portable Coffee Machine, emphasizing its light and portable design, with text indicating "1 Charge Endurance 50 cups" and "Built-in Lithium Battery".