

IMOURLIVE DLJ08

IMOURLIVE 8-Inch Mini Chainsaw User Manual

Model: DLJ08 | Brand: IMOURLIVE

INTRODUCTION

The IMOURLIVE 8-inch Mini Chainsaw is a lightweight, cordless, and compact electric chainsaw powered by a brushless motor. Designed for easy use in tree trimming, wood cutting, and general gardening tasks, it features an auto-oiling system and comes with two 21V 3.0Ah lithium-ion batteries for extended outdoor use. This powerful and portable tool offers low noise operation and enhanced safety features.

SAFETY INFORMATION

- **Always wear appropriate personal protective equipment (PPE)** including safety goggles, gloves, and sturdy footwear when operating the chainsaw.
- **Ensure the safety button is pressed** before activating the chainsaw switch to prevent accidental starts.
- **Keep hands and body clear** of the chain and guide bar during operation.
- **Maintain a firm grip** on the chainsaw with both hands.
- **Do not operate the chainsaw in wet conditions** or near flammable liquids/gases.
- **Regularly check chain tension and lubrication** to ensure safe and efficient operation.
- **Store the chainsaw and batteries in a dry, secure location** away from children.

COMPONENTS AND WHAT'S IN THE BOX

Your IMOURLIVE Mini Chainsaw package includes the following items:

- IMOURLIVE 8-inch Mini Chainsaw Unit
- 2 x 21V 3.0Ah Lithium-Ion Batteries
- Battery Charger (with dual ports for simultaneous charging)
- Safety Goggles

- Screwdriver (flathead and Phillips)
- Chain Tensioning Wrench
- Brush for cleaning sawdust
- Small Funnel for oiling
- Extra Cap for oil reservoir
- Carrying Case



Figure 1: Complete IMOUMLIVE Mini Chainsaw kit contents.



Brushless motor



Long-lasting Life ✓
Stay sturdy & stable all the time



Avoid Overheating ✓
Runs cooler for higher efficiency



Stronger Power Output ✓
Brushless motor delivers more power than normal motor



Highly Reliable ✓
Low noise and more power-saving

VS



Pure Copper Motor



Short Life ✗
Can only be used for 30-40 hours



Snatchy Use ✗
Overheat fast, need to cool down before use again



Power fatigue ✗
Unable to cut hard and dry wood



Unreliable ✗
Sparks and fumes would come out causing potential risks

Other Brand

Figure 2: Side view of the chainsaw highlighting the battery and handle.



Figure 3: Close-up of the auto-oiling system with oil being added.

SETUP AND ASSEMBLY

1. **Battery Installation:** Ensure batteries are fully charged and properly inserted. Align the battery with the slot at the base of the chainsaw handle and slide it in until it clicks securely into place.
2. **Handle/Guard Attachment:** The chainsaw comes with a protective guard and an auxiliary handle. Attach these components using the provided screws and screwdriver.
3. **Chain Tensioning:** Use the included wrench to adjust the chain tension. The ideal tension allows for about 3mm of slack. Turn the tensioner knob clockwise to tighten and counter-clockwise to loosen.
4. **Oiling System Setup:** Unscrew the cap of the oil reservoir. Use the small funnel to fill the reservoir with appropriate chainsaw bar oil (oil not included). Replace the cap securely. Periodically pump the clear bulb to ensure continuous lubrication of the chain, which extends chain and battery life.

Your browser does not support the video tag.

Video 1: Official IMOURLIVE video demonstrating the 8-inch mini chainsaw in use.

OPERATING INSTRUCTIONS

1. **Starting the Chainsaw:** Press the safety button located on the handle with your thumb, then

squeeze the trigger to start the chainsaw. The brushless motor ensures a smooth, low-noise start.

2. **Cutting Techniques:**

- For tree trimming and wood cutting, apply steady, even pressure.
- Allow the chainsaw to do the work; do not force it through the material.
- Be mindful of kickback and maintain a stable stance.

3. **Auto-Oiling System:** The chainsaw features an upgraded auto-oiling system. Periodically check the oil level and pump the clear bulb to ensure continuous lubrication of the chain, which extends chain and battery life.

4. **Stopping the Chainsaw:** Release the trigger to stop the chainsaw.

Your browser does not support the video tag.

Video 2: Official IMOURLIVE video demonstrating the 8-inch mini chainsaw in various cutting tasks.

MAINTENANCE

- **Cleaning:** After each use, clean sawdust and debris from the chainsaw using the provided brush. Ensure the guide bar and chain are free of obstructions.
- **Chain Sharpening:** Use the included file sharpener to maintain the sharpness of the chain. A sharp chain ensures efficient cutting and reduces strain on the motor.
- **Battery Care:** Store batteries in a cool, dry place. Charge batteries fully before extended storage. The 21V 3.0Ah batteries are fast-charging and designed for long life.

TROUBLESHOOTING

- **Chainsaw not starting:**
 - Ensure the battery is fully charged and properly inserted.
 - Verify the safety button is fully pressed before squeezing the trigger.
- **Chain not cutting efficiently:**
 - Check chain tension and adjust if too loose or too tight.
 - Sharpen the chain if it appears dull.
 - Ensure the auto-oiling system is functioning and the reservoir is filled.
- **Excessive noise or vibration:**
 - Check for loose components or debris in the chain/guide bar area.
 - Ensure the chain is properly seated on the guide bar.

SPECIFICATIONS

Feature	Detail
Brand	IMOURLIVE
Model Number	DLJ08

Power Source	Battery Powered
Horsepower	900 Watts
Item Weight	4 Pounds
Product Dimensions	18"L x 6.6"W x 5.5"H
Chain Length	8 Inches
Battery Type	21V 3.0Ah Lithium Ion (2 included)
Motor Type	Brushless
UPC	850039333545

WARRANTY AND SUPPORT

The IMOURLIVE Mini Chainsaw comes with a **one-year manufacturer's warranty**. For any customer service inquiries, returns, or exchanges within this period, please refer to your purchase documentation or contact IMOURLIVE customer support directly.

For additional support, you may refer to the official [User Manual \(PDF\)](#).