

[Manuals.plus](#) /

› [COSTWAY](#) /

› COSTWAY Patio Rattan Lounge Chair User Manual

## COSTWAY Patio Rattan Lounge Chair

# COSTWAY Patio Rattan Lounge Chair User Manual

Model: Patio Rattan Lounge Chair

### IMPORTANT SAFETY INFORMATION

---

**WARNING: MAXIMUM WEIGHT CAPACITY: 360 lbs. DO NOT EXCEED. ADJUST POSITIONS CAREFULLY TO AVOID INJURY.**

Please read this manual thoroughly before assembly and use. Keep these instructions for future reference.

### PRODUCT OVERVIEW

---

The COSTWAY Patio Rattan Lounge Chair is designed for outdoor relaxation, featuring a durable rattan construction and an adjustable backrest for customized comfort. It is suitable for various outdoor settings such as patios, decks, backyards, and poolside areas.



Figure 1: The COSTWAY Patio Rattan Lounge Chair, featuring a brown rattan frame and a comfortable beige cushion.

### Key Features:

- **Sturdy Woven Rattan Construction:** Crafted with weather-resistant woven rattan material, durable and resistant to dampness and deformation.
- **6 Adjustable Reclining Positions:** Backrest can be easily adjusted from flat to sitting up, offering versatile comfort for reading, sleeping, or sunbathing.
- **Removable & Thick Padded Cushion:** Includes a comfortable cushion filled with thick, soft sponge. The cushion is removable, and its cover has a zipper for easy cleaning.
- **Ergonomic Design:** High backrests, soft cushions, and spacious seats are designed to fit the body's curve, reducing muscle tension.
- **Versatile Usage:** Modern design suitable for various indoor and outdoor spaces including gardens, patios, balconies, poolside, and living rooms.

### SETUP AND ASSEMBLY

---

This lounge chair requires minimal assembly. Please ensure all parts are present before beginning. Refer to the included instructions for detailed steps.

#### Package Contents:

- 1 x Rattan Chaise Lounge
- 1 x Cushion
- 1 x Instructions Manual

**Tools Required:** No additional tools are typically required for assembly beyond what is provided or specified in the

detailed instructions.

### **Assembly Steps:**

1. Unpack all components and verify against the parts list in the included instructions.
2. Follow the step-by-step diagrams and instructions to connect the frame components securely.
3. Place the cushion onto the assembled lounge chair. Use the integrated ropes to secure the cushion and prevent movement.
4. Ensure all connections are tight and the chair is stable before use.

## **OPERATING INSTRUCTIONS**

---

### **Adjusting the Backrest:**

The lounge chair features a 6-gear adjustable backrest mechanism. To adjust the backrest:

1. Gently lift the backrest to disengage it from its current position.
2. Move the backrest to the desired angle. There are six distinct positions available.
3. Ensure the backrest clicks securely into place in the chosen gear before applying full weight.

# 6-Level in Adjustable Back Setting

Meet your different needs of positions




Figure 2: Illustration of the 6-level adjustable back setting, allowing for various reclining positions from flat to upright.

The adjustable heights from the floor are approximately 11.5", 25", 27", 29", 31", and 32" depending on the chosen position.



Figure 3: Product dimensions indicating a length of 77.5 inches, width of 26 inches, and adjustable height from 14 to 32 inches.

## MAINTENANCE AND CARE

---

Proper maintenance will extend the life and appearance of your lounge chair.

### Cleaning the Rattan Frame:

- Wipe the rattan frame with a soft, damp cloth.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the rattan.
- Allow the frame to air dry completely before placing cushions back on.

### Cushion Care:

- The cushion cover is removable and washable. Unzip the cover to remove it from the sponge.
- Machine wash the cover on a gentle cycle with cold water, or hand wash.
- Air dry the cushion cover. Do not tumble dry or iron.
- Store cushions indoors during inclement weather or prolonged periods of non-use to prevent fading and wear.

### General Care:

- Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.
- While the rattan is weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) can reduce its lifespan. Consider using a furniture cover or storing the chair in a sheltered area when not in use for extended periods.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your lounge chair.

Problem	Possible Cause	Solution
Chair feels wobbly after assembly.	Loose connections or uneven placement.	Ensure all bolts and screws are tightened securely. Place the chair on a flat, even surface.
Backrest does not stay in position.	Mechanism not fully engaged or damaged.	Lift and re-engage the backrest, ensuring it clicks into one of the six gear positions. Inspect the mechanism for any visible damage.
Cushion slides off the chair.	Ropes not secured or missing.	Utilize the integrated ropes on the cushion to tie it securely to the chair frame.

If you encounter issues not listed here or require further assistance, please contact COSTWAY customer support.

## SPECIFICATIONS

Attribute	Detail
Brand	COSTWAY
Model Name	Patio Rattan Lounge Chair
Color	Brown
Material	PE Rattan, Steel, Fabric (Cushion Fill: Sponge)
Overall Dimension (L x W x H)	77.5" x 26" x (11.5", 25", 27", 29", 31", 32") (Adjustable Height)
Cushion Thickness	2.5"
Weight Capacity	360 lbs
Product Weight	35.5 lbs
Adjustable Positions	6-Gear Reclining
Indoor/Outdoor Usage	Outdoor
Product Care Instructions	Washable (Cushion Cover)

## WARRANTY AND SUPPORT

### Warranty Information:

Specific warranty details for your COSTWAY Patio Rattan Lounge Chair may vary. Please refer to the warranty card included with your product or visit the official COSTWAY website for the most up-to-date warranty policy.

### Customer Support:

For any questions, concerns, or assistance with your product, please contact COSTWAY customer service. You can typically find contact information on the product packaging, the included instruction manual, or on the official COSTWAY website.

Visit the official COSTWAY Store: [COSTWAY Store on Amazon](#)

