

[Manuals.plus](#) /

› [COSTWAY](#) /

› COSTWAY PE Rattan Chaise Lounge Chair Instruction Manual

COSTWAY PE Rattan Chaise Lounge Chair

COSTWAY PE Rattan Chaise Lounge Chair Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COSTWAY PE Rattan Chaise Lounge Chair. Please read this manual carefully before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.



Image: The COSTWAY PE Rattan Chaise Lounge Chair, featuring a brown wicker frame and light-colored cushions, positioned on a wooden deck overlooking a scenic view.

SAFETY INFORMATION

- Ensure all parts are securely fastened before each use. Regularly check and tighten any loose connections.
- Do not exceed the maximum weight capacity of **400 lbs (181 kg)**. Overloading can cause damage or injury.
- Place the chaise lounge chair on a flat, stable, and level surface to prevent tipping.
- Avoid prolonged exposure to extreme weather conditions (heavy rain, strong winds, direct scorching sunlight) to extend the product's lifespan. Consider using a protective cover when not in use.
- Be aware that the armrests and rattan surface can become very hot in direct sunlight. Use caution to avoid burns.
- Keep children and pets away from the product during assembly.

PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- 1 x Patio Lounge Chair Frame

- 1 x Main Cushion
- 1 x Lumbar Pillow
- 1 x User's Manual (this document)
- Hardware Pack (screws, washers, tools, etc. - specific contents may vary)

SETUP AND ASSEMBLY

The COSTWAY PE Rattan Chaise Lounge Chair requires assembly. All necessary parts and a user manual are included in one package. Follow the detailed instructions provided in the separate assembly guide (if included) or the visual diagrams to ensure correct and safe construction.

General Assembly Tips:

- Lay out all components on a soft, clean surface to prevent scratches.
- Identify all hardware and match them with the corresponding steps in the assembly guide.
- Do not fully tighten screws until all parts are loosely assembled. This allows for easier alignment.
- It is recommended to have two people for assembly to ensure stability and ease of handling larger components.
- Once fully assembled, tighten all screws firmly.

OPERATING INSTRUCTIONS

Adjusting the Backrest:

Your chaise lounge chair features a 6-gear adjustable backrest, allowing you to select various reclining positions for optimal comfort, whether sitting upright, lounging, or lying flat.


1. To adjust the backrest, gently lift the backrest section of the chair.
2. Locate the adjustment gears/notches on the side or underside of the backrest frame.
3. Select your desired position by lowering the backrest until it securely locks into one of the six available gears.
4. Ensure the backrest is firmly engaged in the chosen position before applying full weight.

6-Gear Adjustable Backrest

Reclining Design for Drowsily Lying



**Gear for Easy
Reclining Adjustment**



**Crossed Structure Enhances
Stability & Sturdiness**

Image: A visual representation of the chaise lounge chair's backrest being adjusted through its six different reclining positions, highlighting the gear mechanism.

Using the Cushions:

The chair comes with a thick padded main cushion and an additional lumbar pillow for enhanced comfort. The cushion covers are waterproof and feature a zippered design for easy removal and cleaning.



Image: Detailed views illustrating the waterproof quality of the cushion fabric, the plushness of the thick padding, and the practical zippered closure for maintenance.

MAINTENANCE

Cleaning the Frame:

- The PE wicker rattan and steel frame are weather-resistant.
- Wipe down the frame with a soft cloth dampened with mild soap and water.
- Rinse thoroughly with clean water and dry completely to prevent water spots or rust on metal components.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.

Cleaning the Cushions:

- The cushion covers are waterproof and have zippers for easy removal.
- Remove the covers and hand wash them with mild soap and cold water, or machine wash on a gentle cycle.
- Air dry the covers completely before reattaching them to the foam inserts.
- Do not bleach or iron the cushion covers.

Storage:

- During periods of non-use or inclement weather, store the cushions indoors to protect them from moisture and prolong their life.
- Consider using a weather-resistant furniture cover for the entire chaise lounge chair when stored outdoors.

TROUBLESHOOTING

Common Issues and Solutions:

- **Issue: Armrests become hot in direct sunlight.**
Solution: Position the chair in a shaded area or use armrest covers during peak sun hours.
- **Issue: Cushion tie-downs do not secure well.**
Solution: Ensure the ties are properly threaded and knotted. If ties are damaged, consider replacing them or using alternative methods to secure the cushion.
- **Issue: Chair feels unstable or wobbly after assembly.**
Solution: Recheck all bolts and screws to ensure they are fully tightened. Ensure the chair is on a flat, even surface.
- **Issue: Difficulty adjusting the backrest.**
Solution: Ensure there is no obstruction in the gear mechanism. Apply slight upward pressure to the backrest before attempting to recline or raise it.

SPECIFICATIONS

Feature	Detail
Brand	COSTWAY
Model Name	PE Rattan Chaise Lounge Chair
Color	Brown (Rattan), Off-white (Cushion)
Materials	Steel, PE Wicker Rattan, Fabric, Foam
Product Dimensions (Lying Mode)	79"D x 29"W x 12"H
Product Dimensions (Upright Mode)	79"D x 29"W x 40"H
Item Weight	32 lbs (14.5 kg)
Weight Capacity	400 lbs (181 kg)
Reclining Positions	6-Gear Adjustable
Indoor/Outdoor Usage	Outdoor



Image: A detailed diagram illustrating the various dimensions of the chaise lounge chair in both upright and flat positions, including length, width, and height measurements.

WARRANTY INFORMATION

Specific warranty details for your COSTWAY PE Rattan Chaise Lounge Chair are typically provided with your purchase documentation or on the product packaging. Please refer to these materials for information regarding warranty coverage, duration, and terms. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter issues with your COSTWAY PE Rattan Chaise Lounge Chair, please contact COSTWAY customer service. Contact information can usually be found on the product packaging, the official COSTWAY website, or through your retailer.

For online purchases, you may also refer to the seller's support channels.