

Smalody 01YXSM8060BT

Smalody 2.1 Channel TV Soundbar Speaker System with Wireless Subwoofer

MODEL: 01YXSM8060BT - INSTRUCTION MANUAL

1. Introduction

Thank you for purchasing the Smalody 2.1 Channel TV Soundbar Speaker System with Wireless Subwoofer. This manual provides essential information for the proper setup, operation, and maintenance of your new audio system. Please read this manual thoroughly before use and retain it for future reference. This system is designed to enhance your audio experience, delivering clear sound and deep bass for various entertainment needs, including television, movies, music, and gaming.






Image 1.1: Smalody Soundbar System in a home entertainment setup.

2. Safety Information

- **Power Source:** Use only the provided power adapter. Ensure the voltage matches your local power supply.
- **Ventilation:** Do not block any ventilation openings. Maintain adequate space around the soundbar and subwoofer for proper airflow.
- **Water and Moisture:** Do not expose the unit to rain, moisture, dripping, or splashing. Do not place objects filled with liquids, such as vases, on the apparatus.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a soft, dry cloth only. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the unit on a stable, flat surface. If wall-mounting, ensure the wall can support the weight of the soundbar and use appropriate mounting hardware.

3. Package Contents

Carefully unpack your Smalody Soundbar Speaker System and check that all items listed below are present

and in good condition. If any items are missing or damaged, please contact customer support.

- Soundbar Unit
- Wireless Subwoofer
- Remote Control
- Optical Cable
- AUX Cable
- Power Adapter
- User Manual (this document)
- Wall Mounting Screws and Anchors (if applicable)



Image 3.1: Contents of the Smalody Soundbar Speaker System package.

4. Product Overview

4.1 Soundbar Front and Top Panel

The soundbar features integrated controls on the top panel and an LED display on the front for mode indication and status.

4.2 Soundbar Rear Panel Connections

The rear panel of the soundbar provides various input ports for connecting to your audio sources.




Image 4.1: Soundbar Rear Panel Connections and Wallmount Design.

- **DC/5V Input:** Connect the power adapter here.
- **SW OUT:** Connects to the wired subwoofer.
- **OPTICAL:** Optical digital audio input.
- **AUX IN:** 3.5mm auxiliary audio input.
- **COAXIAL:** Coaxial digital audio input.
- **Wallmount Design:** Points for wall mounting.

4.3 Remote Control

The included remote control allows for convenient operation of all soundbar functions.

Switch Mode via Remote Control



Image 4.2: Smalody Soundbar Remote Control.

5. Setup

5.1 Placement

The soundbar can be placed on a tabletop in front of your TV or mounted on a wall. The subwoofer should be placed on the floor near the soundbar for optimal bass performance.

- **Tabletop Placement:** Position the soundbar centrally below your TV. Ensure it does not obstruct the TV's remote sensor.
- **Wall Mounting:** Use the provided screws and anchors. Measure and mark the desired mounting points on the wall, ensuring they align with the wallmount design on the soundbar's rear panel. Drill pilot holes, insert anchors, and secure the soundbar.



Image 5.1: Wall-mounted soundbar and subwoofer placement.

5.2 Connecting the Subwoofer

Connect the wired subwoofer to the soundbar using the provided subwoofer cable. Insert one end into the 'SW OUT' port on the soundbar and the other end into the corresponding input on the subwoofer.

5.3 Connecting to Audio Sources

The soundbar supports multiple connection methods. Choose the one that best suits your device.

Wall Mountable

You can position the soundbar wherever you choose-be by the TV on a shelf or even mounted directly on the wall



Image 5.2: Connection diagram for Smalody Soundbar System.

- **Optical Connection:** Use the optical cable to connect the soundbar's 'OPTICAL' port to your TV's optical output. This is recommended for high-quality digital audio.
- **AUX Connection:** Use the 3.5mm AUX cable to connect the soundbar's 'AUX IN' port to your device's headphone jack or AUX output.
- **Coaxial Connection:** Use a coaxial cable (not always included) to connect the soundbar's 'COAXIAL' port to your TV's coaxial output.
- **Bluetooth Connection:** For wireless audio, refer to Section 6.3 for Bluetooth pairing instructions.

5.4 Power Connection

Connect the provided power adapter to the 'DC/5V Input' port on the soundbar, then plug the adapter into a wall outlet.

6. Operating Instructions

6.1 Power On/Off

Press the Power button on the remote control or the 'M/U' button on the soundbar's top panel to turn the unit

on or off.

6.2 Input Mode Selection

Press the 'MODE' button on the remote control or the 'M/U' button on the soundbar repeatedly to cycle through available input modes: Bluetooth (BLUE), Line In (LINE), Coaxial (COA), Optical (OPE), and HIFI Mode (HIFI).



Image 6.1: Switching input modes via remote control.

6.3 Bluetooth Pairing

1. Turn on the soundbar and select 'Bluetooth' mode (BLUE will appear on the display).
2. Enable Bluetooth on your device (smartphone, tablet, TV, etc.).
3. Search for available Bluetooth devices and select 'Smalody Soundbar' from the list.
4. Once paired, the soundbar will indicate a successful connection, and you can play audio from your device.

6.4 Volume Control

Use the 'VOL+' and 'VOL-' buttons on the remote control or the soundbar's top panel to adjust the master volume.

6.5 Bass Adjustment

Use the 'BASS+' and 'BASS-' buttons on the remote control to adjust the subwoofer's bass level.

6.6 RGB Light Control

Press the 'LIGHT' button on the remote control to cycle through different RGB lighting modes or turn the lights off.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cable is securely connected to the soundbar and a working power outlet.
No sound	Incorrect input mode; Volume too low; Cables not connected properly	Select the correct input mode. Increase volume. Check all audio cables are securely connected.
Bluetooth pairing fails	Soundbar not in pairing mode; Device Bluetooth off; Interference	Ensure soundbar is in Bluetooth mode. Turn Bluetooth on/off on your device. Move closer to the soundbar.
Remote control not working	Batteries depleted; Obstruction between remote and soundbar	Replace remote control batteries. Remove any obstructions. Ensure remote is pointed at the soundbar's sensor.
Distorted sound	Volume too high; Poor audio source quality; Incorrect cable connection	Lower the volume. Try a different audio source. Check cable connections for damage or looseness.

8. Specifications

Feature	Specification
Model Name	Sound Box
Item Model Number	01YXSM8060BT
Brand	Smalody
Speaker Type	Soundbar
Surround Sound Channel Configuration	2.1
Speaker Maximum Output Power	120 Watts (P.M.P.O)
Frequency Response	18000 Hz (Soundbar: 500Hz-20KHz, Subwoofer: 20Hz-300Hz)
Connectivity Technology	Auxiliary, Bluetooth, Coaxial, Optical
Wireless Communication Technology	Bluetooth 5.0, Infrared
Bluetooth Range	Up to 10 meters (30 feet)
Subwoofer Diameter	5 Inches
Subwoofer Connectivity Technology	Wired

Feature	Specification
Control Method	Remote
Product Dimensions	8"D x 8"W x 8"H (Overall, approximate)
Item Weight	4.21 Kilograms (9.26 pounds)
Mounting Type	Tabletop Mount, Wall Mount
Compatible Devices	Home Theater, Smartphone, Television, Computers

9. Maintenance

- Cleaning:** Use a soft, dry, lint-free cloth to clean the surfaces of the soundbar and subwoofer. Do not use abrasive cleaners, waxes, or solvents.
- Dust:** Regularly dust the units to prevent accumulation, which can affect performance and aesthetics.
- Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.

10. Warranty and Support

This product comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.

If you encounter any problems or have suggestions regarding your Smalody Soundbar Speaker System, please contact customer support. For Amazon purchases, you can typically reach the seller by logging into your Amazon account, navigating to 'Your Orders', finding the relevant order ID, and clicking 'Contact Seller'.