K&F CONCEPT KF13.157JP

K&F CONCEPT Camera Sling Bag Instruction Manual

Model: KF13.157JP

Introduction Features Setup Operating Maintenance Specifications Warranty & Support

1. Introduction

Thank you for choosing the K&F CONCEPT Camera Sling Bag. This manual provides essential information for the proper use and care of your new camera bag. Designed for versatility and protection, this bag is suitable for carrying DSLR, SLR, and mirrorless camera equipment, along with accessories.



Image: K&F CONCEPT Camera Sling Bag and included partition.

2. Key Features

- **Compact Dimensions:** External size of 13×8.6×5.9 inches (33x22x15cm) and internal size of 10.6×6.7×4.1 inches (27x17x10.5cm).
- **Adjustable Shoulder Strap:** Strap length can be adjusted from 34.25 to 55.1 inches (87-140cm) for personalized comfort.
- **Customizable Interior:** Includes one flexfold divider for flexible organization, accommodating 1 camera and 2 lenses, or a

drone.

- **Enhanced Protection:** Features 10mm high-density EPE shock-proof cotton to safeguard equipment.
- **Durable and Weatherproof Material:** Constructed from abrasion-resistant thread, with a double PU-coated recycled nylon canvas shell for weather resistance.
- **External Tripod Straps:** Bottom straps allow attachment of small tripods (max diameter 2.99 inches).
- **Multiple Carrying Options:** Can be used as a sling bag, shoulder bag, messenger bag, crossbody bag, or handbag.
- **Ample Storage Pockets:** Includes front and back zipper pockets, internal zipper pockets, internal side pocket, and internal open pocket for accessories.



Image: Overview of the K&F CONCEPT Alpha Sling Bag, highlighting dimensions, material, and weight.



Image: Convenient details of the bag, including comfort handle, quick access buckle, safety pocket, and tripod strap.

3. Setup and Internal Organization

The K&F CONCEPT Camera Sling Bag features a flexible internal organization system to protect your gear. The included flexfold divider allows you to customize the main compartment to fit your specific equipment.

3.1 Configuring Dividers

The bag comes with one flexible divider that can be folded and positioned to create compartments for your camera body, lenses, and other accessories. Experiment with different configurations to find the best fit for your gear.




Image: Examples of internal divider configurations for different camera setups.




Image: Illustration of the flexible placement options for the internal divider.

The main compartment is designed to accommodate one camera body and up to two lenses, or a small drone by removing the dividers. The 10mm high-density EPE shock-proof cotton provides effective protection.



Image: Interior view of the bag with a camera, lens, and other accessories stored.

3.2 Utilizing Pockets

The bag features various pockets for organizing smaller items:

- **Front Zipper Pocket:** Ideal for flat items like filters, lens caps, or a smartphone.
- **Back Zipper Pocket:** A secure pocket for valuables such as a wallet or passport.
- **Internal Zipper Pockets:** For small, loose items like memory cards or batteries.
- **Internal Side/Open Pockets:** Suitable for cables, cleaning cloths, or other small accessories.



Image: Detailed view of the bag's internal pocket organization.

4. Operating Instructions

The K&F CONCEPT Camera Sling Bag offers multiple ways to carry your equipment comfortably and securely.

4.1 Wearing the Bag

The adjustable shoulder strap allows you to wear the bag in several configurations:

- **Sling Bag:** Worn across the body for quick access to gear.
- **Shoulder Bag:** Carried over one shoulder.
- **Crossbody Bag:** Similar to a sling, providing stability and security.
- **Handbag:** Carried by the top handle for short distances.

Adjust the strap length to ensure a comfortable and secure fit for your body type and preferred carrying style.

Shoulder & Hand Carry



Image: Demonstrations of shoulder and hand carrying styles.






Image: Illustration of the adjustable shoulder strap and its suitability for various user heights.

4.2 Attaching a Tripod

The bag includes external straps on the bottom for carrying a small tripod. Ensure your tripod has a maximum diameter of 2.99 inches for a secure fit.

1. Loosen the two straps located on the bottom of the bag.
2. Place your folded tripod securely between the straps.
3. Tighten the straps firmly to prevent the tripod from shifting during transport.



Image: User carrying the bag with a tripod attached to the bottom straps.



Image: Feature highlighting the portable tripod attachment.

4.3 Official Product Video

Your browser does not support the video tag.

Video: Official K&F Concept video demonstrating the Camera Sling Bag's features and usage.

5. Maintenance and Care

To ensure the longevity and performance of your K&F CONCEPT Camera Sling Bag, follow these care instructions:

- **Cleaning:** Hand wash only. Do not machine wash, bleach, tumble dry, or iron.
- **Drying:** Air dry the bag completely before storing or reusing.
- **Storage:** Store in a cool, dry place away from direct sunlight when not in use.
- **Stain Removal:** For minor stains, use a soft cloth with mild soap and water. Gently rub the affected area and rinse thoroughly.

6. Troubleshooting

This product is designed for durability and ease of use. Should you encounter any issues, please refer to the following general advice:

- **Zipper Stiffness:** If zippers become stiff, apply a small amount of zipper lubricant or wax to the teeth.
- **Strap Adjustment Difficulty:** Ensure no fabric is caught in the buckles when adjusting straps. Apply gentle, even pressure.
- **Water Resistance:** While the bag is weatherproof, it is not fully submersible. Avoid prolonged exposure to heavy rain or submersion to protect your equipment.

For persistent issues, please contact K&F CONCEPT customer support.

7. Specifications

Attribute	Detail
Brand	K&F CONCEPT

Attribute	Detail
Model Number	KF13.157JP
External Size (L x W x H)	13.1 x 8.6 x 5.9 inches (33 x 22 x 15 cm)
Internal Size (L x W x H)	10.6 x 6.7 x 4.1 inches (27 x 17 x 10.5 cm)
Weight	1.32 lbs (0.6 kg)
Material Type	Polyester, Nylon (40% Polyester + 60% Nylon)
Capacity	7 Liters (Accommodates 1 camera, 2 lenses, or a drone)
Strap Type	Adjustable (34.25 to 55.1 inches)
Closure Type	Zipper
Number of Compartments	1 (main compartment with customizable divider)
Care Instructions	Hand Wash Only

8. Warranty and Support

The K&F CONCEPT Camera Sling Bag comes with a **6-month manufacturer's warranty** covering defects in materials and workmanship.
For any product-related inquiries, issues, or to claim warranty support, please contact K&F CONCEPT customer service. The manufacturer also states a commitment to provide a "lifetime fix" for any problems, indicating ongoing support beyond the initial warranty period.
Please retain your proof of purchase for warranty claims.

© 2024 K&F CONCEPT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question