

[Manuals.plus](#) /

› [MOFII](#) /

› MOFII Wireless Keyboard and Mouse Combo User Manual

MOFII B0C6QCP1GX

MOFII Wireless Keyboard and Mouse Combo User Manual

Model: B0C6QCP1GX

INTRODUCTION

This user manual provides detailed instructions for the MOFII Wireless Keyboard and Mouse Combo, featuring a retro typewriter style with a number pad and an ambidextrous wireless mouse. Designed for comfort and efficiency, this combo offers a reliable 2.4G wireless connection and universal compatibility with various operating systems. Please read this manual thoroughly to ensure proper setup and optimal performance of your new device.



Image: The MOFII Wireless Keyboard and Mouse Combo in Light Blue Colorful, showcasing its retro round keycaps and matching ambidextrous mouse, along with the USB receiver.

PACKAGE CONTENTS

-
- 1 x MOFII Wireless Keyboard
 - 1 x MOFII Wireless Mouse
 - 1 x USB Receiver (stored inside the mouse)
 - 1 x User Manual

SETUP

1. **Install Batteries:** Open the battery compartments on the underside of both the keyboard and the mouse. Insert the required batteries (not included) according to the polarity indicators.
2. **Locate USB Receiver:** The USB receiver is cleverly stored inside the mouse's battery compartment or a dedicated slot on the mouse's underside. Carefully remove it.
3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer or laptop.
4. **Power On:** Ensure both the keyboard and mouse are switched ON. The devices should automatically connect to your computer. No additional drivers are needed for most operating systems.

Plug and Play

One nano receiver connects both the wireless keyboard and mouse by 2.4G wireless connection



Image: A visual representation of the plug-and-play setup, showing the USB receiver connected to a laptop and the wireless signal extending to the keyboard and mouse, indicating a range of 35 feet.



One USB Receiver for Both
Wireless Keyboard and Mouse

Image: A close-up showing the single USB receiver that connects both the wireless keyboard and mouse, highlighting the convenience of a unified connection.

OPERATING INSTRUCTIONS

Keyboard Features:

- **Retro Typewriter Design:** Features 104 round keycaps with a floated design for tactile feedback and a unique aesthetic.
- **Full-Size Layout:** Includes a dedicated number pad for enhanced productivity.
- **Adjustable Tilt:** The keyboard has foldable stands on the back to adjust the typing angle for ergonomic comfort.
- **Indicator Lights:** Includes lights for Number Lock, Caps Lock, and Power/Low Battery status.
- **Hotkey Functions:** Equipped with 13 hotkey functions for quick access to multimedia and common tasks (e.g., F1-F12, volume control).

Ergonomic Design

Release wrist pressure and work effectively



Image: The keyboard viewed from the side, illustrating its ergonomic design with silicone non-slip pads and foldable stands that allow for an adjustable typing angle.



Image: An overhead view of the keyboard highlighting the Number Lock, Caps Lock, and Power/Low Battery indicator lights. It also mentions the mouse's adjustable DPI settings (800/1200/1600).




Image: The keyboard with an overlay indicating its 13 hotkey functions, designed to streamline work and entertainment tasks.

Mouse Features:

- **Cute Cat Design:** An ambidextrous wireless optical mouse with a unique and relaxing design.
- **Adjustable DPI:** Offers adjustable settings (800/1200/1600 DPI) to suit various tasks and preferences, ensuring

accuracy and speed.

- **Ambidextrous Design:** Suitable for both left and right-handed users.

MAINTENANCE

- **Cleaning Keycaps:** The round keycaps are removable for easy dust cleaning. Use a soft brush or cloth to clean between the keys and the keycaps themselves.
- **General Cleaning:** Wipe the keyboard and mouse surfaces with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the internal components.
- **Battery Replacement:** When the low battery indicator lights up or performance degrades, replace the batteries in both the keyboard and mouse. Refer to the "Setup" section for battery compartment locations.



Detachable Keycaps

Include a brush to deep clean for the keyboard

Image: A close-up of the keyboard showing a few keycaps removed, along with a small brush, illustrating how easy it is to detach keycaps for deep cleaning.

POWER SAVING FUNCTION

The keyboard and mouse combo features an automatic power-saving function to extend battery life. After 8 minutes of inactivity, both devices will automatically enter sleep mode. To wake them up, simply click any key on the keyboard or move the mouse.



Intelligent Auto-Sleep

Enter sleeping automatically while not using,
save battery life and reduce battery replacement

Image: The keyboard and mouse on a desk in a dimly lit room, with a clock icon indicating the "Intelligent Auto-Sleep" feature that saves battery life by entering sleep mode when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Keyboard/Mouse not responding.	Low battery; USB receiver not properly connected; devices in sleep mode.	Replace batteries; ensure USB receiver is firmly plugged in; click a key or move mouse to wake from sleep.
Intermittent connection.	Interference from other wireless devices; distance from receiver too great.	Move devices closer to the receiver (within 10 meters/33 ft); minimize interference from other 2.4G devices.
Mouse cursor erratic or not moving smoothly.	Dirty optical sensor; incorrect DPI setting.	Clean the optical sensor on the mouse's underside; adjust DPI settings (800/1200/1600) using the DPI button on the mouse.
Keyboard keys feel sticky or unresponsive.	Dust or debris under keycaps.	Remove keycaps and clean thoroughly as described in the Maintenance section.

SPECIFICATIONS

- **Brand:** MOFI
- **Model:** B0C6QCP1GX
- **Color:** Light Blue Colorful
- **Connectivity Technology:** 2.4G Wireless
- **Keyboard Layout:** 104-key full-size with number pad
- **Mouse DPI:** 800/1200/1600 adjustable
- **Keyboard Dimensions:** 18.1 x 5.5 x 1.7 inches (approximate, based on image)
- **Mouse Dimensions:** 4.1 x 2.7 x 1.6 inches (approximate, based on image)
- **Item Weight:** 2.05 pounds (approximate, for the combo)
- **Special Feature:** Round Keycaps, Automatic Power Saving

Full-Size Keyboard Combo




Image: Detailed dimensions of the full-size keyboard and the ambidextrous mouse, providing measurements in inches for both components.

COMPATIBILITY

The MOFII Wireless Keyboard and Mouse Combo offers universal compatibility with a wide range of operating systems and devices, ensuring seamless integration into your existing setup.

- Windows XP, Windows Vista, Windows 11/10/8/7
- Chromebook
- Mac OS
- Linux
- Compatible Devices: Laptop, Personal Computer



Image: Icons representing compatibility with Windows operating systems, laptops, and personal computers, indicating broad device support.

© 2025 MOFII. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question