**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Snailax SL-527BRC

# Snailax Foot Massager SL-527BRC Instruction Manual

Model: SL-527BRC | Brand: Snailax

## Product Overview

The Snailax Foot Massager SL-527BRC is designed to provide a comprehensive and comfortable foot massage experience. It integrates deep kneading, vibration, and air compression functions, all adjustable across three intensity levels. This machine also features soothing heat, with two adjustable temperature settings, and a convenient remote control for ease of use. The inner foot covers are machine-washable for hygiene.




Figure 1: Snailax Foot Massager SL-527BRC with its remote control, showcasing the main unit and its intuitive control panel.

## Safety Information

- For first-time users, begin with the lowest intensity setting to allow your feet to adapt to the massage.
- Always ensure the device is unplugged when not in use or before cleaning.
- Do not use the massager in wet environments or with wet hands.
- Keep the device away from water and high temperatures.
- If you experience any discomfort or pain during use, discontinue immediately.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## Setup Guide

1. **Unpack the Device:** Carefully remove the foot massager and all accessories from the packaging. Ensure all

components, including the main unit, remote control, and power adapter, are present.

2. **Position the Massager:** Place the foot massager on a flat, stable surface, such as the floor in front of a chair or sofa. Ensure there is enough space around the unit for proper ventilation.
3. **Connect Power:** Locate the power input port on the back or side of the massager. Insert the power adapter cable firmly into the port. Plug the other end of the power adapter into a standard electrical outlet.
4. **Prepare for Use:** Ensure the inner foot covers are properly installed and zipped. The massager is now ready for operation.




Figure 2: The control panel of the Snailax Foot Massager, showing the various function buttons and their indicators.

## Operating Instructions

The Snailax Foot Massager offers multiple massage modes and intensity levels for a personalized experience. You can control the device using either the integrated control panel or the included remote control.

### Using the Control Panel:

1. **Power On/Off:** Press the **Power Button** (usually indicated by a circle with a vertical line) to turn the massager on or off.
2. **Kneading Function:** Press the **Knead Button** to activate the deep kneading massage. Press repeatedly to cycle through Low, Medium, and High intensity levels.
3. **Air Compression:** Press the **Air Button** to engage air compression. Press repeatedly to adjust the intensity (Low, Medium, High).
4. **Vibration:** Press the **Vibration Button** to turn on the vibration massage. Cycle through intensity levels (Low, Medium, High) with repeated presses.
5. **Heat Function:** Press the **Heat Button** to activate the soothing heat. Press repeatedly to select between two temperature settings (113°F to 131°F). The heat function can be used independently or with other massage modes.

## Using the Remote Control:

The remote control provides convenient access to all functions without needing to bend down.




Figure 3: A user comfortably operating the foot massager using the remote control, highlighting its user-friendly design.

- The remote control features dedicated buttons for Knead, Air, Vibration, Power, and Heat (+/- for

intensity/temperature).

- Simply point the remote at the massager and press the desired function button to activate or adjust settings.
- The remote control comes with a pre-installed battery. Remove the plastic tab before first use.




Figure 4: The foot massager providing professional and customized massage with adjustable intensity levels for kneading, compression, and vibration.




Figure 5: The soothing heat function of the foot massager, which heats up quickly to provide comforting warmth, improving circulation.

## Maintenance

Regular maintenance ensures the longevity and hygiene of your Snailax Foot Massager.

- **Cleaning the Outer Surface:** Wipe the exterior of the massager with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Cleaning Inner Foot Covers:** The inner foot covers are removable and machine-washable for easy cleaning.
    a. Unzip and remove the fabric covers from the foot chambers.
    b. Machine wash the covers on a gentle cycle with cold water.
    c. Air dry completely before reattaching them to the massager.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight when not in use.




Figure 6: The removable and washable inserts of the foot massager, designed for easy cleaning and maintenance of hygiene.

## Troubleshooting

If you encounter any issues with your Snailax Foot Massager, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Massager does not turn on. | Power cord not properly connected; Power outlet malfunction. | Ensure the power adapter is securely plugged into both the massager and a working electrical outlet. Try a different outlet. |
| Weak or no massage intensity. | Incorrect intensity setting; Feet not positioned correctly. | Increase the intensity level using the control panel or remote. Adjust your feet position to ensure proper contact with massage nodes. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Heat function not working. | Heat function not activated; Low temperature setting. | Press the Heat button to activate. Cycle through the heat settings to ensure a higher temperature is selected. Allow a few minutes for the heat to build up. |
| Remote control not responding. | Battery depleted or not properly inserted; Obstruction between remote and unit. | Check and replace the remote control battery if necessary. Ensure no objects are blocking the signal path. |

## Specifications

- **Product Dimensions:** 15.3 x 12.6 x 7.48 inches
- **Item Weight:** 7.08 Pounds
- **Model Number:** SL-527SC (Note: Product title indicates SL-527BRC, but specifications list SL-527SC. Please verify model number on your unit.)
- **Power Source:** Corded Electric
- **Brand:** Snailax
- **Color:** Dark Black
- **Special Feature:** Heat
- **Foot Size Compatibility:** Fits up to US Men's Size 13.

## Warranty and Support

Snailax offers an extended warranty for your product. To extend your warranty from 1 year to 3 years, please email support@snailax.com. Warranty terms and conditions apply.
For any further assistance, technical support, or inquiries, please contact Snailax customer service.
**Email:** support@snailax.com

© 2024 Snailax. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0C6QHYNCB**

More documents and user manuals: **https://manuals.plus/**