

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Bosch Professional](#) /
- › [Bosch Professional 1600A02H5C Tool Bag System Instruction Manual](#)

Bosch Professional 1600A02H5C

Bosch Professional 1600A02H5C Tool Bag System Instruction Manual

Model: 1600A02H5C

INTRODUCTION

This manual provides essential instructions for the safe and efficient use, setup, and maintenance of your Bosch Professional 1600A02H5C Tool Bag System. Please read this manual thoroughly before using the product and retain it for future reference.

PRODUCT OVERVIEW

The Bosch Professional 1600A02H5C is a comprehensive tool bag system designed for professionals and DIY enthusiasts. It offers organized storage and easy access to tools, enhancing work efficiency.

Key Features:

- **Easy Access & Convenient Tool Storage:** Thoughtfully designed compartments for customized tool organization.
- **ProClick System:** Enables quick and easy changing of bags without removing the belt.
- **Equipped with Professional Hand Tools:** Includes a selection of hand tools for common applications.
- **Versatile Use:** Suitable for workshop or on-the-go tasks.



Image: Included professional hand tools.

SETUP

1. Assembling the Tool Belt:

1. Unpack the belt (1 x belt 108, size L/XL) and the two ProClick holders.
2. Adjust the belt to your waist size using the buckle mechanism. Ensure a snug but comfortable fit.
3. Attach the ProClick holders to the belt at desired positions. The holders are designed for quick attachment and detachment.



Image: The Bosch Professional tool belt.

2. Attaching Tool Bags (GWT 2 and GWT 4):

1. Identify the GWT 2 and GWT 4 tool bags.
2. Align the ProClick attachment point on the back of each tool bag with a ProClick holder on the belt.
3. Press firmly until you hear a click, indicating the bag is securely attached.
4. To detach, press the release button on the ProClick holder and lift the bag.



150 mm

210 mm

290 mm

Image: Bosch Professional GWT 4 tool bag.



Image: Bosch Professional GWT 2 tool bag.

OPERATING INSTRUCTIONS

1. Organizing Tools:

Utilize the various compartments and pockets within the GWT 2 and GWT 4 bags to organize your tools efficiently. Place frequently used tools in easily accessible pockets. The system is designed to accommodate the included screwdrivers, Allen key set, side cutters, and utility knife, along with other small hand tools.

2. Using the ProClick System:

The ProClick system allows for quick changes between different tool bags or for removing bags when not needed. This feature is particularly useful when transitioning between tasks that require different sets of tools.



Image: Bosch Professional tool bag system in use.

MAINTENANCE

Cleaning:

- **Tool Bags:** Wipe down the tool bags with a damp cloth and mild soap. Allow to air dry completely before storing tools. Do not machine wash or tumble dry.
- **Tools:** Clean tools after each use to remove dirt, grease, or debris. Apply a light coat of oil to metal parts of tools to prevent rust, if applicable.

Storage:

Store the tool bag system and tools in a dry, clean environment, away from direct sunlight and extreme temperatures. Ensure all tools are clean and dry before storage to prevent corrosion.

TROUBLESHOOTING

Common Issues and Solutions:

- **Tool bag not securely attaching to belt:** Ensure the ProClick holder is properly aligned with the bag's attachment point and press firmly until a click is heard. Check for any obstructions in the mechanism.
- **Difficulty detaching tool bag:** Ensure the release button on the ProClick holder is fully depressed before attempting to lift the bag.
- **Belt slipping:** Adjust the belt to a tighter fit. Ensure the buckle is securely fastened.

SPECIFICATIONS

Feature	Detail
Model Number	1600A02H5C
Brand	Bosch Professional
Material	Leather (for certain components), durable fabric for bags
Color	Black
Item Weight	3.47 Kilograms (total package)
Product Dimensions	33.5 x 30.5 x 19 cm
Number of Pockets	108 (referring to the belt system capacity)
Closure Type	Buckle (for belt)
Maximum Waist Measurement	116 cm

WARRANTY INFORMATION

Bosch Professional products are manufactured to high-quality standards and come with a manufacturer's warranty. For specific warranty terms and conditions applicable to your region, please refer to the official Bosch Professional website or contact their customer service. Keep your proof of purchase for warranty claims.

SUPPORT

For technical assistance, spare parts, or any questions regarding your Bosch Professional 1600A02H5C Tool Bag System, please visit the official Bosch Professional website or contact their authorized service centers. Contact information can typically be found on the product packaging or the official website.

Official Bosch Professional Website: www.bosch-professional.com