

[Manuals.plus](#) /

› [OUTON](#) /

› OUTON Arc Floor Lamp with Remote (Model B0C6SLJ8RJ) User Manual

OUTON B0C6SLJ8RJ

OUTON Arc Floor Lamp with Remote (Model B0C6SLJ8RJ) User Manual

Model: B0C6SLJ8RJ | Brand: OUTON

[Introduction](#)

[Safety Instructions](#)

[Package Contents](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the OUTON Arc Floor Lamp. This modern LED standing lamp is designed to provide versatile lighting for your living space, combining ambient and task lighting capabilities. It features adjustable height, dimmable light with four color temperatures, and convenient control via a remote or foot switch. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your lamp.



Image 1.1: The OUTON Arc Floor Lamp showcasing its design, remote control, and different light temperature options.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the lamp's requirements (110 Volts).
- Do not operate the lamp with a damaged cord or plug. If damaged, contact customer service.
- Do not modify the plug or cord in any way.
- Always unplug the lamp from the electrical outlet before cleaning or attempting any maintenance.
- Do not immerse the lamp in water or use it in wet locations. This product is for indoor use only.
- Keep the lamp away from heat sources and direct sunlight.
- Ensure the lamp base is stable and placed on a level surface to prevent tipping.
- Do not attempt to disassemble or repair the lamp yourself. Refer all servicing to qualified personnel.
- Use only the specified bulb type (E26, 9W LED) or a compatible replacement. Note that the remote control functionality is designed for the included bulb.
- Keep the remote control out of reach of children.

3. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, contact customer service.

- Floor Lamp (Arc Arm, Pole Sections, Base)
- Lampshade (Linen)
- 9W LED Bulb (E26 base)
- Remote Control
- User Manual (This document)



Image 3.1: Components of the OUTON Arc Floor Lamp, illustrating the base, pole, adjustable arm, and lampshade.

4. SETUP AND ASSEMBLY

Assembly is required. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all package contents are present.
2. **Assemble the Base and Pole:**

- Attach the lowest pole section to the weighted lamp base by screwing it clockwise until secure.
- Connect the subsequent pole sections by screwing them together clockwise. Ensure all connections are tight to prevent wobbling.

3. Attach the Arc Arm:

- Carefully attach the arc arm to the top pole section. Ensure the electrical wire passes freely through the pole sections.
- Secure the arc arm connection by tightening any provided screws or rotating mechanisms.

4. Install the Bulb:

- Screw the provided 9W LED bulb into the E26 socket located at the end of the arc arm. Do not overtighten.

5. Assemble the Lampshade:

- The linen lampshade may require minor assembly. Follow any specific instructions provided with the lampshade itself to attach it to the shade frame.
- Once assembled, attach the lampshade to the lamp fixture, ensuring it is centered and securely fastened.

6. Position the Lamp: Place the assembled lamp on a stable, level surface. Ensure the weighted base is fully supported. Adjust the arc arm and reading light to your desired height and angle. The height is adjustable from 60" to 72".

7. Connect to Power: Plug the power cord into a standard 110V electrical outlet.



Remote Control

Easy to control while lying on the sofa.



Foot Pedal Switch

Warm Tips: The foot switch needs to be kept on while using the remote control

Image 4.1: Illustration of the lamp's adjustable height and arm, with key dimensions.

5. OPERATING INSTRUCTIONS

Your OUTON Arc Floor Lamp can be operated using the included remote control or the integrated foot switch.

5.1. Using the Foot Switch

The foot switch provides a simple on/off function. Press the foot switch once to turn the lamp on, and press it again to turn it off. For remote control functionality, the foot switch must be in the "on" position.

Why Choose Us?

Ours ✓



Adjustable Height

Others ✗



Fixed height

VS

Ours ✓



Remote Control & Foot Switch

Others ✗



Foot Switch

VS

Ours ✓



Stepless Color Tempertaure & Dimmable

Others ✗



Only 3 Color temperatures

VS

Image 5.1: Demonstrates the use of the remote control and highlights the foot pedal switch.

5.2. Using the Remote Control

The remote control offers comprehensive control over the lamp's features. Ensure the foot switch is in the "on" position for the remote to function.

- **Power On/Off:** Press the **Power button** to turn the lamp on or off.
- **Brightness Adjustment (Dimming):** Use the **Brightness Up (+)** and **Brightness Down (-)** buttons to adjust the light intensity from 5% to 100%.
- **Color Temperature Adjustment:** Use the **Color Temperature Up (K+)** and **Color Temperature Down (K-)** buttons to cycle through or steplessly adjust the color temperature from 3000K (Warm White) to 6000K (Cool White).
- **Preset Lighting Modes:** The remote may include buttons for quick selection of preset lighting modes (e.g., Reading, Relax, Night Light). Refer to the remote's specific button layout.
- **1-Hour Timer:** Press the **Timer button** (often marked with a clock icon) to activate a 1-hour countdown, after which the lamp will automatically turn off.



Image 5.2: Illustrates the range of color temperatures and dimmable brightness settings.




Image 5.3: The 1-hour timer feature, which automatically turns off the lamp.

5.3. Memory Function

The lamp features a memory function. When the lamp is turned on again after being off, it will resume the last used color temperature and brightness level.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp's surfaces. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish. For the lampshade, a lint roller or soft brush can remove dust.
- **Bulb Replacement:** The lamp uses an E26 base 9W LED bulb. While LED bulbs have a long lifespan (up to 50,000 hours), if replacement is needed, ensure the lamp is unplugged and the bulb has cooled before unscrewing the old bulb and installing a new one. Note that the remote control functionality is specifically designed for the included bulb; using a different bulb may disable remote functions.
- **Cord Care:** Regularly inspect the power cord for any signs of damage. Do not place heavy objects on the cord or run it under carpets.

7. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Lamp does not turn on.	• Power cord not securely plugged in. • Foot switch is off. • Bulb is loose or faulty. • No power from outlet.	• Ensure the power cord is fully inserted into the outlet. • Press the foot switch to the "on" position. • Unplug the lamp, then carefully tighten or replace the bulb. • Test the outlet with another device.
Remote control is not working.	• Foot switch is off. • Remote control batteries are dead or incorrectly inserted. • Remote is too far from the lamp or obstructed. • Bulb is not the original or compatible type.	• Ensure the foot switch is in the "on" position. • Replace batteries in the remote control, ensuring correct polarity. • Move closer to the lamp and ensure a clear line of sight. • The remote is designed for the included bulb. Using a different bulb may disable remote functions.
Lamp is unstable or wobbles.	• Base not on a level surface. • Pole sections or arc arm not securely tightened. • Base not sufficiently weighted (if extended far).	• Relocate the lamp to a flat, stable surface. • Carefully re-tighten all pole and arm connections. • Ensure the lamp is positioned such that the weighted base provides adequate stability, especially when the arm is extended.
Adjustable arm mechanism is loose or broken.	• Over-tightening or forceful adjustment. • Wear and tear.	• Adjust the arm gently. Avoid excessive force when tightening or loosening. • If broken, contact customer service for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	OUTON
Model	B0C6SLJ8RJ
Lamp Type	Arc Floor Lamp
Product Dimensions	11"D x 11"W x 72"H (Adjustable Height: 60" to 72")
Item Weight	16.02 pounds

Feature	Detail
Material	Metal (Base), Linen (Shade)
Finish Type	Painted
Light Source Type	LED
Included Bulb	9W LED Bulb (E26 Base)
Brightness	810 Lumens
Dimmability	5% - 100% Stepless Dimmable
Color Temperature	3000K (Warm White) to 6000K (Cool White) Stepless
Control Method	Remote Control & Foot Pedal Switch
Special Features	1-Hour Timer, Memory Function, Adjustable Height
Power Source	Corded Electric
Voltage	110 Volts
Assembly Required	Yes
Average Life (Bulb)	50,000 Hours

Long Lasting & Money Saving

Save \$6

9W LED Bulb Included

85% Energy Saving
9W=60W

50,000 hrs-Long Lifespan

CRI 85+

No Flickering

Image 8.1: Details of the included 9W LED bulb and its energy-efficient features.

9. WARRANTY AND CUSTOMER SUPPORT

OUTON is committed to providing high-quality products and customer satisfaction.

- **2-Year Warranty:** This product comes with a 2-year quality support warranty from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
- **Customer Service:** If you have any questions, concerns, or require assistance with your OUTON Arc Floor Lamp, please contact our customer service team. We offer 24/7 customer support.
- **Contact Information:** Please refer to the contact details provided on the OUTON official website or your purchase documentation for the most up-to-date customer service information.