FirFurd P721

FirFurd P721 3-Door Buffet Cabinet Instruction Manual

Model: P721 | Brand: FirFurd

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your FirFurd P721 3-Door Buffet Cabinet. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and safe operation. Keep this manual for future reference.

2. Product Overview

The FirFurd P721 is a versatile 3-door buffet cabinet designed for various living spaces. It features a clean, handleless design with adjustable interior shelves and sturdy solid wood legs.



Figure 2.1: FirFurd P721 Buffet Cabinet in a living space.



Figure 2.2: Interior view of the FirFurd P721 Buffet Cabinet with open doors.

3. Safety Information

Observe the following safety precautions during assembly and use:

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws, as this may damage the material.
- Keep small parts away from children during assembly.
- Always use the provided anti-tip kit to secure the cabinet to a wall, especially if children are present.
- Do not exceed the maximum weight capacity of 80 kg for the entire unit. Distribute weight evenly.
- This product is intended for indoor use only.

4. Parts List

Before starting assembly, verify that all components are included. The product is delivered in two packages.



Figure 4.1: The FirFurd P721 cabinet is shipped in two separate packages.

Refer to the separate assembly instructions sheet for a detailed list of all panels, hardware, and tools required.

5. Setup and Assembly

Assembly of the FirFurd P721 buffet cabinet requires following the step-by-step instructions provided in the included assembly guide. General steps include:

1. **Unpacking:** Carefully unpack all components and lay them out on a protected surface.
2. **Base Assembly:** Attach the solid wood legs to the bottom panel of the cabinet.
3. **Frame Construction:** Assemble the side panels, back panel, and top panel to form the main structure.
4. **Shelf Installation:** Insert the adjustable shelves into the desired positions using the shelf pins.
5. **Door Installation:** Attach the three doors using the provided hardware and ensure the push-to-open mechanisms are correctly installed.
6. **Final Placement and Securing:** Position the cabinet in its desired location and secure it to the wall using the anti-tip kit.

For detailed, illustrated assembly steps, please consult the dedicated assembly manual included in your package.

6. Operating Instructions

6.1 Door Operation (Push-to-Open Mechanism)

The FirFurd P721 cabinet features a handleless design with a push-to-open mechanism for its three doors. To open a door, gently press on the center of the door panel. The door will spring open slightly, allowing you to pull it fully open. To close, simply push the door firmly until the mechanism engages and holds it shut.



Figure 6.1: Demonstrating the push-to-open door mechanism.

6.2 Adjustable Shelves

The interior shelves of the cabinet are adjustable, allowing for customized storage space. Each shelf can be moved up or down by 3 cm increments. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove the four shelf pins from their current holes.
3. Reinsert the shelf pins into the desired holes, ensuring they are level and securely seated.
4. Place the shelf back onto the pins.



Figure 6.2: Adjustable shelf mechanism, showing vertical adjustment options.

7. Maintenance

To ensure the longevity and appearance of your FirFurd P721 buffet cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Retighten as necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable indoor humidity level to prevent warping or cracking of the wood material.

8. Troubleshooting

Problem	Possible Cause	Solution
Door does not close properly.	Push-to-open mechanism misaligned or damaged.	Check alignment of the mechanism. Ensure no obstructions. If damaged, contact customer support.
Cabinet feels unstable or wobbly.	Screws are loose; cabinet not level; anti-tip kit not installed.	Retighten all assembly screws. Ensure the cabinet is on a flat, level surface. Install the anti-tip kit as instructed.
Shelves are difficult to adjust.	Shelf pins are stuck or misaligned.	Ensure shelves are empty. Wiggle pins gently to remove. Check for debris in holes.
Surface scratches or minor damage.	Accidental impact or abrasive cleaning.	Use a furniture repair kit or touch-up pen for minor scratches. Avoid abrasive materials for cleaning.

9. Specifications

Feature	Detail
Model Number	P721
Brand	FirFurd
Dimensions (L x W x H)	107 cm x 40 cm x 80 cm (42.1 in x 15.7 in x 31.4 in)

Feature	Detail
Weight	36 kg (79.4 lbs)
Maximum Weight Capacity	80 kg (176 lbs)
Color	White
Material	Engineered Wood, Solid Wood Legs
Features	3 Doors, Handleless (Push-to-Open), Adjustable Shelves, 12cm Solid Wood Legs
Recommended Use	Living Room, Dining Room, Kitchen, Bedroom, Hallway




Figure 9.1: Dimensions of the FirFurd P721 Buffet Cabinet.

10. Warranty and Support

FirFurd is committed to providing high-quality products. For information regarding warranty coverage, missing parts, or any issues encountered during assembly or use, please refer to the contact information provided with your purchase or visit the official FirFurd website. Please have your model number (P721) and purchase details ready when contacting support.

© 2023 FirFurd. All rights reserved.