

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Hilife](#) /
- > [Hilife HF4 3L Ultrasonic Cool Mist Humidifier User Manual](#)

Hilife HF4

Hilife HF4 3L Ultrasonic Cool Mist Humidifier User Manual

Model: HF4 | Brand: Hilife

1. INTRODUCTION

Thank you for choosing the Hilife HF4 3L Ultrasonic Cool Mist Humidifier. This device is designed to improve air quality and comfort in your home by adding moisture to the air. It features a 3-liter capacity, quiet operation, automatic shut-off, and a filter-free design for ease of use and maintenance. Please read this manual thoroughly before operating the humidifier to ensure safe and efficient use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always place the humidifier on a firm, flat, waterproof surface at least 12 inches (30 cm) away from walls and appliances.
- Do not place the humidifier directly on carpet, wood, or other surfaces that may be damaged by water or moisture.
- Ensure the power cord is not pinched or placed under heavy objects. Do not use if the cord or plug is damaged.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not add essential oils directly into the water tank as this may damage the unit.
- Keep out of reach of children and pets.
- Do not cover the mist outlet or air intake during operation.
- Use only clean, cool tap water or distilled water. Avoid hot water.
- Do not immerse the base unit in water or other liquids.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Hilife HF4 Humidifier:



Image 3.1: Front view of the Hilife HF4 Humidifier, showing the transparent water tank, mist outlet, and the digital control panel at the base. The control panel includes buttons for On/Off, Level, Humidity, Set Humidity, and Sleep mode, along with a digital display.

Components:

- Mist Outlet
- Water Tank (3L capacity)
- Base Unit with Ultrasonic Transducer
- Control Panel with Digital Display
- Power Cord

4. SETUP

4.1 Unpacking

1. Carefully remove all packaging materials from the box.
2. Inspect the humidifier for any signs of damage. If damaged, do not operate and contact customer support.
3. Place the humidifier on a flat, stable surface.

4.2 Filling the Water Tank



Image 4.1: A hand pouring water directly into the top opening of the Hilife HF4 Humidifier, demonstrating its convenient top-fill design.

1. Ensure the humidifier is unplugged from the power outlet.

2. Remove the top cover of the humidifier.
3. Pour clean, cool tap water or distilled water directly into the water tank through the top opening. Do not exceed the maximum fill line.
4. Replace the top cover securely.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Plug the power cord into a suitable electrical outlet.
- Press the **On/Off** button on the control panel to turn the humidifier on or off.

5.2 Mist Level Adjustment



Image 5.1: Three Hilife HF4 Humidifiers shown side-by-side, each emitting a different volume of mist, illustrating the three available mist adjustment levels.

- With the humidifier on, press the **Level** button repeatedly to cycle through the three mist output levels (Low, Medium, High).
- The selected level will be indicated on the digital display.

5.3 Auto Mode



Image 5.2: The Hilife HF4 Humidifier operating in an office environment, with a graphic illustrating how Auto Mode maintains optimal humidity levels over time.

- Press the **Humidity** button to activate Auto Mode.
- In Auto Mode, the humidifier will automatically adjust the mist output to maintain a comfortable humidity level based on the ambient conditions.
- You can also press the **Set Humidity** button to set a desired humidity percentage. The unit will work to achieve and maintain this level.

5.4 Sleep Mode

Whisper-Quite Operation



Sleep mode



<30dB



Auto Shut-off



Image 5.3: The Hilife HF4 Humidifier operating quietly beside a bed where a person is sleeping, emphasizing its low noise level (below 30dB) and automatic shut-off feature.

- Press the **Sleep** button to enter Sleep Mode.
- In Sleep Mode, the display lights will dim, and the humidifier will operate at its lowest, quietest setting to ensure minimal disturbance during rest.

5.5 Automatic Shut-off

- The humidifier is equipped with an automatic shut-off feature that activates when the water level in the tank is too low or when the tank is removed.
- This safety feature prevents damage to the unit and ensures peace of mind.

6. MAINTENANCE

Regular cleaning is essential for optimal performance and hygiene. This humidifier does not require a filter.

6.1 Daily Maintenance

- Unplug the humidifier.
- Empty any remaining water from the tank and base.

- Rinse the water tank and base with fresh water.
- Wipe the exterior with a soft, damp cloth.

6.2 Weekly Cleaning (Descaling)

- Unplug the humidifier.
- Remove the top cover and empty the water tank.
- Pour 1 cup (240ml) of white vinegar into the water tank and base.
- Let it soak for 30 minutes.
- Use a soft brush or cloth to clean any mineral buildup on the ultrasonic transducer and inside the tank.
- Rinse thoroughly with clean water until the vinegar smell is gone.
- Dry all parts before reassembling or storing.

6.3 Storage

- Before storing, ensure the humidifier is completely clean and dry.
- Store in a cool, dry place, away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Low water level Mineral buildup on transducer Mist outlet blocked	Refill water tank Clean transducer with vinegar solution Ensure mist outlet is clear
Unusual odor	Stagnant water New unit smell	Clean tank and refill with fresh water Operate for a few hours in a well-ventilated area
Water leakage	Tank not seated correctly Overfilled tank Cracked tank	Ensure tank is properly seated Do not overfill Contact customer support if tank is cracked
Unit not turning on	No power Water tank empty/not seated	Check power connection Refill water tank and ensure it is correctly placed

8. SPECIFICATIONS

- **Model:** HF4
- **Brand:** Hilife
- **Capacity:** 3 Liters
- **Operation Mode:** Ultrasonic Cool Mist
- **Coverage Area:** Up to 325 Square Feet
- **Max Operating Time:** Up to 30 hours (on lowest mist setting)
- **Noise Level:** <30dB (in Sleep Mode)
- **Special Features:** Auto Shut-off, Quiet Operation, Top Fill Design, No Filter Required
- **Product Dimensions:** 18.5D x 18.5W x 26.5H centimeters (approximately 7.3D x 7.3W x 10.4H inches)
- **Item Weight:** Approximately 0.95 kg (2.1 Pounds)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product at the time of purchase or visit the official Hilife website. Ensure you have your model number (HF4) and purchase details available when contacting support.

© 2024 Hilife. All rights reserved.

Related Documents - HF4

 <p>Company: Shenzhen Tangken Technology Co., Ltd. Add: 101-C, Block B, Building 1, No.28, Anhua North Road, South Community, Longhua Street, Longhua District, Shenzhen, Guangdong, China Phone: +86 755 2761 1111 Email: service@hilife.com</p>	<p>HiLIFE Handheld Garment Steamer User Manual</p> <p>Comprehensive user manual for the HiLIFE Handheld Garment Steamer, covering specifications, package contents, product description, operating instructions, care and maintenance, troubleshooting, and warranty information.</p>
	<p>Hilife Garment Steamer: Support, Fabric Guide, and Warm Tips</p> <p>Comprehensive guide for Hilife garment steamers, covering support contact, fabric steaming advice, and essential usage tips for optimal performance and garment care.</p>
 <p>HF4 Plus</p>	<p>Hoover HF4 Plus User Manual</p> <p>Comprehensive user manual for the Hoover HF4 Plus vacuum cleaner, detailing assembly, charging, usage modes, maintenance, and troubleshooting.</p>
	<p>EyeVac Professional Touchless Vacuum Cleaner User Manual and Guide</p> <p>Comprehensive user manual for the EyeVac Professional touchless vacuum cleaner, covering safety instructions, operating procedures, maintenance, troubleshooting, and warranty information.</p>
	<p>Tuya HF3 HF4 CF3 WiFi Access Control System User Manual</p> <p>User manual for Tuya's HF3, HF4, and CF3 WiFi enabled access control systems, featuring fingerprint, keypad, and card reader access. Provides detailed specifications, features, and connectivity options for secure building access management.</p>



HF4

[Hoover HF4 Cordless Vacuum Cleaner User Manual](#)

Comprehensive user manual for the Hoover HF4 cordless vacuum cleaner, covering setup, operation, maintenance, and troubleshooting.

Documents - Hilife – HF4



HAVE QUESTIONS WITH YOUR HUMIDIFIERS?

Enjoy Hilife free replacement. If your Hilife Cool Mist Humidifier is defective or damaged, we will ship you a replacement for free.

For fast and knowledgeable service, please contact one of our customer service specialists today!

Contact Hilife Customer Support directly through Amazon for any assistance. We are always here to help.

- Go to Amazon's product for and select Hilife.
- Select the Ask a Question button.
- Write and send your message. We will reply you within 24 hours.
- Or click the button below.

[Ask a Question](#) service@hilife.com

WARM TIPS:

- We recommend using distilled water (which contains no minerals or bacteria).
- Never add essential oils or vapor rubs.
- Do not cover the nozzle at any time during use.
- Do not store water in the tank when not in use for a long time.
- Always turn off and unplug the humidifier from a power outlet before cleaning.
- Never immerse the base chamber in water, as this may damage the electronic parts inside.
- We recommend keeping the humidity around 55%. If the relative humidity of the room exceeds 65% RH, it is recommended to set at a low mist level setting or turn off the humidifier to avoid excessive humidity.
- In order to maintain indoor humidity and user comfort, mist will not be turned off when using the auto humidity mode.

How to clean the humidifier?

- Pour a combination of water and white vinegar into the tank using a ratio of 2 parts water to 1 part vinegar. Start by pouring the water slowly, followed by the vinegar. Close the lid and switch gently in a circular motion. Let the solution soak for 20 minutes.
- Empty the base and wipe the base with a soft cloth to clean any mineral build-up. Please pay attention to the electronic parts inside.
- Use a cotton swab or a soft cleaning brush to remove any dirt in the water tank. Do not use hard objects to clean.
- Clean the solution from the water tank. Rinse thoroughly with water until the vinegar smell is gone.
- Let the water tank air dry. We recommend emptying the tank every 2 to 3 weeks and cleaning the base once a week. If you are not using the humidifier for a week or longer, do not leave water inside. Please clean it thoroughly and store it in a dry place.

[\[pdf\]](#) Guide

HF4 V2 0 1 User Guide Hilife Humidifiers for Bedroom 3L Ultrasonic Cool Mist Home Baby Nursery Plants Quiet Top Fill Air Humidifier Lasts Up to 30 Hours Auto Shut Off Filterless Kitchen 91umvJtMAEL m media amazon images I |||

...
 lang: score:18 filesize: 598.2 K page_count: 1 document date: 2023-08-09