

[manuals.plus](#) /› [Homatics](#) /› [Homatics DONGLE G 4K HDMI Android Google TV 11 with Voice Remote User Manual](#)

Homatics DONGLE G

Homatics DONGLE G 4K HDMI Streaming Device

User Manual

1. INTRODUCTION

The Homatics DONGLE G is a compact and powerful 4K HDMI streaming device designed to transform any compatible display into a smart Google TV experience. Running on Android Google TV 11, it provides access to a vast library of applications, movies, and shows. With integrated Wi-Fi, LAN connectivity, and a voice-enabled remote control, it offers a comprehensive and user-friendly entertainment solution.



Image: The Homatics DONGLE G streaming dongle and its accompanying voice remote control, shown alongside the product packaging.

2. WHAT'S IN THE Box

Verify that all components are present in the package:

- Homatics DONGLE G (Model 700D)
- Remote Control (Voice-enabled)
- Power Adapter
- Power Cable
- User Manual (this document)




What's in the box



Power Adapter



Remote Control



Power Cable



700D



Manual

Image: A visual representation of the Homatics DONGLE G package contents, including the dongle, remote, power adapter, power cable, and manual.

3. PRODUCT OVERVIEW

Familiarize yourself with the Homatics DONGLE G and its remote control:

3.1. Homatics DONGLE G Device

The dongle features an integrated HDMI connector for direct plug-in to your TV. It includes a USB-C port for power and potential expansion, and an RJ45 Ethernet port for wired network connectivity.

3.2. Voice Remote Control

The remote control allows for intuitive navigation and voice commands. Key buttons include Power, Home, Back, Volume Up/Down, Channel Up/Down, and dedicated buttons for popular streaming services like YouTube and Netflix. The central directional pad is used for menu navigation.



Image: A close-up view of the Homatics DONGLE G, highlighting its HDMI connector, USB-C port, and RJ45 port, alongside the voice remote control.

4. SETUP GUIDE

- 1. Connect the Dongle:** Plug the Homatics DONGLE G directly into an available HDMI port on your television or display.
- 2. Connect Power:** Connect the provided power cable to the USB-C port on the dongle and then plug the power adapter into a wall outlet. The device will power on automatically.
- 3. Select HDMI Input:** Using your TV's remote control, select the corresponding HDMI input source to which the Homatics DONGLE G is connected.
- 4. Pair Remote Control:** Follow the on-screen instructions to pair the Homatics remote control via Bluetooth. This typically involves holding down specific buttons on the remote until a pairing confirmation appears.
- 5. Initial Setup:** Follow the on-screen prompts to complete the initial setup, which includes connecting to your Wi-Fi network (or using the LAN port), logging into your Google account, and installing essential apps.




Image: The Homatics DONGLE G connected to the HDMI port of a television, illustrating its compact form factor and ease of integration.

5. OPERATING INSTRUCTIONS

5.1. Navigation

Use the directional pad on the remote control to navigate through menus and select items on the Google TV interface. The 'OK' button in the center confirms selections. The 'Back' button returns to the previous screen, and the 'Home' button takes you to the main Google TV home screen.

5.2. Voice Control (Google Assistant)

Press the Google Assistant button on your remote (usually a microphone icon) and speak clearly into the remote to issue commands. You can search for content, open apps, control smart home devices, and get information.

5.3. App Installation and Management

Access the Google Play Store from the home screen to download and install a wide variety of streaming apps, games, and utilities. Apps can be managed (moved, uninstalled) from the 'Apps' section in the Google TV interface settings.



Dongle G 4K



Google TV



Image: The Homatics DONGLE G displaying the Google TV interface on a television screen, showcasing various streaming service icons and content recommendations.

Google Play Store

From popular games to the latest apps, explore endless possibilities. Join now and discover your next favorite app!



Image: The Google Play Store interface as seen on a television screen via the Homatics DONGLE G, illustrating the availability of numerous applications.

6. CONNECTIVITY

6.1. Wi-Fi Connection

The device supports Wi-Fi 5 (802.11 b/g/n/ac) for wireless internet access. During initial setup, you will be prompted to select your Wi-Fi network and enter the password. To change Wi-Fi settings later, navigate to Settings > Network & Internet.

6.2. LAN (Ethernet) Connection


For a more stable and potentially faster internet connection, connect an Ethernet cable from your router to the RJ45 port on the Homatics DONGLE G. The device will automatically detect and prioritize the wired connection.

6.3. Bluetooth Connectivity

The Homatics DONGLE G features Bluetooth 5.0, allowing you to connect compatible accessories such as headphones, gamepads, or external speakers. To pair a new Bluetooth device, go to Settings > Remotes & Accessories > Pair new device.

6.4. USB-C Expansion

The USB-C port on the dongle can be used for power and also supports connection of certain USB accessories via a compatible hub (not included). This allows for expanded storage (SSD), gamepads, or webcams for enhanced functionality.



The advertisement features the Homatics logo with a stylized house icon and the word "HOMATICS" below it. The main title "More Possibilities" is displayed in large, bold, white letters. To the left of the text, there is a vertical image of the Homatics DONGLE G, which is a rectangular device with a USB-C port on top and a power port on the side. To the right of the text, there are four small images representing different accessories: a USB drive, an SSD, a gamepad, and a webcam. Below these images is a teal-colored button with the text "You can have even more". At the bottom of the advertisement, there is a section of text: "Experience unrestricted WiFi connections or enjoy faster, more stable RJ45 wired network connections for uninterrupted operation!" To the right of this text is an image of a silver-colored USB-C hub with various ports, including an RJ45 port, a USB port, and a power port.

More Possibilities

Unlock endless expansion possibilities with USB-C ports, allowing you to effortlessly connect additional accessories!

USB SSD Gamepad Webcam

You can have even more

Experience unrestricted WiFi connections or enjoy faster, more stable RJ45 wired network connections for uninterrupted operation!

Image: The Homatics DONGLE G connected to a USB-C hub, illustrating the potential for connecting various accessories such as USB drives, SSDs, gamepads, and webcams.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device and remote. Do not use liquid cleaners or aerosols.
- **Ventilation:** Ensure the device is placed in a well-ventilated area to prevent overheating. Do not cover the dongle.
- **Software Updates:** The device will periodically receive software updates. Ensure it is connected to the internet to receive these updates, which improve performance and add new features.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Solution
No power/Device not turning on	Ensure the power cable is securely connected to the dongle and the power adapter is plugged into a working electrical outlet. Try a different outlet.
No signal on TV	Verify the dongle is fully inserted into the HDMI port. Check that your TV is set to the correct HDMI input source. Try a different HDMI port.
Remote control not responding	Ensure the remote has fresh batteries. Re-pair the remote by following the on-screen instructions during initial setup or via Settings > Remotes & Accessories.
Cannot connect to Wi-Fi	Check your Wi-Fi password. Ensure your router is working correctly. Try restarting your router and the Homatics DONGLE G. Move the device closer to the router if possible.
App crashes or freezes	Try force-stopping the app (Settings > Apps > [App Name] > Force stop). Clear the app's cache (Settings > Apps > [App Name] > Clear cache). If the problem persists, uninstall and reinstall the app.

9. SPECIFICATIONS

Technical specifications for the Homatics DONGLE G:

Feature	Detail
Model Name	DONGLE G
Operating System	Android Google TV 11
Resolution	Up to 4K UHD
Processor	Quad Core Cortex-A35 (Amlogic S905Y4)
RAM	2GB LPDDR4
Flash Storage	8GB eMMC Flash
Connectivity	Wi-Fi 5 (802.11 b/g/n/ac), Bluetooth 5.0, RJ45 (10/100M Ethernet)
Video Output	HDMI 2.1
Audio Support	Dolby Audio, Dolby Atmos
Special Features	Chromecast built-in, Google Assistant
Power Input	DC 5V (via USB-C)



Image: A visual summary of the Homatics DONGLE G's technical specifications, including processor, RAM, storage, connectivity, and audio support.



Image: Illustration highlighting the Homatics DONGLE G's support for Dolby Atmos and Dolby Audio technologies, enhancing the immersive sound experience.

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Homatics website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.



Image: The Homatics remote control, emphasizing its integration with Google Assistant for voice commands and Chromecast built-in for casting content.