

[Manuals.plus](#) /

› [Dreo](#) /

› Dreo Oil Filled Radiator User Manual

Dreo DR-HSH010

Dreo Oil Filled Radiator User Manual

Model: DR-HSH010 | Brand: Dreo

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Dreo Oil Filled Radiator. Please read it thoroughly before first use and retain it for future reference.



Figure 1: Dreo Oil Filled Radiator (Space Grey Large) with included remote control.

SETUP AND ASSEMBLY

Your Dreo Oil Filled Radiator comes with pre-attached wheels for easy mobility. No complex assembly is required.

Unpacking

- Carefully remove the heater from its packaging.
- Inspect the heater for any signs of damage. If damaged, do not operate and contact customer support.
- Ensure all components are present: Main heater unit, remote control, and user manual.

Placement

- Place the heater on a firm, level surface.
- Ensure there is at least 3 feet (0.9 meters) of clear space around the heater to allow for proper heat circulation and to prevent fire hazards.
- Do not place the heater near curtains, drapes, or other flammable materials.
- Plug the heater directly into a 120V wall outlet. Do not use extension cords or power strips.

DREO
NO.1
Space Heater
Two Consecutive Years on Amazon U.S.

DREO | Radiator Heater

**Full-scale Heat.
All-around Comfort.**



7 M-shaped
fins

39.5% Higher
dissipation area

*Source: Ranking based on the Stackline data for Amazon U.S. retail sales of space heaters from January 2023 to January 2025.

Figure 2: Proper placement of the Dreo Radiator Heater for optimal performance and safety.

OPERATING INSTRUCTIONS

The Dreo Oil Filled Radiator features a user-friendly digital display and touch controls, along with a remote control for convenient operation.

Control Panel and Display

The large LED display shows the current temperature and selected mode. Touch controls allow for easy adjustment of settings.



Figure 3: Sleek touch panel for intuitive control.

Power On/Off

- Press the power button on the unit or remote control to turn the heater ON or OFF.

Heating Modes and Temperature Control

Choose from three heating levels (600W, 900W, 1500W) or Eco Mode for tailored power consumption. The digital thermostat allows precise temperature setting between 41°F and 95°F.

- Use the '+' and '-' buttons to adjust the desired temperature.
- Select Eco Mode for optimized energy efficiency, where the heater intelligently maintains your set temperature.

Warm Up the Room Before You Come Back



Figure 4: The 24-hour timer allows for pre-heated comfort.

24-Hour Timer

- Set the timer to automatically turn the heater ON or OFF after a specified number of hours (up to 24 hours).

Child Lock

- Activate the child lock feature to prevent accidental changes to settings. Refer to the user manual for specific activation/deactivation steps.
-

SAFETY FEATURES

Your Dreo Oil Filled Radiator is equipped with multiple safety features to ensure peace of mind during operation.

- **Triple Overheat Protection:** The heater will automatically shut off if it detects overheating.
- **Tip-Over Protection:** An internal sensor will automatically turn off the heater if it is accidentally knocked over.
- **Fire-Resistant Material:** Constructed with V-0 flame retardant materials for enhanced safety.
- **Burn-Proof Plug:** Designed with an enhanced safety plug to prevent electrical hazards.
- **ETL Listed:** Certified for safety by ETL.

Unbreakable Safety

Triple
Overheat Protection



40°
Tip-over Protection

V-0 Flame
Retardant Material

Enhanced Safety Plug



Figure 5: Multiple safety mechanisms ensure secure operation.

Regular maintenance helps ensure the longevity and efficient performance of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

If you encounter issues with your Dreo Oil Filled Radiator, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; Power outlet issue; Tip-over switch activated; Overheat protection activated.	Ensure plug is fully inserted; Check power outlet; Place heater upright on a flat surface; Unplug and allow to cool for 30 minutes before restarting.
Heater is not heating.	Temperature setting too low; Eco mode active; Room temperature already reached.	Increase desired temperature; Adjust mode settings; Heater will resume heating when room temperature drops.
Unusual odor during first use.	Factory residue burning off.	This is normal for initial use. Operate the heater in a well-ventilated area for a few hours until the odor dissipates.

For issues not listed here, or if problems persist, please contact Dreo customer support.

SPECIFICATIONS

Feature	Detail
Brand	Dreo
Model Number	DR-HSH010
Color	Space Grey
Power	1500W (Max)
Voltage	120 Volts
Product Dimensions	12.83"D x 9.92"W x 26.14"H
Item Weight	17.6 pounds
Heating Coverage	250 sq.ft
Min Temperature Setting	41 Degrees Fahrenheit

Feature	Detail
Max Temperature Setting	95 Degrees Fahrenheit
Special Features	Energy Efficient, Digital Display, Electronic Thermostat, Overheat Protection, Tip-Over Protection






Figure 6: Product dimensions for planning placement.

WARRANTY AND SUPPORT

For detailed warranty information, product registration, or further assistance, please refer to the official user manual PDF or visit the Dreo brand store.

- [Download User Manual \(PDF\)](#)
- [Visit the Official Dreo Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0C6XLMXY4>

More documents and user manuals: <https://manuals.plus/>