

Wapaneus HLT1-LT-F

Wapaneus HLT1-LT-F Foot Pocket Heated Electric Throw Blanket User Manual

Model: HLT1-LT-F | Brand: Wapaneus

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Wapaneus Heated Electric Throw Blanket. Retain this manual for future reference.

- The blanket is ETL certified, ensuring high standards of performance and safety.
- Features overheat protection and short-circuit protection design for peace of mind.
- Do not stack electric throws.
- Always turn off the power and unplug the blanket when leaving the room or when not in use.
- Avoid covering the thermostat/controller with electric blankets when in use.
- If the thermostat flashes red, unplug the thermostat and reconnect the power supply.



Figure 1: Do not stack electric blankets to prevent overheating.




Figure 2: Ensure the thermostat is not covered during use.



Figure 3: Always unplug the blanket when not in use or when leaving the room.

2. PRODUCT OVERVIEW


The Wapaneus Foot Pocket Heated Electric Throw Blanket is designed for warmth and comfort. It features a double-sided 220GSM flannel material and integrated heating wires.



Figure 4: The Wopaneus Heated Electric Throw Blanket.

Saving More Heating Bills

The heating wires are densely and evenly distributed that distribute heat evenly across the blanket



☞ Soft, fuzzy surface of the **220GSM** extra cozy flannel that feels gentle against the skin.

☞ The rapid heating function of the heating wires makes you feel warm in **3 minutes**.



Figure 5: Internal structure of the blanket, highlighting the heating wire and soft flannel layers.

3. SETUP

1. Unpack the heated blanket and controller from its packaging.
2. Ensure the blanket is laid flat and free from folds or creases.
3. Connect the controller cord securely to the blanket's connector.
4. Plug the power cord into a standard electrical outlet. The control line is approximately 10.2 ft (or 15 ft as per some product images) long.



10 Heating
Settings



4 Hours
Auto-Off



4-level timing
function



10.2ft length the
control line



Foot Pocket Design

 **Targeted warmth:** The foot pocket concentrates heat specifically on the feet, which tend to get colder than the rest of the body

 **Improved Circulation:** Keeping your feet warm can promote better blood circulation.

Figure 6: The controller connects to the blanket for power and heat regulation.

4. OPERATING INSTRUCTIONS

The blanket features a user-friendly controller to adjust heat and timer settings.

- **Power On/Off:** Press the power button on the controller to turn the blanket on or off.
- **Heat Settings:** The blanket offers 10 heat settings, ranging from 95°F to 113°F. Use the '+' and '-' buttons to select your desired warmth level.
- **Timer Settings:** The blanket has an auto-off function that can be set for up to 4 hours. Some product images indicate a 1-12 hour timer function. Please refer to your specific product's controller for exact timing options.
- **Foot Pocket:** Utilize the integrated foot pocket for targeted warmth to your feet, which can also help improve circulation.

Temperature Controller

Multi-Level Control As You Like



10 Heating Levels



1-12 hours time settings



15ft length the control line



86°F-117°F(-6°F/+6°F)
Choose your temperature

Figure 7: The digital temperature controller allows precise heat and timer adjustments.




Safe & Reliable NTC-PTC

⚠ When the thermostat flashes red, Please unplug the thermostat and power supply, reconnect the thermostat and then plug in the power supply.

Wapaneus Fast Heating

3 minutes fast heating, keep out the cold.



Time (min)	Wapaneus (°F)	Others (°F)
0	0	0
3	105	45
5	125	65
10	125	85
15	125	95
20	125	100
25	125	95
30	125	90
35	125	85
40	125	80

Choose Your Temperature

95°F-113°F (-6°F/ +6°F)

Figure 8: The blanket heats up quickly, reaching desired temperatures within minutes.

Video 1: An overview of the Wapaneus Cozy Heated Throw Blanket, demonstrating its features and comfort.

5. MAINTENANCE

The blanket is machine washable for easy care. Follow these steps to ensure longevity:

1. Always remove the heating controller and unplug the power cord before washing.
2. Wash the throw by machine or hand in water below 30°C/86°F. Use a delicate or gentle cycle if machine washing.
3. Do not use commercial dryers or laundromat dryers, as excessive heat can damage the internal wiring.
4. To dry, preheat your dryer on the 'low' temperature setting for 2 minutes.
5. Place the throw into the dryer and tumble dry for 10 minutes at a low temperature.
6. Remove the throw while it is still damp and gently stretch it to its original size.
7. Drape the heated product over a clothesline or a shower rod to air dry. Do not use clothespins.
8. The heated product must be COMPLETELY dry before reconnecting the power plug or control plug.



Figure 9: Detach the controller before washing the blanket.



⚠ Caution: 1. Do not use commercial dryers or the dryers at your local Laundromat. They get too hot and would damage the wiring of the heated product.
2. Unplug the power cord before washing and drying.



Instructions of Dryer

1. Preheat the dryer on the "low" temperature setting for 2 minutes.
2. Place blanket/mattress pad/throw into the dryer and tumble dry for 10 minutes at a low temperature.
3. Remove the blanket/mattress pad/throw while it is still damp and gently stretch it to its original size.
4. Drape the heated product over a clothesline or a shower rod. DO NOT use clothespins
5. Heated product must be COMPLETELY dry before reconnecting the power plug or control plug.

Figure 10: Detailed instructions for drying the blanket safely.

6. TROUBLESHOOTING

- **Blanket not heating:** Ensure the controller is securely connected to the blanket and the power cord is firmly plugged into a working electrical outlet.
- **Thermostat flashing red:** This indicates a potential issue. Unplug the thermostat from the blanket and the power supply, then reconnect it. If the issue persists, contact customer support.
- **Uneven heating:** Ensure the blanket is laid flat without excessive folds or items stacked on top, which can cause heat concentration.

7. SPECIFICATIONS

Feature	Detail
Model Number	HLT1-LT-F
Dimensions	50"W x 60"L
Material	Flannel (220GSM)
Color	Mushroom
Heating Levels	10 (95°F to 113°F)
Auto Shut-Off	Up to 4 hours (some models 1-12 hours)
Special Feature	Foot Pocket
Care Instructions	Machine Washable (below 30°C/86°F)
Item Weight	3.45 pounds
Manufacturer	Ningbo Royal Peace Household Products Co.,Ltd

Sizing Reference




Figure 11: Sizing reference for different blanket dimensions.

8. WARRANTY AND SUPPORT

For any quality-related issues or support needs, please contact Wapaneus customer service. We are committed to providing a satisfactory solution within 24 hours.

Please refer to the official Wapaneus website or your product packaging for specific warranty details and contact information.

Visit the [Wapaneus Store](#) for more information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What does a flashing 'F' mean on the controller for my Wapaneus HLT1-LT-F heated blanket, and can I order a replacement controller?

A flashing code on the controller (often 'F' or a flashing red light) typically indicates a connection error or a safety protection trigger. Please try the following troubleshooting steps to reset the unit: Unplug the...

[Read full answer](#)